

RDR-VX511/VX515

RMT-D224A

SERVICE MANUAL

US Model

RDR-VX511/VX515

Canadian Model

RDR-VX515



Photo: RDR-VX515

TS-10 MECHANISM

Refer to the SERVICE MANUAL of VHS MECHANICAL ADJUSTMENT MANUAL VII for MECHANICAL ADJUSTMENTS. (9-921-790-11)

SPECIFICATIONS

System

[DVD recorder section]

Laser

Semiconductor laser

Audio recording format

Dolby Digital

Video recording format

MPEG Video

[VCR section]

Format

VHS NTSC standard

Video recording system

Rotary head helical scanning

FM system

Video heads

Double azimuth four heads

Video signal

NTSC color, EIA standards

Tape speed

SP: 33.35 mm/s ($1\frac{3}{8}$ inches/s)

EP: 11.12 mm/s ($\frac{7}{16}$ inches/s)

LP: 16.67 mm/s ($\frac{11}{16}$ inches/s),
playback only

Maximum recording/playback time

8 hrs. in EP mode (with T-160 tape)

Rewind time

Approx. 1 min (with T-120 tape)

[Tuner section]

Channel coverage

VHF 2 to 13

UHF 14 to 69

CATV A-8 to A-1, A to W, W+1 to
W+84

Antenna

75-ohm antenna terminal for VHF/UHF

[Timer section]

Clock

Quartz locked

Timer indication

12-hour cycle

Timer setting

12 programs in total (max.)

Inputs and outputs

LINE 1 IN and LINE 2 IN

VIDEO IN, phono jack (1 each)

Input signal: 1 Vp-p, 75 ohms,
unbalanced, sync negative

AUDIO IN, phono jacks (2 each)

Input level: 327 mVrms

Input impedance: more than 47 kilohms

LINE 2 IN

S VIDEO, 4-pin, mini-DIN jack

Y: 1.0 Vp-p, unbalanced, sync negative

C: 0.286 Vp-p, load impedance 75 ohms

DV IN, 4-pin jack, i.LINK S100

LINE OUT

VIDEO OUT, phono jack (1)

Output signal: 1 Vp-p, 75 ohms,
unbalanced, sync negative

AUDIO OUT, phono jacks (2)

Standard output: 327 mVrms

Load impedance: 47 kilohms

Output impedance: less than 10 kilohms

— Continued on next page —

VIDEO CASSETTE RECORDER/ DVD RECORDER



SONY®

DIGITAL AUDIO OUT
OPTICAL, Optical output jack
–18 dBm (wave length: 660 nm)
COAXIAL, phono jack
Output signal: 0.5 Vp-p, 75 ohms

COMPONENT VIDEO OUT (Y, P_B, P_R)
Phono jack
Y: 1.0 Vp-p/P_B, P_R: 0.7 Vp-p, 75 ohms

S VIDEO OUT
4-pin, mini-DIN jack
Y: 1.0 Vp-p, unbalanced, sync negative
C: 0.286 Vp-p, load impedance 75 ohms

General

Power requirements
120 V AC, 60 Hz

Power consumption
40 W

Power back-up
Back-up duration: 0 min

Operating temperature
5°C to 35°C (41°F to 95°F)

Storage temperature
–20°C to 60°C (–4°F to 140°F)

Operating humidity
25% to 80%

Dimensions including projecting parts and controls (w/h/d)
Approx. 430 × 85 × 334 mm
(Approx. 17 × 3³/₈ × 13¹/₄ inches)

Mass
Approx. 4.9 kg (Approx. 10.8 lbs)


Supplied accessories
Remote commander (remote) (1)
Size AA (R6) batteries (2)
Antenna cable (1)
Audio/video cord (1)

Design and specifications are subject to change without notice.

SAFETY CHECK-OUT

After correcting the original service problem, perform the following safety checks before releasing the set to the customer:

1. Check the area of your repair for unsoldered or poorly-soldered connections. Check the entire board surface for solder splashes and bridges.
2. Check the interboard wiring to ensure that no wires are "pinched" or contact high-wattage resistors.
3. Look for unauthorized replacement parts, particularly transistors, that were installed during a previous repair. Point them out to the customer and recommend their replacement.
4. Look for parts which, though functioning, show obvious signs of deterioration. Point them out to the customer and recommend their replacement.
5. Check the line cord for cracks and abrasion. Recommend the replacement of any such line cord to the customer.
6. Check the B+ voltage to see it is at the values specified.
7. Check the antenna terminals, metal trim, "metallized" knobs, screws, and all other exposed metal parts for AC leakage. Check leakage as described below.



WARNING!!

WHEN SERVICING, DO NOT APPROACH THE LASER EXIT WITH THE EYE TOO CLOSELY. IN CASE IT IS NECESSARY TO CONFIRM LASER BEAM EMISSION, BE SURE TO OBSERVE FROM A DISTANCE OF MORE THAN 25 cm FROM THE SURFACE OF THE OBJECTIVE LENS ON THE OPTICAL PICK-UP BLOCK.

SAFETY-RELATED COMPONENT WARNING!!

COMPONENTS IDENTIFIED BY MARK $\triangle$ OR DOTTED LINE WITH MARK $\triangle$ ON THE SCHEMATIC DIAGRAMS AND IN THE PARTS LIST ARE CRITICAL TO SAFE OPERATION. REPLACE THESE COMPONENTS WITH SONY PARTS WHOSE PART NUMBERS APPEAR AS SHOWN IN THIS MANUAL OR IN SUPPLEMENTS PUBLISHED BY SONY.

LEAKAGE TEST

The AC leakage from any exposed metal part to earth ground and from all exposed metal parts to any exposed metal part having a return to chassis, must not exceed 0.5 mA (500 microamperes). Leakage current can be measured by any one of three methods.

1. A commercial leakage tester, such as the Simpson 229 or RCA WT-540A. Follow the manufacturers' instructions to use these instruments.
2. A battery-operated AC milliammeter. The Data Precision 245 digital multimeter is suitable for this job.
3. Measuring the voltage drop across a resistor by means of a VOM or battery-operated AC voltmeter. The "limit" indication is 0.75V, so analog meters must have an accurate low-voltage scale. The Simpson 250 and Sanwa SH-63Trd are examples of a passive VOM that is suitable. Nearly all battery operated digital multimeters that have a 2V AC range are suitable. (See Fig. A)

Unleaded solder

Boards requiring use of unleaded solder are printed with the lead-free mark (LF) indicating the solder contains no lead.

(Caution: Some printed circuit boards may not come printed with the lead free mark due to their particular size.)



: LEAD FREE MARK

Unleaded solder has the following characteristics.

- Unleaded solder melts at a temperature about 40°C higher than ordinary solder.
Ordinary soldering irons can be used but the iron tip has to be applied to the solder joint for a slightly longer time.
Soldering irons using a temperature regulator should be set to about 350°C.
Caution: The printed pattern (copper foil) may peel away if the heated tip is applied for too long, so be careful!
- Strong viscosity
Unleaded solder is more viscous (sticky, less prone to flow) than ordinary solder so use caution not to let solder bridges occur such as on IC pins, etc.
- Usable with ordinary solder
It is best to use only unleaded solder but unleaded solder may also be added to ordinary solder.

CAUTION:

The use of optical instrument with this product will increase eye hazard.

CAUTION

Use of controls or adjustments or performance of procedures other than those specified herein may result in hazardous radiation exposure.

ATTENTION AU COMPOSANT AYANT RAPPORT À LA SÉCURITÉ!

LES COMPOSANTS IDENTIFIÉS PAR UNE MARQUE $\triangle$ SUR LES DIAGRAMMES SCHÉMATIQUES ET LA LISTE DES PIÈCES SONT CRITIQUES POUR LA SÉCURITÉ DE FONCTIONNEMENT. NE REMPLACER CES COMPOSANTS QUE PAR DES PIÈCES SONY DONT LES NUMÉROS SONT DONNÉS DANS CE MANUEL OU DANS LES SUPPLÉMENTS PUBLIÉS PAR SONY.

TABLE OF CONTENTS

Precautions

1	Safety Precautions	5
2	Servicing Precautions	7
3	ESD Precautions	8
4	Handling the Optical Pick-up	9
5	Reset operation after IC203 or IC205 was replaced	10

1. General

Hookups and Settings	1-2
Quick Guide to Disc Types	1-6
DVD Playback	1-7
DVD Recording	1-10
DVD Editing	1-13
VCR Playback	1-16
VCR Recording	1-17
Dubbing (TAPA ↔ DVD)	1-19
DV/D8 Dubbing (DV/D8 ↔ DVD)	1-21
Settings and Adjustments	1-22
Additional Information	1-25

2. Disassembly and Reassembly

2-1	Cabinet and PCB	2-1
2-1-1	Cabinet Top Removal	2-1
2-1-2	Bottom Cover Removal	2-1
2-1-3	Ass'y Front Panel Removal	2-1
2-1-4	Function Timer PCB Removal	2-1
2-1-5	Chassis Removal	2-2
2-1-6	VCR Main PCB Removal	2-2
2-2	Circuit Board Locations	2-3
2-3	VCR Deck Parts Locations	2-4
2-3-1	Top View	2-4
2-3-2	Bottom View	2-6
2-4	VCR DECK	2-7
2-4-1	Holder FL Cassette Ass'y Removal	2-7
2-4-2	Lever FL Arm Ass'y Removal	2-7
2-4-3	Lever FL Door Removal	2-8
2-4-4	Slider FL Drive, Gear FL Cam Removal	2-8
2-4-5	Gear Worm Wheel Removal	2-9
2-4-6	Cable Flat Removal	2-9
2-4-7	Motor Loading Ass'y Removal	2-10
2-4-8	Bracket Gear, Gear Joint 2, 1 Removal	2-10
2-4-9	Gear Loading Drive, Slider Cam, Lever Load S, T Ass'y Removal	2-11
2-4-10	Gear Loading Drive, Slider Cam, Lever Load S, T Ass'y Assembly	2-11
2-4-11	Lever Pinch Drive, Lever Tension Drive Removal	2-12
2-4-12	Lever Tension Ass'y, Band Brake Ass'y Removal	2-12
2-4-13	Lever Brake S, T Ass'y Removal	2-13
2-4-14	Gear Idle Ass'y Removal	2-13
2-4-15	Disk S, T Reel Removal	2-14
2-4-16	Holder Clutch Ass'y Removal	2-14
2-4-17	Lever Up Down Ass'y, Gear Center Ass'y Removal	2-15
2-4-18	Guide Cassette Door Removal	2-15
2-4-19	Lever Unit Pinch Ass'y, Plate Joint, Spring Pinch Drive Removal	2-16
2-4-20	Lever #9 Guide Ass'y Removal	2-16
2-4-21	FE Head Removal	2-17
2-4-22	ACE Head Removal	2-17
2-4-23	Slider S, T Ass'y Removal	2-18
2-4-24	Plate Ground Deck, Cylinder Ass'y Removal	2-18
2-4-25	Hook Capstan, Belt Pulley Removal	2-19
2-4-26	Motor Capstan Ass'y Removal	2-19
2-4-27	Post #8 Guide Ass'y Removal	2-20
2-4-28	Level Head Cleaner Ass'y Removal	2-20
2-4-29	How to Eject the Cassette Tape	2-20
2-5	The Table of Cleaning, Lubrication and Replacement Time about Principal Parts	2-21

3. Block Diagram 3-1

4. PCB Diagrams

4-1	VCR Main PCB	4-3
4-2	DVD Main PCB	4-7
4-3	Jack PCB	4-11
4-4	DV Jack PCB	4-15
4-5	Function Timer PCB	4-15

5. Schematic Diagrams

◆ Block Identification of Main PCB	5-3
5-1 S.M.P.S (VCR Main PCB)	5-5
5-2 Power (VCR Main PCB)	5-7
5-3 Logic (VCR Main PCB)	5-9
5-4 A/V (VCR Main PCB)	5-11
5-5 Hi-Fi (VCR Main PCB)	5-13
5-6 Function Timer (Function Timer PCB)	5-15
5-7 Encoder (DVD Main PCB)	5-17
5-8 Decoder (DVD Main PCB)	5-19
5-9 Video Decoder and Connector (DVD Main PCB)	5-21
5-10 DV Interface and 1394 Connector (DVD Main PCB)	5-23
5-11 Connectors and Power (DVD Main PCB)	5-25
5-12 Mts/Tuner (JACK PCB)	5-27
5-13 AV IN/OUT (JACK PCB)	5-29
5-14 Component/Super Out (JACK PCB)	5-31

6. Alignment and Adjustments

6-1	VCR Adjustment	6-1
6-1-1	Reference	6-1
6-1-2	Head Switching Point Adjustment	6-3
6-2	VCR Mechanical Adjustment	6-4
6-2-1	Tape Transport System and Adjustment Locations	6-4
6-2-2	Tape Transport System Adjustment	6-5
6-2-3	Reel Torque	6-10

7. Troubleshooting 7-1

8. Repair Parts List

8-1	Exploded Views	8-2
8-1-1	Cabinet Assembly	8-2
8-1-2	VCR Mechanical Parts (Top Side)	8-3
8-1-3	VCR Mechanical Parts (Bottom Side)	8-4
8-2	Electrical Parts List	8-5

PRECAUTIONS

1 SAFETY PRECAUTIONS

- 1) Before returning an instrument to the customer, always make a safety check of the entire instrument, including, but not limited to, the following items:

- (1) Be sure that no built-in protective devices are defective or have been defeated during servicing.

(1) Protective shields are provided to protect both the technician and the customer. Correctly replace all missing protective shields, including any removed for servicing convenience.

(2) When reinstalling the chassis and/or other assembly in the cabinet, be sure to put back in place all protective devices, including, but not limited to, nonmetallic control knobs, insulating fish papers, adjustment and compartment covers/shields, and isolation resistor/capacitor networks. Do not operate this instrument or permit it to be operated without all protective devices correctly installed and functioning.

- (2) Be sure that there are no cabinet openings through which adults or children might be able to insert their fingers and contact a hazardous voltage. Such openings include, but are not limited to, excessively wide cabinet ventilation slots, and an improperly fitted and/or incorrectly secured cabinet back cover.

- (3) Leakage Current Hot Check-With the instrument completely reassembled, plug the AC line cord directly into a 120V AC outlet. (Do not use an isolation transformer during this test.) Use a leakage current tester or a metering system that complies with American National Standards institute (ANSI) C101.1 Leakage Current for Appliances and Underwriters Laboratories (UL) 1270 (40.7). With the instrument's AC switch first in the ON position and then in the OFF position, measure from a known earth ground (metal water pipe, conduit, etc.) to all exposed metal parts of the instrument (antennas, handle brackets, metal cabinets, screwheads, metallic overlays, control shafts, etc.), especially any exposed metal parts that offer an electrical return path to the chassis.

Any current measured must not exceed 0.5mA. Reverse the instrument power cord plug in the outlet and repeat the test. See Fig. 1.

Any measurements not within the limits specified herein indicate a potential shock hazard that must be eliminated before returning the instrument to the customer.




Fig. 1 AC Leakage Test

- (4) Insulation Resistance Test Cold Check-(1) Unplug the power supply cord and connect a jumper wire between the two prongs of the plug. (2) Turn on the power switch of the instrument. (3) Measure the resistance with an ohmmeter between the jumpered AC plug and all exposed metallic cabinet parts on the instrument, such as screwheads, antenna, control shafts, handle brackets, etc. When an exposed metallic part has a return path to the chassis, the reading should be between 1 and 5.2 megohm. When there is no return path to the chassis, the reading must be infinite. If the reading is not within the limits specified, there is the possibility of a shock hazard, and the instrument must be repaired and rechecked before it is returned to the customer. See Fig. 2.




Fig. 2 Insulation Resistance Test

- 2) Read and comply with all caution and safety related notes on or inside the cabinet, or on the chassis.
- 3) Design Alteration Warning-Do not alter or add to the mechanical or electrical design of this instrument. Design alterations and additions, including but not limited to, circuit modifications and the addition of items such as auxiliary audio output connections, might alter the safety characteristics of this instrument and create a hazard to the user. Any design alterations or additions will make you, the servicer, responsible for personal injury or property damage resulting therefrom.
- 4) Observe original lead dress. Take extra care to assure correct lead dress in the following areas:
 - (1) near sharp edges, (2) near thermally hot parts (be sure that leads and components do not touch thermally hot parts), (3) the AC supply, (4) high voltage, and (5) antenna wiring. Always inspect in all areas for pinched, out-of-place, or frayed wiring. Do not change spacing between a component and the printed-circuit board. Check the AC power cord for damage.
- 5) Components, parts, and/or wiring that appear to have overheated or that are otherwise damaged should be replaced with components, parts and/or wiring that meet original specifications. Additionally, determine the cause of overheating and/or damage and, if necessary, take corrective action to remove any potential safety hazard.

-
- 6) Product Safety Notice-Some electrical and mechanical parts have special safety-related characteristics which are often not evident from visual inspection, nor can the protection they give necessarily be obtained by replacing them with components rated for higher voltage, wattage, etc. Parts that have special safety characteristics are identified by shading, an () or a () on schematics and parts lists. Use of a substitute replacement that does not have the same safety characteristics as the recommended replacement part might create shock, fire and/or other hazards. Product safety is under review continuously and new instructions are issued whenever appropriate.

2 SERVICING PRECAUTIONS

CAUTION: Before servicing units covered by this service manual and its supplements, read and follow the Safety Precautions section of this manual.

Note: If unforeseen circumstances create conflict between the following servicing precautions and any of the safety precautions, always follow the safety precautions. Remember: Safety First.

2-1 General Servicing Precautions

- (1) a. Always unplug the instrument's AC power cord from the AC power source before (1) re-moving or reinstalling any component, circuit board, module or any other instrument assembly, (2) disconnecting any instrument electrical plug or other electrical connection, (3) connecting a test substitute in parallel with an electrolytic capacitor in the instrument.
- b. Do not defeat any plug/socket B+ voltage interlocks with which instruments covered by this service manual might be equipped.
- c. Do not apply AC power to this instrument and/or any of its electrical assemblies unless all solid-state device heat sinks are correctly installed.
- d. Always connect a test instrument's ground lead to the instrument chassis ground before connecting the test instrument positive lead. Always remove the test instrument ground lead last.

Note: Refer to the Safety Precautions section ground lead last.

- (2) The service precautions are indicated or printed on the cabinet, chassis or components. When servicing, follow the printed or indicated service precautions and service materials.
- (3) The components used in the unit have a specified flame resistance and dielectric strength.
When replacing components, use components which have the same ratings. Components identified by shading, by () or by () in the circuit diagram are important for safety or for the characteristics of the unit. Always replace them with the exact replacement components.
- (4) An insulation tube or tape is sometimes used and some components are raised above the printed wiring board for safety. The internal wiring is sometimes clamped to prevent contact with heating components. Install such elements as they were.
- (5) After servicing, always check that the removed screws, components, and wiring have been installed correctly and that the portion around the serviced part has not been damaged and so on. Further, check the insulation between the blades of the attachment plug and accessible conductive parts.

2-2 Insulation Checking Procedure

Disconnect the attachment plug from the AC outlet and turn the power ON. Connect the insulation resistance meter (500V) to the blades of the attachment plug. The insulation resistance between each blade of the attachment plug and accessible conductive parts (see note) should be more than 1 Megohm.

Note: Accessible conductive parts include metal panels, input terminals, earphone jacks, etc.

3 ESD PRECAUTIONS

Electrostatically Sensitive Devices (ESD)

Some semiconductor (solid state) devices can be damaged easily by static electricity.

Such components commonly are called Electrostatically Sensitive Devices (ESD). Examples of typical ESD devices are integrated circuits and some field-effect transistors and semiconductor chip components. The following techniques should be used to help reduce the incidence of component damage caused by static electricity.

- (1) Immediately before handling any semiconductor component or semiconductor-equipped assembly, drain off any electrostatic charge on your body by touching a known earth ground. Alternatively, obtain and wear a commercially available discharging wrist strap device, which should be removed for potential shock reasons prior to applying power to the unit under test.
- (2) After removing an electrical assembly equipped with ESD devices, place the assembly on a conductive surface such as aluminum foil, to prevent electrostatic charge buildup or exposure of the assembly.
- (3) Use only a grounded-tip soldering iron to solder or unsolder ESD devices.
- (4) Use only an anti-static solder removal devices. Some solder removal devices not classified as “anti-static” can generate electrical charges sufficient to damage ESD devices.
- (5) Do not use freon-propelled chemicals. These can generate electrical charges sufficient to damage ESD devices.
- (6) Do not remove a replacement ESD device from its protective package until immediately before your are ready to install it. (Most replacement ESD devices are packaged with leads electrically shorted together by conductive foam, aluminum foil or comparable conductive materials).
- (7) Immediately before removing the protective materials from the leads of a replacement ESD device, touch the protective material to the chassis or circuit assembly into which the device will be installed.

CAUTION: Be sure no power is applied to the chassis or circuit, and observe all other safety precautions.

- (8) Minimize bodily motions when handling unpackaged replacement ESD devices. (Otherwise harmless motion such as the brushing together of your clothes fabric or the lifting of your foot from a carpeted floor can generate static electricity sufficient to damage an ESD device).

4 HANDLING THE OPTICAL PICK-UP

The laser diode in the optical pick up may suffer electrostatic breakdown because of potential static electricity from clothing and your body.

The following method is recommended.

- (1) Place a conductive sheet on the work bench (The black sheet used for wrapping repair parts.)
 - (2) Place the set on the conductive sheet so that the chassis is grounded to the sheet.
 - (3) Place your hands on the conductive sheet (This gives them the same ground as the sheet.)
 - (4) Remove the optical pick up block
 - (5) Perform work on top of the conductive sheet. Be careful not to let your clothes or any other static sources to touch the unit.
- ◆ Be sure to put on a wrist strap grounded to the sheet.
 - ◆ Be sure to lay a conductive sheet made of copper etc. Which is grounded to the table.




Fig.3

- (6) Short the short terminal on the PCB, which is inside the Pick-Up ASS'Y, before replacing the Pick-Up. (The short terminal is shorted when the Pick-Up Ass'y is being lifted or moved.)
- (7) After replacing the Pick-up, open the short terminal on the PCB.

5 Reset operation after IC203 or IC205 was replaced

Be sure to perform the reset by the method described below, if the IC203(IC FLASH MEMORY) or IC205(IC EEPROM) used on the DVD Main board was replaced.

Resetting method

1. Enter the Adjustment mode, and press two times the “1” button on the remote commander.
(For an entering method of Adjustment mode, see 6-1. VCR Adjustment.)
The tray will automatically open and the version information will be displayed on the TV screen.
2. Turn the power off.

1. GENERAL

This section is extracted from RDR-VX515 instruction manual. (2-636-467-11)

About this manual

- Instructions in this manual describe the controls on the remote. You can also use the controls on the recorder if they have the same or similar names as those on the remote.
- The on-screen display illustrations used in this manual may not match the graphics displayed on your TV screen.
- The explanations regarding discs in this manual refer to discs created on this recorder. The explanations do not apply to discs that are created on other recorders and played back on this recorder.

Icon	Meaning
	Functions available for DVD+RWs
	Functions available for DVD-RWs in VR (Video Recording) mode
	Functions available for DVD-RWs in video mode
	Functions available for DVD+Rs
	Functions available for DVD-Rs
	Functions available for DVD VIDEOS
	Functions available for VIDEO CDs or CD-Rs/CD-RWs in video CD format
	Functions available for music CDs or CD-Rs/CD-RWs in music CD format
	Functions available for DATA CDs (CD-Rs/CD-RWs containing MP3* audio tracks or JPEG files)
	Functions available for DATA DVDs (DVD+RWs/DVD-RWs/DVD+Rs/DVD-Rs containing MP3* audio tracks or JPEG files)
	Functions available for VHS VIDEOS


* MP3 (MPEG1 Audio Layer 3) is a standard format defined by ISO/MPEG which compresses audio data.

What is a Video Cassette Recorder/DVD Recorder?

This is a DVD recorder with built-in VHS video deck, and allows recording/playback of DVD discs and VHS tapes. DVD editing is also possible.


Recording and timer recording

Record TV programs on a DVD or VHS tape, either manually or using the timer.



Easy dubbing


Dub in either direction between a DVD disc and VHS tape with the simple press of a button.



* Note that copy-protected signals will not be recorded.


Easy selection between DVD and VCR

Simply press the DVD or VIDEO button to select the media format you want to use.



Quick access to recorded titles - Title List


Display the Title List to view all titles on a disc and select a title for playback or editing.



4


Creating your own program - Playlist

Record a program on a DVD-RW (VR mode), then erase, move or add scenes as you like without changing the original contents.



One Touch Dubbing - DV/D8 Dubbing


Connect your digital video camera to the DV IN jack and press the ONE TOUCH DUBBING button to dub a DV/D8 format tape over to a disc.



8

How to Use the On-Screen Menus

The following three displays are mainly used to operate this recorder. Once you become familiar with the basic operations, you will find the recorder easy to use.




- 1 "Title List"
Displays the list of the disc contents, including the recording information and movie thumbnail image, which allows you to select a title to play or edit.
- 2 "Timer"
Used to set a new timer recording for a disc or VHS tape, as well as change or cancel the timer recordings you set.
- 3 "Edit"
Used to create or edit a Playlist (unfinalized DVD-RWs (VR mode) only).
- 4 "Dubbing"
Used to dub from a disc to a VHS tape and vice versa, and also dub from a DV/D8 format tape to a disc.
- 5 "Disc Setting"
Used to rename, format, or finalize a disc.
- 6 "Setup"
Displays the "Setup" display for setting up the recorder to suit your preferences.

Sub-menu

The sub-menu appears when you select an item from a list menu (e.g., a title from the Title List menu), and press ENTER. The sub-menu displays options applicable only to the selected item. The displayed options differ depending on the situation and disc type.

Select an option by pressing $\uparrow/\downarrow$ and ENTER.

Example: The Title List menu



Options for the selected item

Operation restrictions

Current Operation	Possible Simultaneous Operations			
	VCR Playback	VCR Recording	DVD Playback	DVD Recording
Playing a VHS tape ^{*1}	—	No	No	Yes
Recording on a VHS tape	No	—	Yes	Yes ^{*3}
Playing a DVD ^{*2}	No	Yes	—	No
Recording on a DVD	Yes	Yes ^{*3}	No	—

^{*1} When pressing DVD, VCR playback stops.


^{*2} When pressing VIDEO, DVD playback stops.

^{*3} Only the same program can be recorded on a DVD and a VHS tape.

System Menu

The System Menu appears when you press SYSTEM MENU, and provides entries to all of the recorder's main functions, such as timer recording and setup.

Select an option by pressing $\uparrow/\downarrow$ and ENTER.




9

10

TOOLS

The TOOLS menu appears when you press TOOLS. You can search for a title/chapter/track, check the playing and remaining time, or change audio and repeat settings. The displayed options differ depending on the media type. Press $\uparrow/\downarrow$ to select an option, press $\leftarrow/\rightarrow$ to select the desired item, and press ENTER.

Example: When you press TOOLS while a DVD-RW (VR mode) is playing.



Selectable options

Selectable options on the System Menu differ depending on the media type, disc condition, and operating status.

Example: When a disc or a VHS tape is stopped.

Type	Selectable option
+RW	[Icons]
+RWVR	[Icons]
-RWVR	[Icons]
+R	[Icons]
-R	[Icons]
DVD	[Icons]
VCD	[Icons]
CD	[Icons]
DATA CD	[Icons]
DATA DVD	[Icons]
VHS	[Icons]

*1 Unfinalized disc only
*2 With a disc inserted

To return to the previous display
Press $\leftarrow$ RETURN.

Notes

- The TOOLS menu may not appear during DVD recording.
- The System Menu does not appear when recording on a DVD, or dubbing from VHS tape to a DVD.
- You cannot use the DVD or VIDEO buttons with the System Menu turned on.

Hookups and Settings

Hooking Up the Recorder

Follow steps 1 to 7 to hook up and adjust the settings of the recorder.

Notes

- Plug cords securely to prevent unwanted noise.
- See the instructions supplied with the components to be connected.
- You cannot connect this recorder to a TV that does not have a video input jack.
- Be sure to disconnect the power cord of each component before connecting.

Step 1: Unpacking

- Check that you have the following items:
- Audio/video cord
 - (phono plug $\times$ 3 $\leftrightarrow$ phono plug $\times$ 3) (1)
 - Antenna cable (1)
 - Remote commander (remote) (1)
 - Size AA (R6) batteries (2)

Step 2: Connecting the Antenna Cable

Select one of the following antenna hookups. Do not connect the power cord until you reach "Connecting the Power Cord" on page 19.

If you have	Hookup
Cable box or satellite receiver with a video/audio output	A (page 13)
Cable box with an antenna output only	B (page 14)
Cable without cable box, or antenna only (no cable TV)	C (page 14)

Note to CATV system installer (in USA)


This reminder is provided to call the CATV system installer's attention to Article 820-40 of the NEC that provides guidelines for proper grounding and, in particular, specifies that the cable ground shall be connected to the grounding system of the building, as close to the point of cable entry as practical.

Notes

- If your antenna is a flat cable (300-ohm twin lead cable), use an external antenna connector (not supplied) to connect the antenna to the recorder.
- If you have separate cables for VHF and UHF antennas, use a UHF/VHF band mixer (not supplied) to connect the antenna to the recorder.

A: Cable box or satellite receiver with a video/audio output


With this hookup, you can record any channel on the cable box or satellite receiver. Be sure that the satellite receiver or cable box is turned on. To watch cable or satellite programs, you need to match the channel on the recorder (L1) to the input jack connected to the cable box or satellite receiver (LINE 1 IN).



Hookups and Settings


B: Cable box with an antenna output only

With this hookup, you can record any channel on the satellite receiver or cable box. Be sure that the satellite receiver or cable box is turned on. To watch cable programs, you need to match the channel on the recorder (2ch, 3ch or 4ch) to the antenna output channel on the cable box (2ch, 3ch or 4ch).




C: Cable without cable box, or antenna only (no cable TV)

Use this hookup if you watch cable channels without a cable box. Also use this hookup if you are using a VHF/UHF antenna or separate VHF and UHF antennas. With this hookup, you can record any channel by selecting the channel on the recorder.



Step 3: Connecting to Your TV

Connect the supplied audio/video cord to the LINE OUT (AUDIO L/R/VIDEO) jacks of the recorder. To enjoy higher quality images, connect an S video cord (not supplied) instead of the yellow (video) plug. When using this connection, be sure to connect the audio cord to the LINE OUT (AUDIO L/R) jacks.



When playing "wide screen" images

Some recorded images may not fit your TV screen. To change the picture size, see page 95.

Notes


- Do not connect more than one type of video cord between the recorder and your TV at the same time.
- During DVD recording, you cannot watch VHS pictures by pressing VIDEO, as the S VIDEO OUT jack will output DVD video signals only.
- Do not connect your TV's audio output jacks to the LINE IN (AUDIO L/R) jacks at the same time. This will cause unwanted noise to come from your TV's speakers.

If your TV has component video input jacks

Connect the COMPONENT VIDEO OUT jacks using a component video cord (not supplied) or three video cords (not supplied) of the same kind and length. You will enjoy accurate color reproduction and high quality images.

If your TV accepts progressive 480p format signals, you must use this connection and then set "Progressive" of "Video" to "On" in the "Setup" display (page 96). The PROGRESSIVE indicator lights up when the recorder outputs progressive signals.

When using this connection, be sure to connect the audio cord to the LINE OUT (AUDIO L/R) jacks.



Hint

Video signal can also be output from the COMPONENT VIDEO OUT jack when playing a VHS tape.

Note


During DVD recording, you cannot watch VHS pictures by pressing VIDEO, as the COMPONENT VIDEO OUT jacks will output DVD video signals only.

→ continued 15

16

Step 4: Connecting to Your AV Amplifier (Receiver)

Select one of the following patterns ① or ②, according to the input jack on your AV amplifier (receiver). This will enable you to listen to DVD audio tracks through your AV amplifier (receiver).




Hookups and Settings


① Connecting to audio L/R jacks

This connection uses a stereo amplifier's (receiver's) two front speakers for sound. You can enjoy the surround function that creates virtual speakers from two stereo speakers. Select from "Surround1," "Surround2," or "Surround3" of the surround effects (page 33).


Surround 1



Surround 2




Surround 3



② Connecting to a digital audio input jack

Use this connection if your AV amplifier (receiver) has a Dolby[®]1 Digital or DTS[®]2 decoder and a digital input jack. You can enjoy the surround effect of Dolby Digital (5.1ch) or DTS (5.1ch).



*2 "DTS" and "DTS Digital Out" are trademarks of Digital Theater Systems, Inc.

Hints

- For correct speaker location, see the operating instructions supplied with the connected components.
- During VHS playback, the DIGITAL AUDIO OUT jacks can also output digital audio signals.

Notes

- During DVD recording, the DIGITAL AUDIO OUT jacks output DVD audio signals only. You cannot hear VHS sound by pressing VIDEO.
- After you have completed the connection, make the appropriate settings under "Audio Connection Setup" in Easy Setup (page 22). Otherwise, no sound or a loud noise will come from your speakers.
- With a coaxial or optical digital connection, you cannot use the virtual surround effects of this recorder.
- The recorder cannot play Linear PCM soundtracks of 2 channels or more.
- When outputting from the DIGITAL AUDIO OUT jacks, you cannot switch the bilingual sounds on a DVD-RW (VR mode) by pressing AUDIO.


*1 Manufactured under license from Dolby Laboratories. "Dolby," "Pro Logic," and the double-D symbol are trademarks of Dolby Laboratories.

→ continued 17

18


Step 5: Connecting the Power Cord

Plug the recorder and TV power cords into an AC outlet. After you connect the power cord, **you must wait for a short while before operating the recorder.** You can operate the recorder only after the front panel display lights up and the recorder enters standby mode. If you connect additional equipment to this recorder (page 26), be sure to connect the power cord only after all connections are complete.



Step 6: Preparing the Remote

You can control the recorder using the supplied remote. Insert two size AA (R6) batteries by matching the ⊕ and ⊖ ends on the batteries to the markings inside the battery compartment. When using the remote, point it at the remote sensor on the recorder.



Notes

- If the supplied remote interferes your other Sony DVD recorder or player, change the command mode number for this recorder (page 24).
- Use the batteries correctly to avoid possible leakage and corrosion. Do not touch the liquid with bare hands should leakage occur. Observe the following:
 - Do not use a new battery with an old battery, or batteries of different manufacturers.
 - Do not attempt to recharge the batteries.
 - If you do not intend to use the remote for an extended period of time, remove the batteries.
 - If battery leakage occurs, wipe out any liquid inside the battery compartment, and insert new batteries.
- Do not expose the remote sensor (marked with a sun icon on the front panel) to strong light, such as direct sunlight or lighting apparatus. The recorder may not respond to the remote.
- With normal use, the batteries should last about three to six months.
- Do not leave the remote in an extremely hot or humid place.
- Do not drop any foreign object into the remote casing, particularly when replacing the batteries.


Hookups and Settings

Controlling TVs with the remote

You can adjust the remote control's signal to control your TV. If you connect the recorder to an AV amplifier (receiver), you can also use the supplied remote to control the AV amplifier's (receiver's) volume.

Notes

- Depending on the connected unit, you may not be able to control your TV or AV amplifier (receiver) with some or all of the buttons below.
- If you enter a new code number, the code number previously entered will be erased.
- When you replace the batteries of the remote, the code number may be reset to the default setting. Set the appropriate code number again.



1 Slide the TV/DVD-VIDEO switch to TV.

2 Hold down I/⏻.

3 Enter your TV's manufacturer code (see below) using the number buttons.

4 Release I/⏻.

When the TV/DVD-VIDEO switch is set to TV, the remote performs the following:

Press	To
I/⏻	Turn your TV on or off

VOL +/-	Adjust the volume of your TV
CH +/-	Select the channel on your TV
TV/VIDEO	Switch your TV's input source
Number buttons and SET	Select the channel on a Sony TV
WIDE MODE	Switch to or from the wide mode of a Sony wide-screen TV

Code numbers of controllable TVs

If more than one code number is listed, try entering them one at a time until you find the one that works with your TV.

Manufacturer	Code number
Sony	01 (default)
Akai	04
AOC	04
Centurion	12
Coronado	03
Curtis-Mathes	12, 14
Daewoo	04, 22
Daytron	03, 12
Fisher	11
General Electric	04, 06, 10
Hitachi	02, 03, 04
J.C.Penney	04, 10, 12
JVC	09
KMC	03
LG/Gold Star	03, 04, 17
Magnavox	03, 04, 08, 12, 21
Marantz	04, 13
MGA/Mitsubishi	04, 12, 13, 17
NEC	04, 12
Panasonic	06, 19
Philco	02, 03, 04, 08
Philips	08, 21
Pioneer	06, 16

→continued 19 20

Manufacturer	Code number
Portland	03
Proscan	10
Quasar	06, 18
Radio Shack	05, 10, 14
RCA	04, 10
Sampo	12
Samsung	03, 04, 12, 20
Sanyo	11, 14
Scott	12
Sears	07, 10, 11
Sharp	03, 05, 18
Sylvania	08, 12
Teknika	03, 08, 14
Toshiba	07, 18
Wards	03, 04, 12
Yorx	12
Zenith	14, 15

Hint

If you want to control the TV's volume even when the TV/DVD-VIDEO switch is set to DVD-VIDEO, repeat the steps above and enter the code number 90 (default).

Code numbers of controllable AV amplifiers (receivers)

If more than one code number is listed, try entering them one at a time until you find the one that works with your AV amplifier (receiver).

Manufacturer	Code number
Sony	78, 79, 80, 91
Denon	84, 85, 86
Kenwood	92, 93
Onkyo	81, 82, 83
Pioneer	99
Sansui	87
Technics	97, 98
Yamaha	94, 95, 96

Hookups and Settings

Step 7: Easy Setup

Follow the steps below to make the minimum number of basic adjustments for using the recorder. If you do not complete Easy Setup, it will appear each time you turn on your recorder. Settings are made in the following order.

OSD Language Setup



Clock Setup



Tuner and Channel Setup




TV Type Setup



Audio Connection Setup



Finished!



1 Turn on the TV.

2 Press I/⏻.

The recorder turns on.


3 Switch the input selector on your TV so that the signal from the recorder appears on your TV screen.

"Initial setting necessary to operate the DVD recorder will be made. You can change them later using setup," appears.

- If this message does not appear, select "Easy Setup" in the "Setup" display to run Easy Setup (page 102).


4 Press ENTER.

The setup display for selecting the language used in the on-screen display appears.



5 Select a language, and press ENTER.

The setup display for clock setting appears.




6 Select "Auto," and press ENTER.

The recorder will automatically search for a channel that carries a time signal when you turn off the recorder after finishing Easy Setup.

- If broadcasters in your area are not sending time signals, select "Manual," and press ENTER. Press ⬆️ to set the month and press ➡️ to set the day, year, hour, minutes, and AM/PM in the same way. The day of the week is set automatically.

Controlling the volume of your AV amplifier (receiver) with the remote



1 Slide the TV/DVD-VIDEO switch to DVD-VIDEO.


2 Hold down I/⏻, and enter the manufacturer code (see the table below) for your AV amplifier (receiver) using the number buttons.

3 Release I/⏻.

The VOL +/- buttons control the AV amplifier's volume. If you want to control the TV's volume, slide the TV/DVD-VIDEO switch to TV.

21 22


7 Select whether or not you have a cable connection.



If you use an antenna only (no cable TV), select "Antenna."
For all other connections, select "Cable."


8 Press ENTER.

The Tuner Preset function automatically starts searching for all of the receivable channels and presets them.



To set the channels manually, see page 94.
After the Tuner Preset is finished, the setup display for selecting the picture size of the connected TV appears.


9 Select the setting that matches your TV type.



"4:3 Letter Box": For standard TVs.
Displays "wide screen" pictures with bands on the upper and lower sections of the screen.
"4:3 Pan Scan": For standard TVs.
Automatically displays "wide screen" pictures on the entire screen and cuts off the sections that do not fit.
"16:9": For wide-screen TVs or standard TVs with a wide screen mode.
For details, see "Video Settings (Video)" on page 95.

10 Press ENTER.

The setup display for selecting the type of Dolby Digital signal appears.




11 Select the type of Dolby Digital signal you want to send to your amplifier (receiver).

If your AV amplifier (receiver) has a Dolby Digital decoder, select "Dolby Digital."
Otherwise, select "D-PCM."

12 Press ENTER.

The setup display for selecting the type of DTS signal appears.




13 Select whether or not you want to send a DTS signal to your amplifier (receiver), and press ENTER.

If your AV amplifier (receiver) has a DTS decoder, select "On." Otherwise, select "Off."

14 Press ENTER when "Finish" appears.

Easy Setup is finished. All connections and setup operations are complete.



To return to the previous display

Press **RETURN**.

Hint

If you want to run Easy Setup again, select "Easy Setup" in the "Setup" display (page 102).


Note

To record TV programs using the timer, you must set the clock accurately.

If you have a Sony DVD player or more than one Sony DVD recorder

If the supplied remote interferes with your other Sony DVD recorder or player, set the command mode number for this recorder and the supplied remote to one that differs from the other Sony DVD recorder or player.


The default command mode setting for this recorder and the supplied remote is DVD 3.




1 Press SYSTEM MENU.

The System Menu appears.


2 Select "Setup," and press ENTER.



3 Select "Options," and press ENTER.



4 Select "Command Mode," and press ENTER.



5 Select the command mode ("DVD 1," "DVD 2," or "DVD 3"), and press ENTER.

6 Slide the COMMAND MODE switch on the remote so it matches the mode you selected above.

To return to the previous display

Press **RETURN**.

Note

If the command mode does not match, the recorder's command mode appears on the front panel display when you operate the remote. Set the remote's command mode to one that matches the recorder's.

→ continued 23

24

Connecting Another VCR or Similar Device


After disconnecting the recorder's power cord from an AC outlet, connect the other VCR or similar recording device to the LINE IN jacks of this recorder. See also the instruction manual supplied with the connected equipment.

To record on this recorder, see "Recording From Connected Equipment With a Timer (Synchro Rec)" on page 50 and page 78. Connect the equipment to the LINE 1 IN jacks of the recorder to record using the Synchro Rec function.

Connecting to the LINE 2 IN jacks on the front panel

Connect other VCR or similar device to the LINE 2 IN jacks of this recorder. If the equipment has an S video jack, you can use an S video cord (not supplied) instead of the yellow (video) plug of the audio/video cord.

You can connect a second DVD player and record DVDs.



→ : Signal flow

Notes


- You cannot dub a copy guard DVD VIDEO to this DVD recorder.
- Do not connect the yellow LINE IN (VIDEO) jack when using an S video cord.

25

26

Connecting to the LINE 1 IN jacks


You can connect a second VCR or similar device.




Hint
When the connected equipment outputs only monaural sound, connect an audio cord to the LINE 2 IN AUDIO L (MONO) jack.

Notes

- Do not connect the output jack of this recorder to another equipment's input jack with the other equipment's output jack connected to the input jack of this recorder. Noise (feedback) may result.
- Pictures containing copy protection signals that prohibit any copying cannot be recorded.
- If you pass the recorder signals via the VCR, you may not receive a clear image on your TV screen.



Be sure to connect your VCR to the VCR-DVD recorder and your TV in the order shown below. To watch video tapes, watch the tapes through a second line input on your TV.



- If the recorder's power cord is disconnected, you will not be able to view the signals from the connected VCR.
- Do not connect more than one type of video cord between the recorder and your TV at the same time.

Hookups and Settings

Quick Guide to Disc Types

Recordable and Playable Discs

Disc Type	Disc Logo	Icon used in this manual	Formatting (new discs)	Compatibility with other DVD players (finalizing)
DVD+RW			Automatically formatted	Playable on DVD+RW compatible players (automatically finalized)
DVD-RW			Format in VR mode*2 (page 66)	Playable only on VR mode compatible players (finalization unnecessary) (page 86)
			Format in Video mode*2 (page 66)	Playable on most DVD players (finalization necessary) (page 86)
DVD+R			Automatically formatted	Playable on DVD+R compatible players (finalization necessary) (page 86)
DVD+R DL			Automatically formatted	Playable on most DVD players (finalization necessary) (page 86)
DVD-R			Automatically formatted	Playable on most DVD players (finalization necessary) (page 86)

Usable disc versions (as of May 2005)

- 4×-speed or slower DVD+RWs
- 2×-speed or slower DVD-RWs (Ver.1.1, Ver.1.1 with CPRM^{*1})
- 4×-speed or slower DVD-RWs (Ver.1.2, Ver.1.2 with CPRM)
- 8×-speed or slower DVD+Rs
- 8×-speed or slower DVD-Rs (Ver.2.0)
- 2.4×-speed DVD+R DL (Double Layer) discs

"DVD+RW," "DVD-RW," "DVD+R," "DVD+R DL," and "DVD-R" logos are trademarks.

12 cm/8 cm Discs

Operation	DVD+RW		DVD-RW				DVD+R		DVD-R	
	12 cm	8 cm	12 cm	8 cm	12 cm	8 cm	12 cm	8 cm	12 cm	8 cm
Playback	Yes	Yes	Yes	Yes	Yes	Yes	Yes	—	Yes	Yes
Recording	Yes	No	Yes	No	Yes	No	Yes	—	Yes	No

Playable Discs

Disc Type	Disc Logo	Icon Used in This Manual	Characteristics
DVD VIDEO			Discs such as movies that can be purchased or rented
VIDEO CD			VIDEO CDs or CD-Rs/CD-RWs in VIDEO CD format (with PBC function)
CD			Music CDs or CD-Rs/CD-RWs in music CD format that can be purchased
DATA CD			CD-Rs/CD-RWs created on a PC or similar device in music format, or MP3 or JPEG format that conforms to ISO9660* Level 1/Level 2
DATA DVD	—		DVD+RWs/DVD-RWs/DVD+Rs/DVD-Rs in MP3 or JPEG format conforming to UDF
8 cm DVD+RW/ DVD-RW/DVD-R	—	—	8 cm DVD+RWs, DVD-RWs, and DVD-Rs recorded with a DVD video camera (Still images recorded with a DVD video camera cannot be played.)

*DVD VIDEO" and "CD" logos are trademarks.
* A logical format of files and folders on DATA-CDs, defined by ISO (International Standard Organization).

Discs that cannot be played

- CD-Rs/CD-RWs, other than those recorded in music CD format, MP3 or JPEG format, or Video CD format
- Data part of CD-Extras
- DVD-ROMs
- CD-ROMs
- DVD Audio discs
- DVD-R DL (Dual Layer) discs
- DVD-Rs recorded in VR mode (Video Recording format)
- DVD-Rs with CPRM
- DVD-RAMs
- HD layer on Super Audio CDs
- DVD VIDEOs with a different region code (see page 31)
- A disc recorded in a color system other than NTSC, such as PAL or SECAM

Note on playback operations of DVD VIDEOs/VIDEO CDs

Some playback operations of DVD VIDEOs/VIDEO CDs may be intentionally set by software producers. Since this recorder plays DVD VIDEOs/VIDEO CDs according to the disc contents the software producers designed, some playback features may not be available. Also, see the instructions supplied with the DVD VIDEOs/VIDEO CDs.


Note on DualDiscs

A DualDisc is a two sided disc product which mates DVD recorded material on one side with digital audio material on the other side. However, since the audio material side does not conform to the Compact Disc (CD) standard, playback on this product is not guaranteed.

Region code (DVD VIDEO only)

Your recorder has a region code printed on the rear of the unit and will only play DVD VIDEOs (playback only) labeled with identical region codes. This system is used to protect copyrights. DVD VIDEOs labeled  will also play on this recorder.

If you try to play any other DVD VIDEO, a message will appear on the TV screen to indicate that the disc is not playable. Depending on the DVD VIDEO, no region code indication may be labeled even though playing the DVD VIDEO is prohibited by area restrictions.



Music discs encoded with copyright protection technologies


This product is designed to playback discs that conform to the Compact Disc (CD) standard. Recently, various music discs encoded with copyright protection technologies are being marketed by some record companies. Please be aware that among those discs, there are some that do not conform to the CD standard and may not be playable by this product.

Notes

- Some DVD+RWs/DVD+Rs, DVD-RWs/DVD-Rs, or CD-RWs/CD-Rs cannot be played on this recorder due to the recording quality or physical condition of the disc, or the characteristics of the recording device and authoring software. The disc will not play if it has not been correctly finalized. For more information, see the operating instructions for the recording device.
- You cannot mix VR mode and Video mode on the same DVD-RW. To change the disc's format, reformat the disc (page 66). Note that the disc's contents will be erased after reformatting.
- You cannot shorten the time required for recording even with high-speed discs. Also, you cannot record on the disc if the disc is not 1x speed compatible.
- It is recommended that you use discs with "For Video" printed on their packaging.
- You cannot add new recordings to DVD-RWs (Video mode) or DVD-Rs that contain recordings made on other DVD equipment.
- You may not be able to further record on a DVD+RW recorded on other equipment. Note that recording on such discs may cause the recorder to rewrite the DVD menu.
- If the disc contains PC data unrecognizable by this recorder, the data may be erased.

DVD Playback

Playing



- 1 Press DVD to operate the DVD recorder.
- 2 Press , and place a disc on the disc tray.



- 3 Press  to close the disc tray.
Wait until "LOAD" disappears from the front panel display.
- 4 Press  PLAY.
Playback starts.

To stop playback

Press  STOP.

Hints

- You can play DATA CDs or DATA DVDs with MP3 tracks or JPEG files (page 40, 41).
- If you insert a DVD VIDEO, VIDEO CD, or CD, playback starts automatically depending on the disc.
- When playing a DVD+RW, DVD-RW, DVD+R, and DVD-R, you can select the title from the Title List menu (page 37).

Notes


- To play a disc recorded with other equipment on this recorder, finalize the disc on the recording equipment first.
- For simultaneous VHS and DVD operation, see page 9.

Using the DVD's Menu



When you play a DVD VIDEO, or a finalized DVD+RW, DVD-RW (Video mode), DVD+R, or DVD-R, you can display the disc's menu by pressing TOP MENU or MENU.

Playback Options



Button	Operation	Disc
 OPEN/CLOSE	Stops playing and opens the disc tray.	All discs
AUDIO	Selects one of the audio tracks recorded on the disc when pressed repeatedly.  : Selects the audio source.  : Selects stereo or monaural audio tracks.	 
SUBTITLE	Selects a subtitle language when pressed repeatedly.	
ANGLE	Selects an angle when pressed repeatedly. If various angles (multi-angles) for a scene are recorded on the disc, "  " appears in the front panel display.	
ZOOM	Zooms into a scene during playback or still mode when pressed repeatedly. Magnification changes as follows: normal → ×2 → ×4 → normal The zoom function may not work depending on the DVD. To zoom in a JPEG image, see page 42.	    

Button	Operation	Disc
SUR (surround)	Surround lets you enjoy surround sound effects by using sound imaging to create virtual rear speakers from a stereo TV or two front speakers (page 18). Selects one of the effects when pressed repeatedly. "Off": No surround effect. "Surround1": Creates one set of virtual surround speakers. "Surround2": Creates two sets of virtual surround speakers. "Surround3": Creates three sets of virtual surround speakers. This feature is effective when you use two separate front speakers.	All discs
 REPLAY/  ADVANCE	• Replays or briefly fast forwards a scene when pressed during playback. • Goes to the previous or next frame when pressed during pause mode.	    
 PREV/  NEXT	• Goes to the beginning of the current or next title/chapter/scene/track and starts playback when pressed during playback. • Goes to the beginning of the previous title/chapter/scene/track when  PREV is pressed within three seconds after starting a title/chapter/scene/track.	All discs
 (fast reverse/fast forward)	Fast reverses or fast forwards the disc when pressed during playback. Search speed changes with each press: fast reverse FR1 ← → FF1^{*1} FR2^{*2} ← → FF2^{*2} FR3^{*3} ← → FF3^{*3} fast forward 	All discs ^{*1} FF1 with sound (Scan Audio) is available for DVDs with Dolby Digital soundtracks. ^{*2} FR2 and FF2 are not available for MP3. ^{*3} FR3 and FF3 are only available for DVDs and VIDEO CDs.
 (slow)	Plays in slow motion when pressed in pause mode. Playback speed changes with each press: reverse slow motion ←13 ← → 31 ←12 ← → 21 ←11 ← → 11 forward slow motion 	      * Playback direction only
 PAUSE	Pauses playback. If you pause playback for more than five minutes, playback starts automatically.	All discs

Button	Operation	Disc
REPEAT	Displays the items to be repeated when pressed. Select an item using ↑/↓, and press ENTER. To cancel Repeat Play, select "Off" and press ENTER. Press ↶ RETURN to turn off the display. When playing a DVD "Chapter": Repeats the current chapter. "Title": Repeats the current title on a disc. "A-B" (Repeat A-B Play): Repeats a specific portion (page 36). When playing a VIDEO CD (with PBC function off) "Track": Repeats the current track. "Disc": Repeats all of the tracks. "A-B" (Repeat A-B Play): Repeats a specific portion (page 36). Selects the item to be repeated when pressed repeatedly. To cancel Repeat Play, select "Off." When playing a CD "Track": Repeats the current track. "Disc": Repeats all of the tracks. When playing a DATA CD/DATA DVD (MP3 audio) "File": Repeats the current track. "Folder": Repeats the current album.	+RW -RWVR -RWdata +R -R DVD VCD * With PBC function off CD DATA CD DATA DVD

To resume normal playback, press **▷** PLAY.

Hints

- You can change playback options, such as subtitle, audio track, angle, etc., using the TOOLS menu (page 11).
- During playback or pause mode, the recorder's **◀/▶** buttons and the remote's **◀/▶** buttons work the same way (page 34). Hold the buttons down during playback to fast forward or fast reverse. In pause mode, you can play in slow motion. Three speeds are available, depending on the duration of the press.
- See "DVD Audio/Subtitle Language" on page 118 for the meaning of the language abbreviation.

Notes

- You cannot use the repeat play function with VIDEO CDs while the PBC function is on (page 36).
- When the playback signal does not contain a signal for the surround speakers, the surround effects will be difficult to hear.
- When you select one of the surround modes, turn off the surround settings of the connected TV or amplifier (receiver).
- If you pause playback of a CD, or DATA CD/DATA DVD containing MP3 audio tracks, playback will not start until you press **▷** PLAY or **⏏** PAUSE.
- Make sure that your listening position is between and at an equal distance from your speakers, and that the speakers are located in similar surroundings.
- Sound will be interrupted during Scan Audio (page 36).

Notes on playing DTS soundtracks on a CD

When playing DTS-encoded CDs, excessive noise will be heard from the analog stereo jacks. To avoid possible damage to the audio system, the consumer should take proper precautions when the analog stereo jacks of the recorder are connected to an amplification system. To enjoy DTS Digital Surround™ playback, an external 5.1-channel decoder system must be connected to the digital jack of the recorder.

Notes on playing DVDs with a DTS soundtrack

DTS audio signals are output only through the DIGITAL AUDIO OUT (COAXIAL or OPTICAL) jack. When you play a DVD with DTS soundtracks, set "Digital Out" – "DTS" to "On" of "Audio" in the "Setup" display (page 97).

Playing quickly with sound (Scan Audio) (DVDs with Dolby Digital soundtracks only)

You can play quickly with dialog or sound during FF1 fast-forward of a DVD with Dolby Digital soundtracks. Simply press **▶▶** during playback.

Hint

To turn off the Scan Audio function, set "Scan Audio" of "Audio" to "Off" in the "Setup" display (page 98).

Note

Sound will be interrupted during Scan Audio.

Playing VIDEO CDs with PBC functions

VCD

PBC (Playback Control) allows you to play VIDEO CDs interactively using a menu on your TV screen. When you start playing a VIDEO CD with PBC functions, a menu appears. Select an item using the number buttons and press ENTER. Then follow the instructions in the menu (press **▷** PLAY when "Press SELECT" appears). Operations differ depending on the disc. See the instructions supplied with the disc.

To cancel PBC Playback

Press MENU to display "Menu: Off." To use the PBC functions, press MENU again to display "Menu:On."

Resuming playback from the point where you stopped the disc (Resume Play)

Press **▷** PLAY again after stopping a disc to resume playback from the same point. To start from the beginning, press **■** STOP twice, and press **▷** PLAY.

The point where you stopped playing is cleared when:

- you open the disc tray.
- you play another title.
- you switch the Title List menu to Original or Playlist (DVD-RW (VR mode) only).
- you edit the title after stopping playback.

→continued 35 36

Locking the recorder (Child Lock)

You can lock all of the buttons on the recorder so that the settings are not canceled by mistake.



With the recorder turned on, hold down **I/O** on the recorder. The recorder turns off and "CHILD LOCK" appears in the front panel display. The **I/O** indicator remains lit if there is a timer setting. The recorder will not work except for timer recordings.

To unlock the recorder, hold down **I/O** on the recorder until "CHILD LOCK" disappears from the front panel display. The recorder is unlocked and turns on.

To stop timer recording while the recorder is locked, press **■** twice. The recording stops and the recorder is unlocked.


Note

The recorder will be unlocked when:
 – you stop timer recording by pressing **■**.
 – you insert a tape.

Playing a Title From the Title List


+RW -RWVR -RWdata +R -R

The Title List menu displays the program titles on the disc.



- Press DVD to operate the DVD recorder.
- Place a disc on the disc tray.
- Press TITLE LIST.

Example: DVD-RW (VR mode)



- Title type (DVD-RWs (VR mode) only): Displays the title type, "Title List (Original)" or "Playlist."
- Movie thumbnail image
- Title information: Displays the title number, title name, recording date, and recording mode. "Ⓢ" indicates a protected title, while "Ⓢ" indicates unprotected.
- Clock

→continued 37 38

– you make a recording.

Repeating a specific portion (Repeat A-B Play)

+RW -RWVR -RWdata +R -R DVD
 VCD

- During playback, press REPEAT.
- Select "A" using **↑/↓**.
- Press ENTER at the starting point (point A) of the portion to be played repeatedly. "A-" appears.
- Continue playing or press **◀/▶** to locate the ending point (point B), and press ENTER. Repeat A-B Play starts.

To return to normal playback, press REPEAT to select "Off," and press ENTER. Press **↶** RETURN to turn off the display.

* Only with PBC function off.

Playing restricted DVDs (Parental Control)

DVD

If you play a restricted DVD, a message appears asking whether you want to override the restriction.


- Select "OK" and press ENTER. The display for entering your password appears.
- Enter your four digit password using the number buttons. The recorder starts playback.

To register or change the password, see "Parental (DVD VIDEOS only)" on page 101.

Searching for a Title/Chapter/Track, etc.

+RW -RWVR -RWdata +R -R DVD
 VCD

You can search a DVD by title or chapter, and VIDEO CD by track or scene. As titles and tracks are assigned individual numbers on the disc, select the title or track by entering its number. You can also search for a scene using the time code.




- Press TOOLS during playback. The TOOLS menu appears.
- Select a search method.
 "Title" (for DVDs)
 "Chapter" (for DVDs)
 "Track" (for VIDEO CDs with PBC function off)
 "Time" (for DVDs/VIDEO CDs): Searches for a starting point using the time code.
- Press **↑/↓/◀/▶** to select the number of the title, chapter, track, etc., you want, or press the number buttons to enter the time code.
 For example: "Time"
 To find a scene at 2 hours, 10 minutes, and 20 seconds, enter "21020."
 If you make a mistake, wait a moment until the display returns to the elapsed playing time display, then select another number.
- Press ENTER.
 The recorder starts playback from the selected point.
 To turn off the display, press TOOLS.

Note

Depending on the disc, you may not be able to use the TOOLS menu to search for a title/chapter/track, or enter the time code for a playback point.

Bookmarking a favorite scene (Bookmark)

You can have the recorder store specific portions of a disc in memory and play them immediately whenever you want (Bookmark). Up to ten bookmarks per disc can be set.




During playback, press **MARKER** at a favorite scene.

The bookmark is set.

To play from bookmarks

- 1 During playback, press **SEARCH**.



- 2 Press **ENTER** to select a bookmark, and press **ENTER**.
Playback starts from the selected bookmark.

To erase bookmarks

- 1 During playback, press **SEARCH**.

- 2 Press **ENTER** to select the bookmark to be erased.

- 3 Press **CLEAR**.


Note

When you eject the disc, the bookmark information is cleared.

Playing MP3 Audio Tracks

DATA CD DATA DVD


You can play MP3 audio tracks on DATA CDs (CD-Rs/CD-RWs) or DATA DVDs (DVD+RWs/DVD-RWs/DVD+Rs/DVD-Rs).



- 1 Press **DVD** to operate the DVD recorder.

- 2 Place a **DATA CD/DATA DVD** on the disc tray.


When you insert a DATA CD/DATA DVD containing MP3 audio tracks and JPEG image files, the display for selecting a media type appears.



If you insert a DATA CD/DATA DVD containing only MP3 audio files, the "Music" display appears. Go to step 4.

- 3 Select "Music," and press **ENTER**.
The "Music" display appears.

- 4 Select an album, and press **ENTER**.



- 5 Select a track, and press **ENTER**.

Playback starts from the selected track. When a track or album is being played, the title is shown in a box.

To stop playback

Press **STOP**.

To pause playback

Press **PAUSE**.

To restart playback, press **PLAY** or **PAUSE**.

To play repeatedly

Press **REPEAT** repeatedly during playback.

"Off": Does not play repeatedly.

"File": Repeats the current track.

"Folder": Repeats the current album.

To return to the previous display

Press **RETURN**.

To switch between MP3 audio tracks and JPEG image files

Press **STOP**, and press **TOP MENU**.

About MP3 audio tracks

You can play back DATA CDs (CD-Rs/CD-RWs) or DATA DVDs (DVD+RWs/DVD-RWs/DVD+Rs/DVD-Rs) recorded in MP3 (MPEG-1 Audio Layer III) format. However, the discs must be recorded according to ISO9660 Level 1/Level 2 or Joliet format and DATA DVDs of Universal Disk Format (UDF) for the recorder to recognize the tracks (or files).

39

40

See the instructions supplied with the CD-R/CD-RW/DVD-R/DVD-RW drives and the recording software (not supplied) for details on the recording format.

Hints

- Since a disc with many trees takes longer to start playback, it is recommended that you create albums with no more than two trees.
- When playback of all the MP3 audio tracks within the album finishes, the recorder stops.


Notes

- The recorder may not be able to play some DATA CDs or DATA DVDs created in the Packet Write format.
- The recorder will play any data with the extension ".MP3," even if they are not in MP3 format. Playing such data may generate a loud noise which could damage your speaker system.
- Only one session of a multi-session DATA DVD can be played back.
- The recorder does not conform to audio tracks in MP3PRO format.
- The recorder can recognize up to 499 MP3 audio tracks within a single album. The recorder may not recognize some discs depending on the recording device used for recording or the disc condition.
- The recorder can play MP3 audio tracks recorded in the following sampling frequencies: 32 kHz, 44.1 kHz, 48 kHz.
- ID3 tags cannot be displayed.
- Only alphabet and numbers can be used for album or track names. Anything else is displayed as an asterisk.

Playing JPEG Image Files

DATA CD DATA DVD


You can play JPEG image files on DATA CDs (CD-Rs/CD-RWs) or DATA DVDs (DVD+RWs/DVD-RWs/DVD+Rs/DVD-Rs).



- 1 Press **DVD** to operate the DVD recorder.

- 2 Place a **DATA CD/DATA DVD** on the disc tray.

When you insert a DATA CD/DATA DVD containing MP3 audio tracks and JPEG image files, the display for selecting a media type appears.




If you insert a DATA CD/DATA DVD containing only JPEG files, the "Photo" display appears. Go to step 4.

- 3 Select "Photo," and press **ENTER**.

The "Photo" display appears.

- 4 Select a folder, and press **ENTER**.

Directory information



To display the previous or next page, press **LEFT** or **RIGHT**.

- 5 Select an image file, and press **ENTER**.

The selected image is displayed over the entire screen.

To display the previous or next image, press **LEFT** or **RIGHT**.

The following menu icons appear in the upper part of the screen.

: Returns to the "Photo" display.

: Starts the slide show (page 42).

: Rotates the image (page 42).

: Zooms the image (page 42).

Press **TOOLS** to turn on/off the menu icons.

To play the slide show

- 1 Press **ENTER** to select , and press **ENTER**.

The "Slide Show Speed" menu appears.

: Slow

: Normal

: Fast

- 2 Press **ENTER** to select the desired play speed, and press **ENTER**.
Slide show starts from the selected image. To stop playing, press **STOP**.

To rotate the selected image

Press **ENTER** to select , and press **ENTER**. Each time you press **ENTER**, the image turns clockwise by 90°.

To zoom in an image

Press **ENTER** to select , and press **ENTER**. Each time you press **ENTER**, the magnification changes as follows:

2x → 4x → 2x → normal

To return to the previous display

Press **RETURN**.

To switch between MP3 audio tracks and JPEG image files

Press **STOP**, and press **TOP MENU**.

Hint

You can also start the slide show by pressing **PLAY** in step 5 above.

Notes

- You cannot use **ENTER** to move the image within the screen while zooming.
- Slide show can play in only one direction.
- You cannot rotate or zoom during slide show.
- If you select in the rotated image display, the images in the "Photo" display will not be rotated.

About JPEG image files

You can play back DATA CDs (CD-Rs/CD-RWs) or DATA DVDs (DVD+RWs/DVD-RWs/DVD+Rs/DVD-Rs) recorded in JPEG format. However, the discs must be recorded according to ISO9660 Level 1/Level 2 or Joliet format and DATA DVDs of Universal Disk Format (UDF) for the recorder to recognize the tracks (or files). See the instructions supplied with the CD-R/CD-RW/DVD-R/DVD-RW drives and the recording software (not supplied) for details on the recording format.

Hint

If you add numbers (01, 02, 03, etc.) to the front of the file names, the files will be played in that order.

Notes

- The recorder can only play the files with the extension ".JPG" or ".JPEG."
- Some DATA CDs or DATA DVDs cannot be played on this recorder depending on file format.
- If you add the extension ".JPG" or ".JPEG" to data not in JPEG format, a message appears indicating that the format is not supported.
- Only one session of a multi-session DATA DVD can be played back.
- Depending on the disc or the size of image files, playback may take some time to start.
- The recorder can recognize up to 999 JPEG image files within a single folder. The recorder may not recognize some discs depending on the recording device used for recording or the disc condition.

→ continued 41


42

- Progressive and lossless compression JPEG image files are not supported.
- The image size that the recorder can display is limited to width 32 - 7680 pixels by height 32 - 8192 pixels.

Displaying the Playing Time and Play Information




You can check disc information, such as playing time, recording mode, and remaining disc space.



Press DISPLAY.

The information display appears. Each time you press the button, the display changes as follows:

- Disc and tape information/date and time
- Disc information only
- No display



◆ DVD

- 1 Playing status
- 2 Playing time
- 3 Recording mode

DVD Playback

- 4 Remaining disc space (in stop mode)
Remaining time of the current title (during playback)
- 5 Channel or input source*
- 6 Date and time

* Title type (original or Playlist) for DVD-RWs (VR mode).


Viewing information on the front panel display

You can view the information on the front panel display.

Press TIME/TEXT repeatedly.

The displays differ depending on the disc type or playing status.

Example: When playing a DVD



Example: When a DVD is stopped

- Clock
- Current title and chapter number
- Remaining disc space
- Channel or input source

Example: When playing a CD

- Playing time of the current track
- Current track number
- Clock

→continued 43 44

DVD Recording

Before Recording

Before you start recording...

- This recorder can record on various discs types. Select the disc type according to your needs (page 28).
- Check that the disc has enough available space for the recording (page 43). For DVD+RWs or DVD-RWs, you can free up disc space by erasing titles (page 56).

Hint

To play a disc recorded with this recorder on other equipment, finalize the disc (page 86).

Notes

- Timer recordings will start with or without the recorder turned on. The recorder automatically turns off after a recording has finished.
- This recorder records at ×1 speed.
- This recorder shares a single tuner for both the DVD recorder and the VCR. You cannot record different programs to a DVD and a VHS tape at the same time.

Recording mode

Like the SP or EP recording mode of VCRs, this recorder has eight different recording modes. Select a recording mode according to the time and picture quality you need. For example, if picture quality is your top priority, select the High Quality mode (HQ). If recording time is your priority, Super Extended Play mode (SEP) can be a possible choice. Note that the recording time in the following table is an approximate guide.

Press REC MODE repeatedly to switch the recording modes.

I want to record with the best possible picture quality, so I'll select HQ.



Recording mode	Recording time (minute)
HQ (High quality)	60
HSP ↑	90
SP (Standard mode)	120
LSP ↓	150
LP ↓	180
EP ↓	240
SLP ↓	360
SEP (Long duration)	480

Note

- Situations below may cause slight inaccuracies with the recording time.
 - Recording a program with poor reception, or a program or video source of low picture quality
 - Recording on a disc that has already been edited
 - Recording only a still picture or just sound

Recording a stereo/SAP program

The recorder can receive and record stereo/SAP programs.

Stereo programs

When a stereo program is received, the "STEREO" indicator lights up in the front panel display. If there is noise in the stereo program, press AUDIO repeatedly until the "MONO" indicator disappears from the TV screen. The sound will be recorded in monaural but with less noise.

SAP (Second Audio Program)

When a SAP is received, the "SAP" indicator lights up in the front panel display. To record only SAP sound, set "Tuner Audio" of "Audio" to "SAP" in the "Setup" display (page 97).

DVD Recording


Unrecordable pictures

Pictures with copy protection cannot be recorded on this recorder. Recording stops when a copy guard signal is detected.

Copy control signals	Recordable discs
Copy-Free	+RW +RWVR +RWvideo +R -R
Copy-Once	-RWVR Ver.1.1 with CPRM* Ver.1.2 with CPRM*
Copy-Never	None

* The recorded disc can be played only on CPRM compatible equipment (page 29).

DVD Recording Without the Timer



- 1 Press DVD to operate the DVD recorder.
- 2 Press OPEN/CLOSE, and place a recordable disc on the disc tray.



Recording side facing down

- 3 Press OPEN/CLOSE to close the disc tray.
Wait until "LOAD" disappears from the front panel display.
Unused DVD-RWs are formatted in VR mode automatically. To format in Video mode, see page 100.
- 4 Press CH +/- or INPUT SELECT repeatedly to select the channel or input source you want to record.

→continued 45 46

5 Press REC MODE repeatedly to select the recording mode.

The display changes on the TV screen as follows:

HQ → HSP → SP → LSP
SEP ← SLP ← EP ← LP

For details about the recording mode, see page 45.

6 Press ● REC.

Recording starts.

Recording continues until you stop the recording or the disc is full.

To stop recording

Press ■ STOP.

Note that it may take a few seconds for the recorder to stop recording.

To pause recording

Press ■ PAUSE.

To restart recording, press ■ PAUSE again.

To watch another TV program while recording

1 Slide the TV/DVD-VIDEO switch to TV.

2 Press TV/VIDEO to set the TV to the TV input.

3 Select another channel on the TV.

To watch a VHS tape while recording

Press VIDEO to operate the VCR, insert a tape, then press ▷ PLAY.

Hints

- To play a disc recorded with this recorder on other equipment, finalize the disc (page 86).
- You can use the number buttons for channel selection. Enter the channel number, and press SET.
- You can select a video source from the LINE 1 IN or LINE 2 IN jacks using the INPUT SELECT button.
- You can turn off the TV during recording. If you are using a cable box or a satellite receiver, make sure to leave it on.

Notes

- Recording may not start immediately after ● REC is pressed.
- You cannot change the recording mode during recording or recording pause.
- If there is a power failure, the program you are recording may be erased.

- You cannot change the channel or input source during recording.

Recording using the Quick Timer (One-touch Timer Recording)

You can set the recorder to record in 30-minute increments.

1 Press DVD to operate the DVD recorder.

2 Press ● REC repeatedly to set the duration.

Each press increases the time by 30 minutes, up to eight hours (12 hours for DVD+R DL (Double Layer) discs).

0:30 → 1:00 → 7:30 → 8:00 → (normal recording)

“⊙” and “OTR” light up, and the remaining recording time appears in the front panel display.

When the counter reaches “0:00,” the recorder stops recording and turns off.

To cancel the Quick Timer

Press ● REC repeatedly until the counter appears in the front panel display. The recorder returns to normal recording mode.

To stop recording.

Press ■ STOP twice.

Note that it may take a few seconds for the recorder to stop recording.

Checking the disc status while recording


You can check the recording information such as recording time or disc type.

Press DISPLAY during recording.

The information display appears.

Press the button repeatedly to change the display (page 43).

DVD Recording



- Disc type
- Recording status
- Recording time
- Recording mode
- Remaining disc space
- Channel or input source

Hint

You can view the information also in the front panel display. Press TIME/TEXT repeatedly to change the display. Note that TIME/TEXT does not work during One-touch Timer Recording.

Creating chapters in a title

The recorder will automatically divide a recording (a title) into chapters by inserting chapter marks at 5 or 15-minute intervals during recording. Select the interval, “5 Min” (default) or “15 Min” in “DVD Auto Chapter” of “Features” in the “Setup” display (page 99).

If you do not want to divide titles, select “Off.”

Hint

You can create chapters manually when playing DVD+RWs or DVD-RWs (VR mode) (page 59).

DVD Timer Recording

*RW *RWVR *RWvideo *R *R


You can set the timer for a total of 12 programs together with DVD and VCR timer recording, up to one month in advance.

Note that the maximum continuous recording time for a single title is 12 hours. Contents beyond this time will not be recorded.

Follow the steps below to set each timer recording item.

Note

Do not operate your cable box or satellite receiver just before or during a timer recording. This may prevent the accurate recording of a program.



- Press DVD to operate the DVD recorder.
- Press ▲ OPEN/CLOSE, and place a recordable disc on the disc tray.




3 Press ▲ OPEN/CLOSE to close the disc tray.

Wait until “LOAD” disappears from the front panel display.

Unused DVD-RWs are formatted in VR mode automatically. To format in Video mode, see page 100.

4 Press TIMER.



5 Select an item using ←/→ and adjust using ↑/↓.

1 “RecTo”: Select “DVD.”

2 “Date”: Sets the date using ↑.

To record the same program every day or the same day every week, press ↓.

The item changes as follows:

Today ↔ Sun-Sat (Sunday to Saturday)

↔ Mon-Sat (Monday to Saturday) ↔

Mon-Fri (Monday to Friday) ↔ Sun

(every Sunday) ↔ Mon (every Monday)

↔ ... ↔ Sat (every Saturday) ↔

1 month later ↔ ... ↔ Today

3 “Start”: Sets the start time.

4 “Stop”: Sets the stop time.

5 “CH”: Selects the channel or input source.

6 “Mode”: Selects the recording mode (page 45).

To use the Rec Mode Adjust function (page 49), select “AUTO.”

If you make a mistake, select the item and change the setting.

6 Press ENTER.

The Timer List menu (page 52) appears.

The ⊙ indicator lights up in the front panel display, and the recorder is ready to start recording.

If the ⊙ indicator flashes in the front panel display, check that a recordable disc is inserted and that there is enough disc space for the recording.

There is no need to turn off the recorder before the timer recording starts.

If timer settings overlap, a message appears. To change or cancel a timer recording, select “Edit” from the Timer List (page 52).

7 Press SYSTEM MENU to turn off the menu.


To stop recording

Press ■ STOP twice.

Note that it may take a few seconds for the recorder to stop recording.

If timer settings overlap

The program that starts first has priority and the second program starts recording only after the first program has finished. If the programs start at the same time, the program listed first in the menu has priority. If the end time of one setting and the start time of another timer setting is the same, the beginning of the program that starts later will be cut.



To change or cancel timer recording

See “Changing or Canceling DVD Timer Settings (Timer List)” on page 52.

To use the Rec Mode Adjust function

If the remaining disc space is not enough for the current recording, the recorder automatically

DVD Recording

adjusts the recording mode. Select “AUTO” for “Mode” when setting the timer.

Hints

- You can play the recorded program by selecting the program title in the Title List menu.
- When the start time and the channel or input source to be recorded are the same but the “RecTo” setting differs, the program is recorded to both the DVD disc and the VHS tape.
- You can also turn on the timer programming menu from the System Menu. Press SYSTEM MENU to select “Timer,” and select “Timer-Standard.”

Notes


- To record a cable or satellite program, turn on the cable box or satellite receiver and select the program you want to record. Leave the cable box or satellite receiver turned on until the recorder finishes recording.
- Even when correctly set, the program may not be recorded if another recording is underway, or other prioritized timer setting overlaps.
- Before the timer recording starts, “TIMER REC” flashes in the front panel display.
- The recorder automatically turns off when a timer recording finishes, even if the recording started with the recorder turned on.
- The recorder does not record programs with Copy-Never signals. Such recordings stop after a few seconds.

Recording From Connected Equipment With a Timer (Synchro Rec)

*RW *RWVR *RWvideo *R *R

You can set the recorder to automatically record programs from connected equipment that has a timer function (such as a satellite tuner). Connect the equipment to the LINE 1 IN jacks on the rear of the recorder (page 27).

When the connected equipment turns on, the recorder starts recording a program from the LINE 1 IN jacks.



- Press DVD to operate the DVD recorder.
- Insert a recordable disc.
- Select the line input audio. Set “Line Audio Input” of “Audio” to “Stereo” or “Main/Sub” in the “Setup” display (page 99).

→ continued 47 48

→ continued 49 50

4 Press REC MODE repeatedly to select the recording mode.

The display changes on the TV screen as follows:

HQ → HSP → SP → LSP
SEP ← SLP ← EP ← LP

For details about the recording mode, see page 45.

5 Press SYSTEM MENU while the recorder is in stop mode.

6 Select "Setup," and press ENTER.

7 Select "Features," and press ENTER.

The "Features" setup appears.

8 Select "Synchro Recording," and press ENTER.

9 Select "to DVD," and press ENTER.

10 Press SYSTEM MENU to turn off the menu.

11 Set the timer on the connected equipment to the time you want to record, and turn it off.


12 Press SYNCHRO REC.

The SYNCHRO REC indicator lights up on the front panel and the recorder stands by for Synchro-Rec.

The recorder starts recording when a signal is received from the connected equipment. When the connected equipment turns off, the recording stops and the recorder turns off.

If the timer settings of a Synchro-Recording and another timer recording overlap

Regardless of whether or not the program is a Synchro-Rec program, the program that starts first has priority. The recorder starts recording the second program about ten seconds after the first program has finished. If the end time of one setting and the start time of another timer setting is the same, the beginning of the program that starts later will be cut.



DVD Recording

Notes

- The recorder starts recording only after detecting the video signal from the connected equipment. The beginning of the program may not be recorded regardless of whether or not the recorder's power is on or off.
- To use the connected equipment during Synchro-Rec standby, cancel the standby mode by pressing SYNCHRO REC. To return to standby mode again, be sure to turn off the equipment and press SYNCHRO REC, before Synchro-Rec starts.
- The Synchro-Rec function does not work with some tuners. For details, see the tuner's operating instructions.
- During Synchro-Rec standby, the Auto Clock Set function does not work (page 94).
- After a recording has finished, the recorder enters the Synchro-Rec standby mode until the SYNCHRO REC indicator turns off.
- If Synchro-Rec starts with the recorder turned on, the recorder will turn off when the recording ends.
- The recorder does not record programs with Copy-Never signals. Such recordings stop after a few seconds.

To stop recording

Press ■ STOP twice.

To cancel a Synchro-Rec standby


Press SYNCHRO REC before recording starts. The SYNCHRO REC indicator on the recorder turns off.

If you press SYNCHRO REC during Synchro-Rec, the recording stops, the SYNCHRO REC indicator turns off, and the recorder turns off.

Changing or Canceling DVD Timer Settings (Timer List)

+RW -RWvR -RWvRdel +R -R

You can change or cancel timer settings using the Timer List menu.



1 Press SYSTEM MENU.

The System Menu appears.

2 Select "Timer," and press ENTER.

3 Select "Timer List," and press ENTER.

No	RecTo	Date	Start	Stop	CH	Mode	Edit
01	DVD	04/15	09:00PM	10:00PM	CH1	SP	▶
02	DVD	04/20	09:15PM	09:45PM	CH11	SP	▶
03	---	---	---	---	---	---	▶

Timer information displays the recording date, time, recording mode, etc. If there are more than six timer settings, press ↓ to display the next page.

4 Select the timer setting you want to change or cancel, and press ENTER.

The sub-menu appears.

No	RecTo	Date	Start	Stop	CH	Mode	Edit
01	DVD	04/15	09:00PM	10:00PM	CH1	SP	▶
02	DVD	04/20	09:15PM	09:45PM	CH11	SP	▶
03	---	---	---	---	---	---	▶

5 Select one of the options, and press ENTER.

"Edit": Changes the timer setting.

Select an item using ←/→ and adjust using ↑/↓. Press ENTER.

RecTo	Date	Start	Stop	CH	Mode	Edit
01	DVD	04/15	09:00PM	10:00PM	CH1	SP
02	DVD	04/20	09:15PM	09:45PM	CH11	SP
03	---	---	---	---	---	---

"Del": Erases the timer setting.

Select "OK" and press ENTER when asked for confirmation.

6 Press SYSTEM MENU to turn off the Timer List.

To return to the previous display

Press ↶ RETURN.

Notes


- Even when correctly set, the program may not be recorded if another recording is underway, or other prioritized timer setting overlaps. For priority, see page 49.

- You cannot change the timer settings for a recording currently underway.
- The Timer List displays both the DVD recorder and VCR timer settings.

Recording From Connected Equipment Without a Timer

+RW -RWvR -RWvRdel +R -R

You can record from a connected VCR or similar device. For connection details, see "Connecting Another VCR or Similar Device" on page 26. Use the DV IN jack on the front panel if the equipment has a DV/D8 output jack (i.LINK jack).



1 Press DVD to operate the DVD recorder.

2 Insert a recordable disc.

3 Press INPUT SELECT repeatedly to select an input source according to the connection you made.

The front panel display changes as follows:

Channel → LINE1 → LINE2 → DV

DVD Recording

4 Press REC MODE repeatedly to select the recording mode.

The display changes on the TV screen as follows:

HQ → HSP → SP → LSP
SEP ← SLP ← EP ← LP

For details about the recording mode, see page 45.

5 Select the line input audio.

Set "Line Audio Input" of "Audio" to "Stereo" or "Main/Sub" in the "Setup" display (page 99).

6 Insert the source tape into the connected equipment and set to playback pause.

7 Press ● REC on this recorder and the pause or play button on the connected equipment at the same time.

Recording starts.

To stop recording, press ■ STOP on this recorder.

If you connect a digital video camera with a DV IN jack

See "Dubbing from a DV/D8 Format Tape to a DVD" (page 89) for an explanation of how to record from the DV IN jack.

Notes

- A video game image may not be recorded clearly.
- The recorder does not record programs with Copy-Never signals. Such recordings stop after a few seconds.
- During recording or recording pause, you cannot change the recording mode.
- You cannot change the channel or input source during recording.

DVD Editing

Before Editing

This recorder offers various edit options for various disc types. Before you edit, check the disc type in the front panel display, and select the option available for your disc (page 28).

Note

You may lose the edited contents if you remove the disc or a timer recording starts while editing.

Edit options for DVD+RWs/DVD-RWs (Video mode)/DVD-Rs/DVD-Rs

+RW -RWVR +R -R

You can perform simple edits. Since Video mode titles are actual recordings on the disc, you cannot undo any edits you make. The edit functions available for Video mode titles are:

- Renaming a title (page 60).
- Erasing a title (page 56).
- Setting protection against erasure (DVD+RWs only) (page 56).
- Dividing a title (DVD+RWs only) (page 58).

Notes

- Once the disc is finalized, you cannot edit or record on the disc (except for DVD+RWs).
- If a message appears and indicates that the disc's control information is full, erase unnecessary titles.

Edit options for DVD-RWs (VR mode)

-RWVR

You can enjoy advanced edit functions. First you have two options for a DVD-RW (VR mode): editing either the original recording (called the "original"), or the playback information created from the original (called a "Playlist"). Since each is different in nature and offers different merits, read the following and select the one that better suits your needs.

To edit original titles


Edits made to the original titles are final. If you plan to retain an unaltered original recording, create and edit a Playlist (see below). The edit functions available for original titles are:

- Renaming a title (page 60).
- Erasing a title (page 56).
- Erasing a chapter (page 57).
- Setting protection against erasure (page 56).
- Erasing a section of a title (A-B Erase) (page 57).
- Dividing a title (page 58).

To create and edit Playlist titles

A Playlist is a group of Playlist titles created from the original title for editing purposes. When you create a Playlist, only the control information necessary for playback, such as the playback order, is stored on the disc. Since the original titles are left unaltered, Playlist titles can be re-edited. If you erase an original title used in a Playlist, that Playlist is also erased.

Example: You have recorded the final few matches of a soccer tournament on a DVD-RW (VR mode). You want to create a digest with the goal scenes and other highlights, but you also want to keep the original recording.



In this case, you can compile highlight scenes as a Playlist title. You can even rearrange the scene order within the Playlist title. See "Editing a Playlist" on page 62.

The advanced edit functions available for Playlist titles are:

- Renaming a title (page 60).
- Erasing a title (page 56).
- Erasing a chapter (page 57).
- Erasing a section of a title (A-B Erase) (page 57).
- Editing a Playlist scene (page 62).
- Dividing a title (page 58).
- Combining titles (page 63).

Hint

You can switch the Title List to show original or Playlist. While the Title List menu is turned on, press ORIGINAL/PLAYLIST repeatedly.


Notes

- You cannot protect Playlist titles.
- If a message appears and indicates that the disc's control information is full, erase unnecessary titles.
- Once the disc is finalized, you cannot create or edit Playlist titles on the disc.

Editing a Title

+RW -RWVR -RWVR +R -R


This section explains the basic edit functions. Note that editing is irreversible. To edit a DVD-RW (VR mode) without changing the original recordings, create a Playlist title (page 61).



1 Press DVD to operate the DVD recorder.

2 Press TITLE LIST.

When editing a DVD-RW (VR mode), press ORIGINAL/PLAYLIST to switch to the "Title List (Original)," if necessary.



3 Select a title, and press ENTER.

The sub-menu appears.

→ continued 55 56

4 Select an option, and press ENTER.

You can select from the following:
 "Title Erase": Erases the selected title. Select "OK" when asked for confirmation.
 "Chapter Erase"^{*1}: Allows you to select a chapter in the title and erase it (see below).
 "Protect"^{*2}: Protects the title. Select "On" when the Protection display appears. "Off" appears for the protected title. To cancel the protection, select "Off." "Off" changes to "On."
 "Title Name"^{*}: Allows you to rename the title (page 60).
 "A-B Erase"^{*1}: Erases a section of the title (see below).
 "Divide Title"^{*2}: Divides a title into two (page 58).

^{*1} DVD-RWs (VR mode) only

^{*2} DVD+RWs and DVD-RWs (VR mode) only

Hints

- You can also rename a disc (page 66).
- For a DVD+R or DVD-R, erasing titles does not free up disc space. For DVD+RWs and DVD-RWs (Video mode), you can free up space only by erasing the last title.

Notes

- When editing a DVD-RW (Video mode), DVD+R, or DVD-R, finish all editing before finalizing the disc. You cannot edit a finalized disc.
- You cannot erase protected titles or erase chapters from a protected title.
- If you erase an original title used in a Playlist, that Playlist is also erased.


Erasing a chapter (Chapter Erase)

-RWVR

You can select a chapter within a title and erase it. Note that erasing chapters from original titles cannot be undone.

- 1 Press TITLE LIST.
Press ORIGINAL/PLAYLIST to switch to the "Title List (Original)," if necessary.
- 2 Select a title, and press ENTER.
The sub-menu appears.
- 3 Select "Chapter Erase," and press ENTER.

The display for erasing chapters appears.



4 Select the chapter you want to erase, and press ENTER.

"Check" is selected. To preview the chapter, press ENTER. When playback finishes or when you press RETURN, the display returns to "Chapter Erase (Original)."

5 Select "Erase," and press ENTER.

The display asks for confirmation.

6 Select "OK," and press ENTER.

The selected chapter is erased from the title. To erase other chapters, repeat from step 4.

Hint

You can also erase chapters from a Playlist title (page 62).

Note

If you erase an original title used in a Playlist, that Playlist is also erased.


Erasing a section of a title (A-B Erase)

-RWVR

You can select a section (scene) within a title and erase it. Note that erasing scenes from original titles cannot be undone.


- 1 Press TITLE LIST.
Press ORIGINAL/PLAYLIST to switch to the "Title List (Original)," if necessary.
- 2 Select a title, and press ENTER.
The sub-menu appears.
- 3 Select "A-B Erase," and press ENTER.
The display for setting point A and B appears.

"Start" is selected.



4 Press ENTER at the start point of the section to be erased (point A).

You can use PLAY, PAUSE, STOP, and PAUSE to find the point. "End" is selected.



5 Press ENTER at the end point of the section (point B).

"Erase" is selected. To reset the start or end point, select "Start" or "End" and repeat from step 4 or 5.

6 Press ENTER.

The display asks for confirmation.

7 Select "OK," and press ENTER.

The scene is erased. To continue, repeat from step 4. To finish, select "Finish," and press ENTER.

Hints

- A chapter mark is inserted after the scene was erased. The chapter mark divides the title into separate chapters on either side of the mark.
- You can also erase a section of a Playlist title (page 62).

Notes

- Images or sound may be momentarily interrupted at the point where you erase a section of a title.
- Sections shorter than five seconds may not be erased.
- The start and end points of a title may be different from what you have set.
- The total playing time of the title does not change even if a scene was erased.

- If you erase an original title used in a Playlist, that Playlist is also erased.

Dividing a title into two (Divide Title)

+RW -RWVR

You can divide a title into two. Note that dividing original titles cannot be undone.

1 Press TITLE LIST.


When editing a DVD-RW (VR mode), press ORIGINAL/PLAYLIST to switch to the "Title List (Original)," if necessary.

2 Select a title, and press ENTER.

The sub-menu appears.


3 Select "Divide Title," and press ENTER.

The display for setting the dividing point appears. "Point" is selected.



4 Press ENTER at the point where you want to divide the title.

You can use PLAY, PAUSE, STOP, and PAUSE to find the point. "Divide" is selected.



5 Press ENTER.

The display asks for confirmation. To reset the dividing point, select "No" and press ENTER, then repeat from step 4.

→ continued 57 58


- 6 Select "Yes," and press ENTER.
The display asks whether to use the same title name as before.
To use the same name, select "Yes" and press ENTER to finish.
- 7 Select "No," and press ENTER.
The display asks whether to rename the title.
- 8 Select "Yes," and press ENTER.
The "Title Name" display appears.
- 9 Follow steps 5 to 7 of "Changing the Name of a Title" (page 60) to complete renaming.
The divided title appears in the Title List with the new name.

Hint
You can also divide a Playlist title (page 62).


Creating chapters manually

+RW -RWVR

You can manually insert a chapter mark at any point you like during playback.



Press CHAPTER MARK at the point where you want to divide the title into chapters.
Each time you press the button, "Marking..." appears on the screen, and the scenes before and after the mark become separate chapters.



To erase chapter marks

You can combine two chapters by erasing the chapter mark during playback.
During playback, press CHAPTER MARK ERASE.
The current chapter combines with the previous chapter.

Notes


- If a message appears and indicates that no more chapter marks can be added, you may not be able to record or edit.
- You cannot add or erase chapter marks on protected titles or discs.

DVD Editing


Changing the Name of a Title

+RW -RWVR -RWVideo +R -R

You can enter a title name of up to 32 characters. Since the displayed number of characters is limited, their appearance in menus such as Title List may be different. When the display for entering characters appears, follow the steps below.



- 1 Press DVD to operate the DVD recorder.
- 2 Press TITLE LIST.
When editing a DVD-RW (VR mode), press ORIGINAL/PLAYLIST to switch to the "Title List (Original)," if necessary.
- 3 Select a title, and press ENTER.
The sub-menu appears.
- 4 Select "Title Name," and press ENTER.
The "Title Name" display appears.



- 5 Select the character you want to enter using $\uparrow/\downarrow/\leftarrow/\rightarrow$, and press ENTER.
The selected character appears in the input row.
You can only enter characters and symbols that are displayed.
 - To change the cursor position, select the input row using $\uparrow$, and press $\leftarrow/\rightarrow$.
 - To erase a character, select either of the following setting buttons and press ENTER.
 - "Backspace": Erases the character to the left of the cursor.
 - "Delete": Erases the character at the cursor position.
 - "Clear": Erases all the characters in the input row.
 - To insert a space, move the cursor to the desired position, select "Space," and press ENTER.
 - To insert a character, move the cursor to the desired position, select the character, and press ENTER.
- 6 Repeat step 5 to enter the remaining characters.
- 7 Select "Finish," and press ENTER.

Hint
You can also rename a disc (page 66). Follow steps 5 to 7 above when the "Disc Name" display appears.


Creating a Playlist

+RWVR


Playlist titles allow you to edit without changing the original recordings (see "Edit options for DVD-RWs (VR mode)" on page 55). You can create a Playlist title by combining up to 99 sections (scenes) from original titles.

Notes


- If you erase an original title used in a Playlist, that Playlist is also erased.
- Once the disc is finalized, you cannot create Playlist titles on the disc.




- 1 Press DVD to operate the DVD recorder.
- 2 Press SYSTEM MENU while the recorder is in stop mode.




- 3 Select "Edit," and press ENTER.



- 4 Select "Create Playlist," and press ENTER.
The display for creating a Playlist appears. "Start" is selected.



- 5 Press ENTER at the start point.
You can use $\triangleright$ PLAY, $\leftarrow/\rightarrow$, $\blacksquare$ STOP, and $\parallel$ PAUSE to find the point.
"End" is selected.



- 6 Press ENTER at the end point.
"Make" is selected.
To reset the start or end point, select "Start" or "End" and repeat step 5 or 6.
- 7 Press ENTER.
The selected section is captured as a scene. To continue, repeat from step 5.
- 8 When you finish capturing scenes, select "Finish" and press ENTER.

DVD Editing

Playing a Playlist title

- 1 Press TITLE LIST.
- 2 Press ORIGINAL/PLAYLIST to switch to the "Playlist" Title List.
- 3 Select a Playlist title, and press ENTER.
The sub-menu appears.
- 4 Select "Play," and press ENTER.

Hint
When a Playlist title is created, the start and end points will become chapter marks, and each scene will become a chapter.


Notes

- The picture may pause when an edited scene is played.
- The start and end points in a title may be different from what you have set.


Editing a Playlist

+RWVR


You can edit Playlist titles or scenes within them, without changing the actual recordings.




- 1 Press DVD to operate the DVD recorder.
- 2 Press SYSTEM MENU while the recorder is in stop mode.



- 3 Select "Edit," and press ENTER.




- 4 Select “Edit Playlist,” and press ENTER.**
The “Playlist” Title List appears.



- 5 Select a Playlist title, and press ENTER.**
The sub-menu appears.
- 6 Select an option, and press ENTER.**
Select from the following options. For details, see the pages in parentheses.

“Title Erase”: Erases the title. Select “OK” when asked for confirmation.
 “Chapter Erase”: Allows you to select chapters in the Playlist title to erase (page 57).
 “Title Name”: Allows you to rename the title (page 60).
 “A-B Erase”: Allows you to select sections in the title to erase (page 57).
 “Edit Scene”: Allows you to re-edit scenes in the Playlist title. Go to step 7.
 “Divide Title”: Divides the title in two at a desired point (page 56).
 “Combine Titles”: Allows you to combine two titles into one (page 63).

- 7 Select “Edit Scene,” and press ENTER.**
The display for editing scenes appears.



“Check”: Allows you to preview a scene. Starts playback of the selected scene when you press ENTER. The display returns to the “Edit Scene” display when the playback finishes or when you press **RETURN**.
 “Erase”: Erases a scene (page 64).
 “Modify”: Allows you to change the start and end point of a scene (page 64).

“Move”: Allows you to change scene order (page 65).
 “Add”: Allows you to add other scenes before a selected scene (page 65).

To return to the previous display
Press **RETURN**.

To turn off the display
Press SYSTEM MENU.

Hint
The Resume Play function will work for scene playback.

Note


Once the disc is finalized, you cannot edit Playlist titles on the disc.

Combining two titles into one (Combine Titles)


-RWVR

You can select a Playlist title and combine it with another Playlist title.

- Follow steps 1 to 5 of “Editing a Playlist” (page 62) to select a Playlist title.**
The sub-menu appears.
- Select “Combine Titles,” and press ENTER.**
The next title below is also selected.



- 3 Select a Playlist title to be combined.**



→ continued 63

- 4 Press ENTER.**

The display asks for confirmation.

- 5 Select “Yes,” and press ENTER.**

The display asks whether to use the same title name as before.
 To use the same name, select “Yes” and press ENTER to finish.

- 6 Select “No,” and press ENTER.**

The display asks whether to rename the title.

- 7 Select “Yes,” and press ENTER.**

The “Title Name” display appears.

- 8 Follow steps 5 to 7 of “Changing the Name of a Title” (page 60) to complete renaming.**

The two Playlist titles become one Playlist title with the new name.

Erasing a scene (Erase)

-RWVR

You can erase a selected scene.

- Follow steps 1 to 7 of “Editing a Playlist” (page 62).**
- Select a scene in the “Edit Scene” display and press ENTER.**
- Select “Erase,” and press ENTER.**
The display asks for confirmation.
- Select “OK,” and press ENTER.**
The selected scene is erased.
To erase other scenes, repeat from step 2.


Modifying a scene (Modify)

-RWVR

You can change the start and end point of the selected scene.


- Follow steps 1 to 7 of “Editing a Playlist” (page 62).**
- Select a scene in the “Edit Scene” display and press ENTER.**
- Select “Modify,” and press ENTER.**

“Start” is selected.



- 4 Press ENTER at the start point.**

You can use **PLAY**, **STOP**, and **PAUSE** to find the point.
 “End” is selected.



- 5 Press ENTER at the end point.**

“Change” is selected.
 To reset the start or end point, select “Start” or “End” and repeat step 4 or 5.

- 6 Press ENTER.**

The display returns to the “Edit Scene” display.
 The re-selected section is captured as a scene.
 To modify other scenes, repeat from step 2.

To cancel modifying

Select “Cancel,” and press ENTER.

Note


The start and end point of a scene may be different from what you have set.

Moving a scene (Move)

-RWVR


You can change the scene order within the Playlist title.

- Follow steps 1 to 7 of “Editing a Playlist” (page 62).**
- Select a scene in the “Edit Scene” display and press ENTER.**
- Select “Move,” and press ENTER.**




- 4 Select a new location using **LEFT** and **RIGHT** arrows, and press ENTER.**

The selected scene moves to the new location. To move other scenes, repeat from step 2.




“Start” is selected.



- 4 Press ENTER at the start point.**

You can use **PLAY**, **STOP**, and **PAUSE** to find the point.
 “End” is selected.



- 5 Press ENTER at the end point.**

“Add” is selected.
 To reset the start or end point, select “Start” or “End” and repeat step 4 or 5.

- 6 Press ENTER.**

The display returns to the “Edit Scene” display.
 The selected section is added before the selected scene.
 To add other scenes, repeat from step 2.

To cancel adding

Select “Cancel,” and press ENTER.


Note

The start and end point of a scene may be different from what you have set.

Formatting/Renaming/Protecting a Disc


-RW VR RW+R -R

The “Disc Setting” display allows you to check the disc information or change the disc name. Depending on the disc type, you can also format or set protection.



- Press DVD to operate the DVD recorder.**
- Press SYSTEM MENU while the recorder is in stop mode.**

- 3 Select “Disc Setting,” and press ENTER.**
The “Disc Setting” display appears.



- 4 Select an option, and press ENTER.**

- “Disc Name”: Allows you to rename a disc.
For details on how to enter characters, see page 60.
- “Disc Protect” (DVD-RWs (VR mode) only): Protects all titles on the disc when “Protected” is selected. To cancel the protection, select “Not Protected.”

- 3 “Disc Format” (DVD+RWs/DVD-RWs only):** Erases all contents of the disc, including protected titles, and makes a blank disc.
 For DVD-RWs, select a recording format (“VR Mode” or “Video Mode”) according to your needs.

- 4 “Disc Finalize”:** Finalizes a disc. See page 86 for details.

- 5 “Disc Information”:** Displays the following information.
- Disc name
 - Disc type (and recording format for a DVD-RW (VR mode))
 - Total number of titles
 - Protect setting
 - The oldest and most recent recording date
 - The total available recording time in each recording mode

Disc Information			
Disc Name	Disc 1		
Media	DVD-RW	Format	VR Mode
Title No.	Original 6 / Playlist 1		
Protected	Not Protected		
Date	04/05/2005 - 04/05/2005		
Remainder	HQ : 24 52M	HSP : 24 28M	SP : 24 52M
	LSP : 24 23M	LP : 24 52M	EP : 24 52M
	SLP : 54 48M	SEP : 24 48M	4:44:12B

- 6 “Erase All Titles” (DVD+RWs/DVD-RWs only):** Erases all titles on the disc (except protected titles). Select “OK” when asked for confirmation.
 For DVD-RWs (VR mode), Playlist titles created with protected titles are also erased.

To return to the previous display

Press **RETURN**.

Hints

- You can set protection for individual titles (page 56).
- By reformatting, you can change the recording format on DVD-RWs, or record again on DVD-RWs (Video mode) that have been finalized.


Note

You can label a disc using up to 32 characters; however, the name may not display on other DVD equipment.

VCR Playback

Playing


VHS



1 Press VIDEO to operate the VCR.

2 Insert a tape.

Playback starts automatically if you insert a tape with its safety tab removed.



3 Press ▷ PLAY.

The front panel display shows the playing time. When the tape reaches the end, it will rewind automatically.

To stop playback

Press ■ STOP.

To eject the tape

Press ▲ OPEN/CLOSE.

To turn off the power while rewinding (Rewind Shut Off)

Press I/⏮ while the tape is rewinding. The power will turn off but the tape will keep rewinding until it reaches the end.

To use the time counter

Press CLEAR at the point where you want to find later. The counter in the front panel display resets to "0:00:00."

To search for the 0:00:00 point automatically, see page 70.

To display the counter on the TV screen, press DISPLAY.

Notes

- During playback, the VCR automatically detects the recording system (S-VHS/VHS) and the recording mode (SP or EP) from the tape. LP mode recordings made on other equipment will play, but picture quality is not guaranteed.
- The counter resets to "0:00:00" whenever a tape is reinserted.
- The counter stops counting when it comes to a portion with no recording.
- The counter resets to "0:00:00" after ten hours, and starts recounting.
- When playback does not start even if you insert a tape with its safety tab removed, set "VCR Function" – "Auto Play" of "Features" to "On" in the "Setup" display (page 100).
- If you switch to the VCR while playing a disc, DVD playback stops.
- The VCR does not record in S-VHS format, but will play S-VHS tapes by automatically detecting the format, but picture quality will be lower than usual S-VHS. Image may be unclear if playback options such as slow-motion, etc., are used.
- Playback of S-VHS tapes recorded in EP (3x) mode is not guaranteed.
- The VCR is not compatible with the PAL or SECAM color system. Only NTSC tapes can be played.
- For simultaneous VHS and DVD operation, see page 9.

VCR Playback


Adjusting the picture (tracking)

You can manually adjust tracking if the recording quality is too poor to be remedied by the VCR's automatic tracking (a tracking meter appears during the automatic tracking).

Press TRACKING +/-.

The tracking meter appears.

Press TRACKING +/- repeatedly until the distortion disappears.




To resume automatic tracking

Press TRACKING + and TRACKING – on the recorder at the same time for more than ten seconds. Or, eject the tape and reinsert it.

→continued 67

68

Playback Options



Button	Operation
◀◀ ▶▶ (fast reverse/fast forward)	• Fast reverses or fast forwards when pressed during stop mode. • When you hold down during fast reverse or fast forward, you can view the picture. • Plays at high speed when briefly pressed during playback. • When you hold down the button during playback, the high-speed play continues until you release the button.
◀◀ ▶▶ (slow)	Plays in slow motion when pressed in pause mode.
▶ ADVANCE	• Advances one frame for each press in pause mode. • Fast forwards the current scene for 30 seconds when pressed during playback.*1
◀◀ REPLAY	Replays the previous scene when pressed during playback.*2
◀◀ PREV/ NEXT ▶▶	Press during playback. Playback speed changes with each press: →x7 ↔ →x5 ↔ →x3 ↔ STILL ↔ SLOW ↔ PLAY ↔ x2 ↔ x3 ↔ x5 ↔ x7
PAUSE	Pauses playback. If you pause playback for more than five minutes, playback starts automatically.

*1 Can be pressed up to four times to forward about two minutes.

*2 For 10 seconds in SP or LP mode/for 15 seconds in EP mode.

To resume normal playback, press ▷ PLAY.

Notes

- The sound is muted during playback at various speeds.
- The picture may show noise during high-speed reverse play.

VCR Playback

Searching Using Various Functions


VHS

The VCR automatically marks the tape with an index signal at the point where each recording begins.

You can easily find a specific point using various search functions.

Note


During DVD recording, you cannot use VCR search functions.




1 Press VIDEO to operate the VCR.

2 Press TOOLS.


3 Select a search method from the TOOLS menu, and press ENTER.




"Go To Zero": Searches for the 0:00:00 point on the tape counter.
To reset the counter to 0:00:00, press CLEAR.



"End Search": Searches for the beginning of a blank space. If no blank space is found, the tape will reach the end.



"Forward Intro Scan"/"Reverse Intro Scan": Searches for an index mark and plays back for about five seconds at that point. Press ▷ PLAY to view that program. If you do not press ▷ PLAY, the VCR automatically searches for the next index mark, or until it reaches the end of the tape.



Notes

- The VCR may not recognize the end of a blank space depending on its length.
- No index signal is marked if you pause a recording and then keep recording the same program. To mark an index, press ■ STOP or change the channel once during recording pause.


69

70

Displaying the Playing Time and Play Information

VHS


You can check playback information, such as elapsed or remaining time, recording mode, etc., on the TV screen.



Press DISPLAY during playback.

The information display appears. Each time you press the button, the display changes as follows:

Tape and disc information/date and time
↓
Tape information only
↓
No display



- 1 Playing status
- 2 Time counter (elapsed time)
- 3 Recording mode
- 4 Remaining tape length

- 5 Channel or input source
- 6 Date and time


Viewing information on the front panel display

You can view the information on the front panel display.


Press TIME/TEXT repeatedly.

The displays differ depending on the status.

Example: When playing a tape




Example: When a tape is in stop mode



Selecting the Sound During Playback

VHS




Press AUDIO repeatedly during playback.

To listen to	On-screen display	Front panel display
Stereo	Hi-Fi	STEREO
Left channel	Left	STEREO
Right channel	Right	STEREO
Monaural sound on the normal audio track	Mono	STEREO*

* No indicator appears in the front panel display when you play a tape without Hi-Fi recording.

How sound is recorded on a video tape

The VCR records sound onto two separate tracks. Hi-Fi audio is recorded onto the main track along with the picture. Monaural sound is recorded onto the normal audio track along the edge of the tape.



VCR Recording

Before Recording

Before you start recording...


- This VCR records in VHS format, not S-VHS format.
- Check that the tape is longer than the recording time (page 71).

Notes

- Timer recordings will start with or without the recorder turned on. Once started, the recorder cannot be turned off. The recorder automatically turns off after a recording has finished.
- This recorder shares a single tuner for both the DVD recorder and the VCR. You cannot record different programs to a DVD and a VHS tape at the same time.
- This recorder has the copy guard function. Programs that contain a Copy-Never copy guard signal cannot be correctly recorded on the VCR.

To save a recording

To prevent accidental erasure, break off the safety tab as illustrated. To record on the tape again, cover the tab hole with adhesive tape.



Recording mode

"EP" (Extended Play) and "SP" (Standard Play) is available for recording mode (tape speed). "EP" provides recording time three times as long as "SP." However, "SP" produces better picture and audio quality.

Maximum recording time

Tape Length	SP	EP
T-120	2 hrs	6 hrs
T-160	2 hrs 40 mins	8 hrs
T-180	3 hrs	9 hrs

Notes

- Tapes recorded in EP (x3) mode by this VCR cannot be played back on VHS video decks with SP mode only.
- Noise may appear in the image when tapes recorded in EP (x3) mode by this VCR are played back on other VHS video decks with EP mode.

Recording a stereo/SAP program

The recorder can receive and record stereo/SAP programs.

Stereo programs


When a stereo program is received, the "STEREO" indicator lights up in the front panel display. If there is noise in the stereo program, press AUDIO repeatedly until the "MONO" indicator disappears from the TV screen. The sound will be recorded in monaural but with less noise.

SAP (Second Audio Program)


When a SAP is received, the "SAP" indicator lights up in the front panel display. To record only SAP sound, set "Tuner Audio" of "Audio" to "SAP" in the "Setup" display (page 97).

VCR Recording Without the Timer

VHS



- 1 Press VIDEO to operate the VCR.
- 2 Insert a tape with its safety tab in place.



- 3 Press CH +/- or INPUT SELECT repeatedly to select the channel or input source you want to record.
- 4 Press REC MODE repeatedly to select the recording mode, "SP" or "EP."
- 5 Press ● REC.

For details about the recording mode, see page 73.

"REC" appears in the front panel display, and recording starts.

To stop recording

Press ■ STOP.

To pause recording

Press ■ PAUSE.

To restart recording, press ■ PAUSE again. If you pause recording for more than five minutes, recording stops automatically.

To watch another TV program while recording

- 1 Slide the TV/DVD-VIDEO switch to TV.
- 2 Press TV/VIDEO to set the TV to the TV input.
- 3 Select another channel on the TV.

To watch a DVD while recording

Press DVD to operate the DVD recorder, insert a disc, and press ► PLAY.

Hints

- To select a channel, you can use the number buttons. Enter the channel number, and press SET.
- You can select a video source from the LINE 1 IN or LINE 2 IN jacks using the INPUT SELECT button.
- Tape information displayed on the TV screen will not be recorded on the tape.
- You can turn off the TV during recording. If you are using a cable box or a satellite receiver, make sure to leave it on.

Notes


- You cannot change the recording mode, channel, or input source while recording.
- If you insert a tape with its safety tab removed, the tape is ejected when you press ● REC.

Recording using the Quick Timer (One-touch Timer Recording)

You can set the recorder to record in 30-minute increments.

- 1 Press VIDEO to operate the VCR.
- 2 Press ● REC repeatedly to set the duration.

Each press increases the time by 30 minutes, up to six hours.



"⊙" and "OTR" light up, and the remaining recording time appears in the front panel display.

When the counter reaches "0:00," the recorder stops recording and turns off.

To cancel the Quick Timer

Press **●** REC repeatedly until the counter appears in the front panel display. The recorder returns to normal recording mode.

To stop recording

Press **■** STOP twice.


Checking the remaining tape length

You can check recording information, such as remaining tape length or recording mode, etc.

Press DISPLAY while recording.

The information display appears.

Press the button repeatedly to change the display (page 71).



- 1 Recording status
- 2 Time counter
- 3 Recording mode
- 4 Remaining tape length
- 5 Current channel

To check the remaining tape length, set "VCR Function" – "Tape Length" of "Features" in the "Setup" display correctly (page 100).

Hint

You can view the information also in the front panel display. Press TIME/TEXT repeatedly to change the display. Note that TIME/TEXT does not work during One-touch Timer Recording.

Notes

- The remaining tape length may not be indicated accurately for short tapes such as T-20 or T-30, or tapes recorded in LP mode.
- After DISPLAY is pressed, it may take one minute for the remaining tape length to appear.

VCR Timer Recording


VHS

You can set the timer for a total of 12 programs together with DVD and VCR timer recording, up to one month in advance.


Follow the steps below to set each timer recording items.

Note


Do not operate your cable box or satellite receiver just before or during a timer recording. This may prevent the accurate recording of a program.



- 1 Press VIDEO to operate the VCR.
- 2 Insert a tape with its safety tab in place.



3 Press TIMER.



4 Select an item using ←/→ and adjust using ↑/↓.

- 1 "RecTo": Select "VCR."
- 2 "Date": Sets the date using ↑. To record the same program every day or the same day every week, press ↓. The item changes as follows:
Today ↔ Sun-Sat (Sunday to Saturday) ↔ Mon-Sat (Monday to Saturday) ↔ Mon-Fri (Monday to Friday) ↔ Sun (every Sunday) ↔ Mon (every Monday) ↔ ... ↔ Sat (every Saturday) ↔ 1 month later ↔ ... ↔ Today
- 3 "Start": Sets the start time.
- 4 "Stop": Sets the stop time.
- 5 "CH": Selects the channel or input source.
- 6 "Mode": Selects the recording mode; "SP" or "EP." To use the Rec Mode Adjust function (page 77), select "AUTO."

If you make a mistake, select the item and change the setting.

5 Press ENTER.

The Timer List menu (page 79) appears. The indicator lights up in the front panel display, and the recorder is ready to start recording. If the indicator flashes in the front panel display, check that a tape with its safety tab in place is inserted. There is no need to turn off the recorder before the timer recording starts. If timer settings overlap, a message appears. To change or cancel a timer recording, select "Edit" from the Timer List (page 79).


6 Press SYSTEM MENU to turn off the menu.

To stop recording

Press **■** STOP twice.

If timer settings overlap

The program that starts first has priority and the second program starts recording only after the first program has finished. If the programs start at the same time, the program listed first in the menu has priority. If the end time of one setting and the start time of another timer setting is the same, the beginning of the program that starts later will be cut.



To change or cancel timer recording

See "Changing or Canceling VCR Timer Settings (Timer List)" on page 79.

To use the Rec Mode Adjust function

If the remaining tape length is too short for the current recording, the VCR automatically changes the recording mode from SP to EP.

When setting the timer, select "AUTO" in "Mode," and check that the "Tape Length" setting is correct for the inserted tape ("VCR Function" – "Tape Length" of "Features" in the "Setup" display (page 100)).

Hints

- When the start time and the channel or input source to be recorded are the same but the "RecTo" setting differs, the program is recorded to both the DVD disc and the VHS tape.
- You can also turn on the Timer programming menu from the System Menu. Press SYSTEM MENU to select "Timer," and select "Timer-Standard."

Notes


- To record a cable or satellite program, turn on the cable box or satellite receiver and select the program you want to record. Leave the cable box or satellite receiver turned on until the recorder finishes recording.
- Even when correctly set, the program may not be recorded if another recording is underway, or other prioritized timer setting overlaps.
- You cannot record on a tape with its safety tab removed.
- Before the timer recording starts, "TIMER REC" flashes in the front panel display.
- The recorder automatically turns off when a timer recording finishes, even if the recording started with the recorder turned on.

Recording From Connected Equipment With a Timer (Synchro Rec)

VHS

You can set the recorder to automatically record programs from connected equipment that has a timer function (such as a satellite tuner). Connect the equipment to the LINE 1 IN jacks on the rear of the recorder (page 27).

When the connected equipment turns on, the recorder starts recording a program from the LINE 1 IN jacks.



- 1 Press VIDEO to operate the VCR.
- 2 Insert a tape with its safety tab in place.
- 3 Press REC MODE repeatedly to select the recording mode, "SP" or "EP."
- 4 Press SYSTEM MENU while the recorder is in stop mode.
- 5 Select "Setup," and press ENTER.
- 6 Select "Features," and press ENTER. The "Features" setup appears.
- 7 Select "Synchro Recording," and press ENTER.

8 Select "to Video," and press ENTER.

9 Press SYSTEM MENU to turn off the menu.

10 Set the timer on the connected equipment to the time of the program you want to record, and turn it off.

11 Press SYNCHRO REC.

The SYNCHRO REC indicator lights up on the front panel and the recorder stands by for Synchro-Rec. The recorder starts recording when a signal is received from the connected equipment. When the connected equipment turns off, the recording stops and the recorder turns off.

To stop recording

Press **■** STOP twice.


To cancel Synchro-Rec function

Press SYNCHRO REC before recording starts. The SYNCHRO REC indicator on the recorder turns off.

If you press SYNCHRO REC during Synchro-Rec, the recording stops, the SYNCHRO REC indicator turns off, and the recorder turns off.

If the timer settings of a Synchro-Recording and another timer recording overlap

Regardless of whether or not the program is a Synchro-Rec program, the program that starts first has priority and the second program starts recording only after the first program has finished. If the end time of one setting and the start time of another timer setting is the same, the beginning of the program that starts later will be cut.




Notes

- The recorder starts recording only after detecting the video signal from the connected equipment. The beginning of the program may not be recorded regardless of whether or not the recorder's power is on or off.
- To use the connected equipment during Synchro-Rec standby, cancel the standby mode by pressing SYNCHRO REC. To return to standby mode again, be sure to turn off the equipment and press SYNCHRO REC, before Synchro-Rec starts.
- The Synchro-Rec function does not work with some tuners. For details, see the tuner's operating instructions.
- During Synchro-Rec standby, the Auto Clock Set function does not work.
- After a recording has finished, the recorder enters the Synchro-Rec standby mode until the SYNCHRO REC indicator turns off.
- You cannot record on a tape with its safety tab removed.
- If Synchro-Rec starts with the recorder turned on, the recorder will turn off when the recording ends.

Changing or Canceling VCR Timer Settings (Timer List)

VHS

You can change or cancel timer settings using the Timer List menu.



- Press **SYSTEM MENU**. The System Menu appears.
- Select **"Timer,"** and press **ENTER**.
- Select **"Timer List,"** and press **ENTER**.

No.	RecTo	Date	Start	Stop	CH	Mode	Edit
01	VCR	06/15	09:00PM	10:00PM	CH8	SP	▶
02	VCR	06/20	09:15PM	09:45PM	CH11	SP	▶
03	---	---	---	---	---	---	▶
04	---	---	---	---	---	---	▶
05	---	---	---	---	---	---	▶
06	---	---	---	---	---	---	▶

Timer information displays the recording date, time, recording mode, etc.
If there are more than six timer settings, press **↓** to display the next page.

- Select the timer setting you want to change or cancel, and press **ENTER**. The sub-menu appears.

No.	RecTo	Date	Start	Stop	CH	Mode	Edit
01	VCR	06/15	09:00PM	10:00PM	CH8	SP	▶
02	VCR	06/20	09:15PM	09:45PM	CH11	SP	▶
03	---	---	---	---	---	---	▶
04	---	---	---	---	---	---	▶
05	---	---	---	---	---	---	▶
06	---	---	---	---	---	---	▶

- Select one of the options, and press **ENTER**.

"Edit": Changes the timer setting.
Select an item using **←/→** and adjust using **↑/↓**. Press **ENTER**.

RecTo	Date	Start	Stop	CH	Mode
01	06/15	09:00PM	10:00PM	CH8	SP
02	06/20	09:15PM	09:45PM	CH11	SP
03	---	---	---	---	---
04	---	---	---	---	---
05	---	---	---	---	---
06	---	---	---	---	---

"Del": Erases the timer setting.
Select **"OK"** and press **ENTER** when asked for confirmation.



- Press **SYSTEM MENU** to turn off the Timer List.

To return to the previous display
Press **↶** RETURN.

Notes

- Even when correctly set, the program may not be recorded if another recording is underway, or other prioritized timer setting overlaps. For priority, see page 77.


→ continued 79

80

Recording From Connected Equipment Without a Timer

VHS

You can record from a connected VCR or similar device. For connection details, see "Connecting Another VCR or Similar Device" on page 26.



- Press **VIDEO** to operate the VCR.
- Insert a tape with its safety tab in place.
- Press **INPUT SELECT** repeatedly to select an input source according to the connection you made.
The front panel display changes as follows:

Channel → LINE1 → LINE2
↑

- Press **REC MODE** repeatedly to select the recording mode, "SP" or "EP."
- Insert the source tape into the connected equipment and set to playback pause.
- Press **● REC** on this recorder and the pause or play button on the connected equipment at the same time.
Recording starts.

To stop recording, press **■ STOP** on this recorder.

Notes

- A video game image may not be recorded clearly.
- You cannot record on a tape with its safety tab removed.
- During recording or recording pause, you cannot change the recording mode.
- You cannot change the channel or input source during recording.

Dubbing (TAPE ↔ DVD)


Dubbing From a VHS Tape to a DVD

▶REW ◀RW▶ ◀RW▶▶ ▶R ▶R VHS

You can easily record (dub) a VHS tape to a disc. Before dubbing, make the necessary audio settings on the VCR.

◆How titles and chapters are created

The recorder takes each recording on the VHS tape and automatically divides them into titles as they are dubbed to a disc. These titles are then further divided into chapters at either 5 or 15-minute intervals, according to the "DVD Auto Chapter" setting of "Features" in the "Setup" display.



- Press **DVD** and insert a recordable disc.
To select the recording mode, press **REC MODE** repeatedly (see page 45).

- Insert a source **VHS** tape.
- Press **VIDEO** to operate the VCR.
- Start playing the **VHS** tape, and then press **■ STOP** or **⏸ PAUSE** at the point where you want to start dubbing.
To select VCR sound, press **AUDIO** during playback (see page 72).
- Press **← VIDEO** on the recorder.
Dubbing starts.


To stop dubbing

Press **■ STOP**.
Note that it may take a few seconds for the recorder to stop dubbing.


To play discs recorded with this recorder on other **DVD** equipment
Finalize the disc (see page 86).

To dub using the on-screen menu

- After step 4 above, press **SYSTEM MENU**.
- Select **"Dubbing"** from the System Menu, and press **ENTER**.



- Select **"Simple Dubbing,"** and press **ENTER**.



- Select **"VIDEO → DVD,"** and press **ENTER**. The display asks for confirmation.
- Select **"Yes,"** and press **ENTER**.
Dubbing starts.

81

82

Hints

- A black (no signal) screen at the end of the dubbed disc is not a malfunction. This screen is recorded if a time discrepancy exists between the disc and tape when the recording is stopped.
- When dubbing a VHS tape to a DVD, the VHS tape counter value may differ slightly from the DVD recording time.
- VCR playback sound is output during dubbing.


Notes

- Dubbing cannot be made when:
 - using a non-recordable DVD.
 - using VHS software with copy guard functions.
- Dubbing stops when:
 - the VHS tape reaches the end and stops.
 - the VHS video deck or the DVD deck is stopped.
 - the disc remaining time runs out.
- The System Menu, TOOLS menu, and information display are not displayed during dubbing.
- Copyrights
 - Recordings made from VHS tapes and other copyrighted material are solely for individual enjoyment, and other unauthorized use is prohibited under copyright law.
 - Unauthorized editing of copyrighted material is prohibited under copyright law.

Dubbing From a DVD to a VHS Tape



You can record (dub) a DVD title to a VHS tape. Note that when you record copy-protected software to a tape, picture may appear disrupted when you play back the tape. You can also select titles or scenes and dub them all at once. See "Dubbing selected titles and scenes (Program Dubbing)" on page 84. Before dubbing, make the necessary audio settings on the DVD recorder.



1 Press VIDEO and insert a VHS tape with its safety tab in place.

To select the recording mode, SP or EP, press REC MODE repeatedly (see page 73).

→continued 83

84

2 Insert a source disc.

3 Press DVD to operate the DVD recorder.

4 Press TOP MENU or TITLE LIST to select a title.

5 Start playing the DVD, and then press ■ STOP or ■ PAUSE at the point where you want to start dubbing.

To select DVD sound, language, or subtitle, press AUDIO or SUBTITLE during playback (see page 33).

6 Press DVD → on the recorder.

Dubbing starts.

To stop dubbing


Press ■ STOP.

Note that it may take a few seconds for the recorder to stop dubbing.


To dub using the on-screen menu

1 After step 5 above, press SYSTEM MENU.

2 Select "Dubbing" from the System Menu, and press ENTER.



3 Select "Simple Dubbing," and press ENTER.



4 Select "DVD → VIDEO," and press ENTER. The display asks for confirmation.

5 Select "Yes," and press ENTER.

Dubbing starts.

If the disc's menu appears when DVD playback finishes, press ■ STOP to stop

dubbing. Otherwise the disc's menu is recorded until the tape reaches its end.

Hints

- The brightness of the playback picture may differ from normal DVD playback picture.
- The DVD playback time may differ slightly from the VHS tape counter value.
- The sound being played back (main, sub, etc.) is the dubbed sound.

Notes

- Dubbing cannot be made when "Progressive" of "Video" is set to "On" in the "Setup" display.
- Dubbing stops when:
 - the DVD is played back to the end and stops.
 - the DVD deck or the VHS video deck is stopped.
 - the tape remaining time runs out.
- The System Menu, TOOLS menu, and information display are not displayed during dubbing.
- Copyrights
 - Recordings made from discs and other copyrighted material are solely for individual enjoyment, and other unauthorized use is prohibited under copyright law.
 - Unauthorized editing of copyrighted material is prohibited under copyright law.

Dubbing selected titles and scenes (Program Dubbing)

You can select titles or scenes from a DVD, and dub the contents to a VHS tape all at once.

1 Press VIDEO and insert a VHS tape with its safety tab in place.

To select the recording mode, SP or EP, press REC MODE repeatedly (see page 73).


2 Press DVD and insert a source disc.

To select DVD sound, language, or subtitle, press AUDIO or SUBTITLE during playback (see page 33).


3 Press SYSTEM MENU.

The System Menu appears.

4 Select "Dubbing," and press ENTER.




5 Select "Program Dubbing," and press ENTER.



6 Select "Create Dubbing List," and press ENTER.

If you have performed Program Dubbing before, the display asks for confirmation. To continue, select "Yes" and press ENTER. The display for selecting titles appears.




7 Select the title you want to dub, and press ENTER.

The sub-menu appears. To dub the entire title, select "Title Dubbing" and press ENTER. The Program Dubbing List appears with the selected title. Go to step 13. To select a scene to dub, go to step 8.


8 Select "Scene Dubbing," and press ENTER.

The display for setting a scene appears. "Start" is selected.



9 Press ENTER at the start point.

You can use ▷ PLAY, ◀◀◀ PAUSE, ▶▶▶, ■ STOP, and ■ PAUSE to find the point. "End" is selected.



10 Press ENTER at the end point.

"Make" is selected.


To reset the start or end point, select "Start" or "End" and repeat from step 9 or 10.

11 Press ENTER.

To continue, repeat from step 9.

12 Select "Finish," and press ENTER.

The Program Dubbing List appears with the selected scene.



13 Select an option and press ENTER, if necessary.

To add other titles or scenes, select "Addition" and press ENTER, and repeat from step 7. To cancel the selected title or scene, select "Erase" and press ENTER. When asked for confirmation, select "OK" and press ENTER. To view the selected title or scene, select "Check" and press ENTER. To cancel dubbing, press ◀◀◀ RETURN.

14 Select "Dubbing," and press ENTER.

Dubbing starts.

Dubbing (TAPE → DVD)

→continued 85

86

To stop dubbing

Press ■ STOP.

Note that it may take a few seconds for the recorder to stop dubbing.

Hints

- The brightness of the playback picture may differ from normal DVD playback picture.
- The DVD playback time may differ slightly from the VHS tape counter value.
- The sound being played back (main, sub, etc.) is the dubbed sound.

Notes

- Dubbing cannot be made when "Progressive" of "Video" is set to "On" in the "Setup" display.
- Dubbing stops when:
 - the DVD is played back to the end and stops.
 - the DVD deck or the VHS video deck is stopped.
 - the tape remaining time runs out.
- The System Menu, TOOLS menu, and information display are not displayed during dubbing.
- Copyrights
 - Recordings made from discs and other copyrighted material are solely for individual enjoyment, and other unauthorized use is prohibited under copyright law.
 - Unauthorized editing of copyrighted material is prohibited under copyright law.
- Once you eject the disc, the Program Dubbing List is erased.

Finalizing a Disc (Preparing a Disc for Playback on Other Equipment)




Finalizing is necessary in order to play discs recorded with this recorder on other DVD equipment.

When you finalize a DVD+RW/DVD-RW (Video mode)/DVD+R/DVD-R, a DVD menu will be automatically created, which can be displayed on other DVD equipment.


Before finalizing, check the differences between the disc types in the table below.

Differences between the disc types


+RW	Discs are automatically finalized when removed from the recorder. If you want to record on it again, reformat the disc (page 66). Note however, that reformatting a disc erases all its contents.
-RWVR	Finalizing is unnecessary when playing a disc on VR format compatible equipment. Even if your other DVD equipment is VR format compatible, you may need to finalize the disc, especially if the recording time is short. After finalizing, you cannot edit or record on the disc. If you want to edit or record on it again, unfinalize or reformat the disc (page 66). Note however, that reformatting a disc erases all its contents.
-RWvideo	Finalizing is necessary in order to play on equipment other than this recorder. After finalizing, you cannot edit or record on the disc. If you want to edit or record on it again, unfinalize or reformat the disc (page 66). Note however, that reformatting a disc erases all its contents.
+R	Finalizing is necessary in order to play on equipment other than this recorder. After finalizing, you cannot further edit or record on the disc.
-R	




- 1 Press DVD to operate the DVD recorder.
- 2 Insert a disc.
- 3 Press SYSTEM MENU while the recorder is in stop mode.
The System Menu appears.
- 4 Select "Disc Setting," and press ENTER.
The "Disc Setting" display appears.



- 5 Select "Disc Finalize," and press ENTER.
The display asks for confirmation.



- 6 Select "Finalize," and press ENTER.
The display asks for confirmation again.



- 7 Select "OK," and press ENTER.
The recorder starts finalizing the disc.

To turn off the display

Press SYSTEM MENU.

To unfinalize a DVD-RW (VR mode)

If you cannot record or edit on a DVD-RW (VR mode) that has been finalized, unfinalize the disc by selecting "Unfinalize" in step 6 above.

Hints

- You can check whether the disc has been finalized or not. If you cannot select "Finalize" in step 6 above, the disc has already been finalized.
- To check the disc information, select "Disc Information" in the "Disc Setting" display and press ENTER. See page 66 for details.

Notes

- A finalized disc may not play, depending on the condition of the disc, recording, or the DVD equipment.
- The recorder may not be able to finalize a disc if it was recorded on another recorder.

Dubbing (TAPE → DVD)

DV/D8 Dubbing (DV/D8 → DVD)

Before DV/D8 Dubbing

This section explains dubbing with a digital video camera via the DV IN jack on the front panel. If you want to dub by way of the LINE IN jacks, see "Recording From Connected Equipment With a Timer (Synchro Rec)" on page 50.

To record from the DV IN jack

The DV IN jack on this recorder conforms to the i.LINK standard. You can connect any other equipment that has an i.LINK (DV) jack, and record digital signals. Follow the instructions in "Connecting a Digital Video Camera to the DV IN Jack," and then move on to the section on dubbing. For more information about i.LINK, see "About i.LINK" on page 110.

Hint

If you plan to do additional editing on a disc after the initial dub, use the DV IN jack and record on a DVD-RW (VR mode).


Connecting a Digital Video Camera to the DV IN Jack

You can connect a digital video camera to the DV IN jack on the recorder to record or edit from a DV/D8 format tape. Operation is straightforward because the DVD recorder will fast forward and rewind the tape for you – you do not need to operate your digital video camera. Do the following to start using the "DV/D8 Edit" functions of this recorder. See the instruction manual supplied with the digital video camera as well before connecting.

Notes

- The DV IN jack is for input only. It will not output signals.
- You cannot use the DV IN jack when:
 - your digital video camera does not work with this recorder. Connect the camera to the LINE IN jack and follow the instructions of "Recording From Connected Equipment Without a Timer" on page 53.
 - the input signal is not in DVC-SD format. Do not connect a MICRO MV format digital video camera even if it has an i.LINK jack.
 - the images on the tape contain copy protection signals, which limit recording.

Hookups



Dubbing From a DV/D8 Format Tape to a DVD


+RW -RWvR -RWvR +R -R

You can record a DV/D8 format tape onto a disc. The recorder controls the digital video camera. You can fast forward, rewind, play in slow motion, and stop the tape to select the scenes using the on-screen menu.

To simply dub the entire contents of a DV/D8 format tape (One Touch Dubbing), see page 91.

◆How titles and chapters are created

The dubbed contents on the disc become one title, and the title is then divided into chapters at either 5 or 15-minute intervals, according to the "DVD Auto Chapter" setting of "Features" in the "Setup" display.



- 1 Press DVD to operate the DVD recorder.
- 2 Press OPEN/CLOSE, and place a recordable disc on the disc tray.



- 3 Press OPEN/CLOSE to close the disc tray.
Wait until "LOAD" disappears from the front panel display.

Unused DVD-RWs are formatted in VR mode automatically. To format in Video mode, see page 100.

- 4 Insert the source DV/D8 format tape into your digital video camera.


For the recorder to record or edit, your digital video camera must be set to video playback mode.

- 5 Press INPUT SELECT repeatedly to select "DV."


- 6 Press REC MODE repeatedly to select the recording mode.
For details about the recording mode, see page 45.

- 7 Press SYSTEM MENU while the recorder is in stop mode.
The System Menu appears.

- 8 Select "Setup," and press ENTER.




- 9 Select "Audio," and press ENTER.



DV/D8 Dubbing (DV/D8 → DVD)

- 10 Select "DV Audio Input," and press ENTER.



"Stereo 1": Records original sound only. Normally select this when dubbing a DV format tape.

"Stereo 2": Records additional audio only.


"Mix": Records original and additional sounds.

Select "Stereo 2" or "Mix" if you have added a second audio channel when recording with your digital video camera. For the details, see page 99.

- 11 Select an option, and press ENTER.

- 12 Press RETURN twice.

- 13 Select "Dubbing," and press ENTER.



- 14 Select "DV/D8 Dubbing," and press ENTER.



- 15 Select "DV/D8 Simple Dubbing," and press ENTER.
The following display appears.

If "DV" or "DV Camera Mode" is displayed instead of "DV Tape Mode," check that the digital video camera is correctly connected and its power turned on, and that its mode is set for dubbing.

- 16 Find the dubbing start point on the tape, and stop or pause playback.

Press **ENTER** to select **◀**, **■**, **II**, **▶**, **▷**, or **▶▶** on the TV screen and press ENTER to find the point, and stop or pause with **■** or **II**.

- 17 Press **▶▶** to select **●** on the TV screen, and press ENTER.
Dubbing starts.

To stop during recording

Select **■** on the TV screen, and press ENTER. Note that it may take a few seconds for the recorder to stop recording.

To turn off the display for DV/D8 dubbing

Press INPUT SELECT or CH +/-.

Hint

If "DV Camera Mode" appears on the screen, you can use **●** on the TV screen to record the camera image directly on the recorder.

Notes

- If you want to play the disc on other DVD equipment, finalize the disc (page 86).
- You cannot connect more than one piece of digital video equipment to the recorder.
- You cannot record the date, time, or contents of a DV/D8 format tape onto the disc.
- If you record from a DV/D8 format tape with a soundtrack that is recorded in multiple sampling frequencies (48 kHz, 44.1 kHz, or 32 kHz), no sound, or an unnatural sound will be output when playing back the sampling frequency switch point on the disc.
- The recorded picture may be momentarily affected if the picture size of the source image changes, or if there is nothing recorded on the tape.

→ continued 89


90

• Noise may occur when you switch the audio sampling mode (48 kHz/16 bits → 32 kHz/12 bits).

Dubbing an entire DV/D8 format tape to a DVD (One Touch Dubbing)

▶RW ◀RW▶ ◀RW▶ ▶R ▶R

You can record the entire contents of a DV/D8 format tape onto a disc with a single press of the ONE TOUCH DUBBING button. The recorder controls the digital video camera for the whole process, and completes the recording.



Follow steps 1 to 11 of "Dubbing From a DV/D8 Format Tape to a DVD" (page 89), and press ONE TOUCH DUBBING on the remote.

The recorder rewinds the tape in the digital video camera and then starts recording the tape contents from the beginning.

When playback of the tape stops, One Touch Dubbing ends automatically.

To stop during recording

Press ■ STOP.

Note that it may take a few seconds for the recorder to stop recording.

Hint

You can also perform One Touch Dubbing when you select "DV/D8 One Touch Dubbing" and press ENTER in step 15 of "Dubbing From a DV/D8 Format Tape to a DVD" on page 89. Follow the instructions appearing on the TV screen.


Settings and Adjustments

Using the Setup Displays

By using the setup displays, you can make various adjustments to items such as picture and sound, as well as select a language for the subtitles. The setup displays are used in the following way.


Note

Playback settings stored on the disc take priority over the setup display settings, and not all of the functions described may work.




1 Press SYSTEM MENU while the recorder is in stop mode.


The System Menu appears.



2 Select "Setup," and press ENTER. The "Setup" display appears.




3 Select "Tuner Preset," "Clock Set," "Video," "Audio," "Features," "Options," or "Easy Setup," and press ENTER. The selected setup display appears. Example: "Video" setup




4 Select the item you want to set up, and press ENTER.

Available options for the item appear. Example: "TV Type"




Some items display a dialog box that requires additional settings. Example: When "Parental" in "Options" setup is selected.



5 Select an option, and press ENTER.

The currently selected option is displayed next to the setup item. Example: When "16:9" is set.



To return to the previous display Press ◀ RETURN.

To turn off the display Press SYSTEM MENU.


Antenna Reception Setting (Tuner Preset)

The "Tuner Preset" setup allows you to make tuner settings for the recorder.

1 Press SYSTEM MENU while the recorder is in stop mode.

2 Select "Setup," and press ENTER.

3 Select "Tuner Preset," and press ENTER. The "Tuner Preset" setup appears with the following options.




Note

You cannot preset channels for a connected cable box or satellite receiver.

Auto Preset

Automatically presets the receivable channels. The recorder can receive VHF channels 2 to 13, UHF channels 14 to 69, and unscrambled CATV channels 1 to 125. First, we recommend that you preset the receivable channels in your area using automatic presetting methods.

1 Select "Antenna/Cable," and press ENTER.




"Antenna": Presets VHF and UHF channels. "Cable": Presets cable TV channels.

2 Select an option, and press ENTER.

3 Select "Auto Preset," and press ENTER.


All receivable channels are preset in numerical sequence.



Manual Set

Presets or disables channels manually. If some channels could not be set using the "Auto Preset" or "Easy Setup" function, you can set them manually.

1 Select "Antenna/Cable," and press ENTER.




"Antenna": Presets VHF and UHF channels. "Cable": Presets cable TV channels.

2 Select an option, and press ENTER.

3 Select "Manual Set," and press ENTER.

4 Select the channel you want to preset/disable using ▲/▼ or CH +/-, and press ENTER.



5 Select "Add" or "Erase" using ▲/▼, and press ENTER. To cancel the setting, select "Exit" and press ENTER.

6 To preset or disable another channel, repeat steps 4 and 5.


Clock Setting (Clock Set)

The "Clock Set" setup allows you to make clock settings for the recorder.

1 Press SYSTEM MENU while the recorder is in stop mode.

2 Select "Setup," and press ENTER.


3 Select "Clock Set," and press ENTER. The "Clock Set" setup appears with the following options.



Auto (Auto Clock Set)

Turns on the Auto Clock Set function when a channel in your local area broadcasts a time signal.

1 Select "Auto," and press ENTER.




2 Select "Clock Set CH," "Time Zone," or "Daylight Saving" and press ENTER.

3 Adjust these settings by pressing ▲/▼ and ENTER.

◆ Clock Set CH

Select a channel that carries a time signal using ▲/▼. Use this option if you know of a channel that carries a time signal. Most PBS member stations broadcast a time signal. For the fastest response, select your local PBS station. Leave the setting at "Auto" to have the recorder

automatically search for a channel that carries a time signal.



◆ Time Zone

Select the time zone for your area, or select "Auto" to have the recorder automatically set your time zone.

The options are:
Auto ↔ Atlantic ↔ Eastern ↔ Central
↔ Mountain ↔ Pacific ↔ Alaska ↔
Hawaii ↔ Auto


◆ Daylight Saving

Select "On" or "Off" (standard time), or select "Auto" to have the recorder automatically set the daylight saving time.

Manual

If the Auto Clock Set function did not set the clock correctly for your local area, set the clock manually.

- 1 Select "Manual," and press ENTER.




- 2 Press $\uparrow/\downarrow$ to set the month, and press $\rightarrow$. Set the day, year, hour, minutes, and AM/PM in sequence. Press $\leftarrow/\rightarrow$ to select the item to be set, then press $\uparrow/\downarrow$ to set the item. The day of the week is set automatically.
- 3 Press ENTER to start the clock.

Video Settings (Video)

The "Video" setup allows you to adjust items related to the image, such as size and color. Choose the settings according to the type of TV, tuner, or decoder connected to the recorder.

- 1 Press **SYSTEM MENU** while the recorder is in stop mode.
- 2 Select "Setup," and press ENTER.
- 3 Select "Video," and press ENTER.

The "Video" setup appears with the following options. The default settings are underlined.



TV Type

Selects the aspect ratio of the connected TV (4:3 standard or wide).

16:9	Select this when connecting to a wide-screen TV or TV with a wide mode function.
4:3 Letter Box	Select this when connecting to a 4:3 screen TV. Displays a wide picture with bands on the upper and lower portions of the screen.
4:3 Pan Scan	Select this when connecting to a 4:3 screen TV. Automatically displays a wide picture on the entire screen and cuts off the portions that do not fit.

Settings and Adjustments

16:9



4:3 Letter Box



4:3 Pan Scan



Note

Depending on the disc, "4:3 Letter Box" may be selected automatically instead of "4:3 Pan Scan" or vice versa.

Black Level

Selects the black level (setup level) for the video signals output from the LINE OUT jacks (page 15).

This setting is not effective when the PROGRESSIVE indicator lights up in the front panel and the recorder outputs progressive signals.

On	Raises the standard black level. Select this when the picture appears too dark.
Off	Sets the black level of the output signal to the standard level.

Picture Control

You can adjust the video signal of DVD or VIDEO CD (with PBC function off) from the recorder to obtain the picture quality you want. Select the setting that best suits the program you are watching.

Dynamic 1	Produces a bold dynamic picture by increasing the picture contrast and the color intensity.
Dynamic 2	Produces a more dynamic picture than Dynamic 1 by further increasing the picture contrast and the color intensity.

Standard	Off Displays a standard picture.
Cinema 1	White colors become brighter and black colors become richer, and the color contrast is increased.
Cinema 2	Enhances details in dark areas by increasing the black level.
Personal	Adjusts "Contrast," "Brightness," "Color," and "Hue" using $\uparrow/\downarrow$.


Hint

When you watch a movie, "Cinema 1" or "Cinema 2" is recommended.

Progressive

If your TV accepts progressive (480p) format signals, you will enjoy accurate color reproduction and high quality image.

- 1 Select "Progressive," and press ENTER.
- 2 Select "On," and press ENTER.
- 3 Follow the instructions appearing on the TV screen.



- 1 Ensure your TV is (480p) Progressive Scan capable.
- 2 Connect with Component Video Output jacks (red/green/blue connections). See "If your TV has component video input jacks" on page 16.
- 3 Select [OK] to test your video signal.
- 4 If video signal appears OK, video connection is complete.
- 4 Select "OK" and press ENTER. The PROGRESSIVE indicator on the recorder lights up. If picture is distorted, press $\leftarrow$ RETURN. Check the connection (page 16).

→ continued 95 96

Hint

The "Progressive" setting can be canceled by pressing **PAUSE** on the recorder continuously for five seconds or more, or selecting "Off" in step 2.

Note


If you select progressive signals when you connect the recorder to a TV that cannot accept the signal in progressive format, the image quality will deteriorate. In this case, set "Progressive" to "Off."

Audio Settings (Audio)

The "Audio" setup allows you to adjust the sound according to the playback and connection conditions.

- 1 Press **SYSTEM MENU** while the recorder is in stop mode.
- 2 Select "Setup," and press ENTER.
- 3 Select "Audio," and press ENTER.

The "Audio" setup appears with the following options. The default settings are underlined.



Tuner Audio

Selects the sound to be recorded.

Main	Records only the main sound.
SAP	Records only the SAP (Second Audio Program) sound.

Note

If no SAP sound is received, the main sound is recorded regardless of the setting.


Digital Out

The following setup items switch the method of outputting audio signals when you connect a component such as an amplifier (receiver) with a digital input jack.

For connection details, see "Connecting to Your AV Amplifier (Receiver)" on page 17.

Press ENTER, and select "Dolby Digital Output" or "DTS."

Settings and Adjustments



If you connect a component that does not accept the selected audio signal, a loud noise (or no sound) will come out from the speakers, and may affect your ears or cause speaker damage.

- Dolby Digital Output (DVDs only)
Selects the type of Dolby Digital signal.

D-PCM	Select this when the recorder is connected to an audio component lacking a built-in Dolby Digital decoder. You can select whether the signals conform to Dolby Surround (Pro Logic) or not by making adjustments to the "Downmix" item in "Audio" setup (page 98).
Dolby Digital	Select this when the recorder is connected to an audio component with a built-in Dolby Digital decoder.

- DTS (DVD VIDEOS only)

Selects whether or not to output DTS signals.

On	Select this when the recorder is connected to an audio component with a built-in DTS decoder.
Off	Select this when the recorder is connected to an audio component without a built-in DTS decoder.

Downmix (DVDs only)

Switches the method for mixing down to two channels when you play a DVD which has rear sound elements (channels) or is recorded in Dolby Digital format. For details on the rear signal components, see "Connecting to audio L/R jacks" on page 18. This function affects the output of the following jacks:

- LINE OUT (AUDIO L/R) jacks
- AUDIO OUT L/R jacks
- DIGITAL AUDIO OUT (OPTICAL or COAXIAL) jack when "Dolby Digital Output" is set to "D-PCM" (page 97).

Dolby Surround	Normally select this position. Multi-channel audio signals are output to two channels for enjoying surround sounds.
Normal	Multi-channel audio signals are downmixed to two channels for use with your stereo.

Audio DRC (Dynamic Range Control) (DVDs only)

Makes the sound clear when the volume is turned down when playing a DVD that conforms to "Audio DRC." This affects the output from the following jacks:

- LINE OUT (AUDIO L/R) jacks
- AUDIO OUT L/R jacks
- DIGITAL AUDIO OUT (OPTICAL or COAXIAL) jack only when "Dolby Digital Output" is set to "D-PCM" (page 97).

Standard	Normally select this position.
Wide Range	Gives you the feeling of being at a live performance.

Scan Audio (DVDs only)

On	Outputs audio signals during FF1 fast-forward of a DVD disc with Dolby Digital soundtracks.
Off	No sound is output during FF1 fast-forward.

→ continued 97 98

Note

Sound will be interrupted during Scan Audio.

DV Audio Input

Stereo 1	Records original sound only. Normally select this when dubbing a DV format tape.
Stereo 2	Records additional audio only.
Mix	Records both original and additional sounds.

Note

Select "Stereo 2" or "Mix" if you have added a second audio channel when recording with your digital video camera.

Line Audio Input

When recording from equipment connected to the LINE 1 IN or LINE 2 IN jack to a DVD disc in this recorder, select line input audio.

Stereo	Records stereo sound only. Select this for discs other than DVD-RWs (VR mode).
Main/Sub	Records the two different soundtracks on DVD-RWs (VR mode). You can select either soundtrack when playing back the disc.

Hint


Audio selected with the connected equipment is recorded on a disc other than DVD-RWs (VR mode).

Recording and VCR Settings (Features)

The "Features" setup allows you to change the tape length, auto play and auto repeat settings.

- 1 Press **SYSTEM MENU** while the recorder is in stop mode.
- 2 Select **"Setup,"** and press **ENTER**.
- 3 Select **"Features,"** and press **ENTER**.

The "Features" setup appears with the following options. The default settings are underlined.



DVD Auto Chapter

Automatically divides a recording (a title) into chapters by inserting chapter markings at specified intervals. The markings are inserted while the recording is being made.

Off	No chapter mark is inserted.
<u>5 Min</u>	Inserts chapter marks at approximately 5 minute intervals.
15 Min	Inserts chapter marks at approximately 15 minute intervals.

Note

Actual intervals may differ depending on the size of the recording. The selected setting should be regarded as an approximate chapter interval.

Format DVD (DVD-RWs only)

Selects the format for an unused DVD-RW, when first inserted.

<u>VR</u>	Automatically formats the disc in VR mode.
Video	Automatically formats the disc in Video mode.

VCR Function

Press **ENTER** and select "Tape Length," "Auto Play," or "Auto Repeat."

◆ Tape Length

<u>T120</u>	For T-120 or shorter length tapes.
T160	For T-160 length tapes.
T180	For T-180 or longer length tapes.

◆ Auto Play

<u>On</u>	Starts playback automatically, when you insert a tape with its safety tab removed.
Off	Turns off Auto Play. You need to press ▶▶ PLAY to start playback, even if you insert a tape with its safety tab removed.

◆ Auto Repeat

<u>On</u>	Plays back a tape repeatedly. The VCR rewinds the tape to the beginning and restarts playback automatically.
<u>Off</u>	Turns off Auto Repeat.

Synchro Recording


<u>to DVD</u>	Sets the recorder to record programs from connected equipment that has a timer function (such as a satellite tuner) to a DVD disc.
to Video	Sets the recorder to record programs from connected equipment that has a timer function (such as a satellite tuner) to a VHS tape.

Language, Parental Control Settings/Factory Settings (Options)

The "Options" setup allows you to set up other operational settings.

- 1 Press **SYSTEM MENU** while the recorder is in stop mode.
- 2 Select **"Setup,"** and press **ENTER**.
- 3 Select **"Options,"** and press **ENTER**.

The "Options" setup appears with the following options. The default settings are underlined.



Language

◆ OSD (On-Screen Display)

Switches the display language on the screen.

◆ Disc Menu (DVD VIDEOS only)

Switches the language for the DVD menu.

◆ Audio (DVD VIDEOS only)

Switches the language of the soundtrack. When you select "Original," the language given priority in the disc is selected.

◆ Subtitle (DVD VIDEOS only)

Switches the language of the subtitles recorded on the disc.

When you select "Auto," the subtitle language changes according to the language you selected for the soundtrack. See page 118 for an explanation of the language abbreviations.

Note


If you select a language in "Disc Menu," "Subtitle," or "Audio" that is not recorded on the DVD VIDEO, one of the recorded languages will be automatically selected.

→continued 99 100


Parental (DVD VIDEOS only)

Playback of some DVD VIDEOS can be limited according to a predetermined level, such as the age of the users. Scenes may be blocked or replaced with different scenes.


- 1 After step 3 above, select **"Parental,"** and press **ENTER**.
 - If you have not entered a password, the display for registering a new password appears. Enter a 4-digit password using the number buttons.




The display for confirming the password appears. Re-enter the password.



- When you have already registered a password, the display for entering the password appears. Enter a 4-digit password using the number buttons.



- 2 Select **"Rating Level,"** and press **ENTER**. The selection items for "Rating Level" are displayed.



The lower the value, the stricter the limitation.

- 3 Select the level, and press **ENTER**. The Parental setting is complete.

- To cancel the Parental setting for the disc, set "Rating Level" to "Off" in step 3.
- To change the password, select "Change Password" in step 2, and press **ENTER**. When the display for registering a password appears, enter a new four-digit password using the number buttons.

Notes

- If you forget your password, select "Factory Setting" of "Options" in the "Setup" display.
- Playback of discs without the Parental Control function cannot be limited on this recorder.
- Depending on the disc, you may be asked to change the Parental Control level while playing the disc. In this case, enter your password, then change the level.

Front Display

Adjusts the lighting of the front panel display.

<u>Auto</u>	Adjusts to low lighting when power is off.
Bright	Maintains bright lighting when power is off.
Dimmer	Maintains low lighting regardless of whether power is on or off.

Command Mode

Changes the command mode of this recorder if other DVD equipment is assigned the same command mode. Be sure to match the COMMAND MODE switch on the remote to the setting made here. For details, see "If you have a Sony DVD player or more than one Sony DVD recorder" on page 24.

DVD 1	Select this if the default command mode conflicts with other DVD equipment.
DVD 2	Select this if the default command mode conflicts with other DVD equipment.
<u>DVD 3</u>	The default command mode of the recorder.

Factory Setting


Allows you to return the setup settings to their default settings. Note that all of your previous settings will be lost.

- 1 After step 3 above, select **"Factory Setting,"** and press **ENTER**.
- 2 Select **"Start,"** and press **ENTER**. The setup settings return to their default settings.
- 3 Press **ENTER** when "Finish" appears. The power automatically turns off and then on again, and the recorder is reset to the factory settings. When the "Easy Setup" display appears, follow the instructions for Easy Setup (page 22) from step 4.

Easy Setup (Resetting the Recorder)

Select this to run the Easy Setup program.

- 1 Press **SYSTEM MENU** while the recorder is in stop mode.
- 2 Select **"Setup,"** and press **ENTER**.
- 3 Select **"Easy Setup,"** and press **ENTER**.



- 4 Select **"Start,"** and press **ENTER**.
- 5 Follow the instructions for Easy Setup (page 22) from step 5.

→continued 101 102

Additional Information

Troubleshooting

If you experience any of the following difficulties while using the recorder, use this troubleshooting guide to help remedy the problem before requesting repairs. Should any problem persist, consult your nearest Sony dealer.

Power

The power does not turn on.

- ➔ Check that the AC power cord is connected securely.

Picture

There is no picture.

- ➔ Re-connect all connecting cords securely.
- ➔ The connecting cords are damaged.
- ➔ Check the connection to your TV (page 12).
- ➔ Switch the input selector on your TV (such as to "VIDEO") so that the signal from the recorder appears on the TV screen.

Picture noise appears.

- ➔ Check the connection to your TV (page 12) and switch the input selector on your TV so that the signal from the recorder appears on the TV screen.
- ➔ If the picture output signal from your recorder passes through your VCR to get to your TV, or if you are connected to a combination TV/VIDEO player, the copy-protection signal applied to some DVD programs could affect picture quality. If you still experience this problem even when you connect your recorder directly to your TV, try connecting your recorder to your TV's S VIDEO input.
- ➔ You have set the recorder to progressive format (the PROGRESSIVE indicator lights up) even though your TV cannot accept the progressive signal. In this case, set "Progressive" to "Off" in "Video" setup (page 96).
- ➔ Even if your TV is compatible with progressive format (480p) signals, the image may be affected when you set the recorder to progressive format. In this case, set "Progressive" to "Off" in "Video" setup (page 96).

TV program reception does not fill the screen.

- ➔ Set the channel manually in "Tuner Preset" setup (page 93).
- ➔ Select the correct source using the INPUT SELECT button, or select a channel of any TV program using the CH +/- buttons.

TV program pictures are distorted.

- ➔ Reorient the TV antenna.
- ➔ Adjust the picture (see the TV's instruction manual).
- ➔ Place the recorder and TV farther apart.
- ➔ Place the TV and any bunched antenna cables farther apart.

TV channels cannot be changed.

- ➔ The channel is disabled (page 94).
- ➔ A timer recording started, which cause the channels to change.

The picture from equipment connected to the recorder's input jack does not appear on the screen.

- ➔ If the equipment is connected to the LINE 1 IN jack, select "LINE1" in the front panel display by pressing INPUT SELECT.
- ➔ If the equipment is connected to the LINE 2 IN jacks, select "LINE2" in the front panel display by pressing INPUT SELECT.

The playback picture or TV program from the equipment connected through the recorder is distorted.

- ➔ If the playback picture output from a DVD player, VCR, or tuner goes through your recorder before reaching your TV, the copy-protection signal applied to some programs could affect picture quality. Disconnect the playback equipment in question and connect it directly to your TV.

The picture does not fill the screen.

- ➔ Set "TV Type" in "Video" setup to fit the aspect ratio of your TV (page 95).

The picture does not fill the screen, even though the aspect ratio is set in "TV Type" in "Video" setup.

- ➔ The aspect ratio of the disc is fixed on your DVD.

Additional Information

Sound

There is no sound.

- ➔ Re-connect all connections securely.
- ➔ The connecting cord is damaged.
- ➔ The input source setting on the amplifier or the connection to the amplifier is incorrect.
- ➔ The recorder is in reverse play, fast-forward, slow motion, or pause mode.
- ➔ If the audio signal does not come through the DIGITAL AUDIO OUT (OPTICAL or COAXIAL) jack, check the "Audio" setup settings (page 97).

Sound is noisy.

- ➔ When playing a CD with DTS soundtracks, noise will come from the LINE OUT (AUDIO L/R) or AUDIO OUT L/R jacks (page 35).

The sound volume is low.

- ➔ The sound volume is low on some DVDs. The sound volume may improve if you set "Audio DRC" in "Audio" setup to "Wide Range" (page 98).

An alternate audio track cannot be recorded or played.

- ➔ Second Audio Program (SAP) is not available for all programs. The program you are recording does not have a second audio program.
- ➔ You have set "Tuner Audio" in "Audio" setup to "Main" (page 97). Select "SAP" to record alternate audio programs.
- ➔ If you have connected an AV amplifier to the DIGITAL AUDIO OUT (OPTICAL or COAXIAL) jack and want to change the audio track for a DVD-RW (VR mode) during playback, set "Dolby Digital Output" in "Audio" setup to "D-PCM" (page 97).
- ➔ When recording to a disc other than DVD-RWs (VR mode), set "Line Audio Input" in "Audio" setup to "Stereo."

DVD Playback

The disc does not play.

- ➔ The disc is upside down. Insert the disc with the labeled side facing up.
- ➔ The disc is not correctly inserted.
- ➔ Moisture has condensed inside the recorder. Remove the disc and leave the recorder turned on for about half an hour until the moisture evaporates.
- ➔ If the disc was recorded on another recorder, the recorder cannot play the disc if it was not finalized (page 86).

The disc does not start playback from the beginning.

- ➔ Resume play was activated (page 36).
- ➔ You have inserted a disc whose Title menu or DVD menu automatically appears on the TV screen when it is first inserted. Use the menu to start playback.

The recorder starts playing the disc automatically.

- ➔ The DVD VIDEO features an auto playback function.

Playback stops automatically.

- ➔ If the disc has an auto pause signal, the recorder stops playback at the auto pause signal.

Some functions such as Stop, Search, or Slow-motion Play cannot be performed.

- ➔ Depending on the disc, you may not be able to do some of the operations above. See the instruction manual supplied with the disc.
- ➔ While the recorder is reading disc information, playback operations will not work.

The language for the soundtrack cannot be changed.

- ➔ Multilingual tracks are not recorded on the disc being played.
- ➔ The DVD VIDEO prohibits the changing of the language for the soundtrack.
- ➔ Try changing the language using the DVD VIDEO's menu.

The subtitle language cannot be changed or turned off.

- ➔ Multilingual subtitles are not recorded on the DVD VIDEO.
- ➔ The DVD VIDEO prohibits changing of the subtitles.
- ➔ Try changing the subtitle using the DVD VIDEO's menu.
- ➔ The subtitles cannot be changed for the titles recorded on this recorder.

The angles cannot be changed.

- ➔ Multi-angles are not recorded on the DVD VIDEO being played.
- ➔ You are trying to change the angles when "⏮" does not appear in the front panel display (page 33).
- ➔ The DVD VIDEO prohibits changing angles.
- ➔ Try changing the angle using the DVD VIDEO's menu.
- ➔ The angles cannot be changed for the titles recorded on this recorder.

The MP3 audio track cannot be played.

- ➔ The DATA CD is not recorded in the MP3 format that conforms to ISO9660 Level 1/Level 2.
- ➔ The MP3 audio track does not have the extension ".MP3."
- ➔ The data is not formatted in MP3 even though it has the extension ".MP3."
- ➔ The data is not MPEG1 Audio Layer 3 data.
- ➔ The recorder cannot play audio tracks in MP3PRO format.

The JPEG image file cannot be played.

- ➔ The DATA CD is not recorded in a JPEG format that conforms to ISO9660 Level 1/Level 2.
- ➔ The JPEG image file does not have the extension ".JPG" or ".JPEG."
- ➔ The data is not formatted in JPEG even though it has the extension ".JPG" or ".JPEG."
- ➔ The length or width of the image is more than 4,720 dots.

The title of the MP3 audio album/track or JPEG image folder/file is not correctly displayed.

- ➔ The recorder can only display numbers and alphabet. Other characters are displayed as asterisks.

DVD Recording/Timer recording/Editing

The channel cannot be changed from the channel you are recording.

- ➔ Set the TV's input source to "TV."

Recording does not start immediately after ● REC is pressed.

- ➔ Operate the recorder only after "LOAD," "FORMAT," or "INF WRITE" disappears from the front panel display.

Nothing was recorded even though the timer setting is set correctly.

- ➔ There was a power failure during recording.
- ➔ Disconnect the AC power cord from the AC outlet, and connect it again.
- ➔ The program contains copy protection signals that restrict copying.
- ➔ The program that starts first has priority and the second program starts recording only after the first program has finished. If the programs start at the same time, the program listed first in the menu has priority (page 49).
- ➔ There is no DVD inserted in the recorder.
- ➔ There is not enough disc space for the recording.

Recording does not stop immediately after ■ STOP is pressed.

- ➔ It will take a few seconds for the recorder to input disc data before recording can stop.

Timer recording is not complete or did not start from the beginning.

- ➔ There was a power failure during recording. If the power recovers when there is a timer recording, the recorder resumes recording. The clock is automatically set by EDS, but it is reset during a power failure when the EDS signal cannot be received (page 94).
- ➔ The program that starts first has priority and the second program starts recording only after the first program has finished. If the programs start at the same time, the program listed first in the menu has priority (page 49).
- ➔ There is not enough disc space for the recording.

Additional Information

The Ⓢ indicator flashes after timer recording is set.

- ➔ Insert a recordable disc (page 28).
- ➔ Insert a disc with enough space for the recording.
- ➔ The disc has 99 or more titles, which prevents further recording.
- ➔ The disc is protected (page 66).

The SYNCHRO REC indicator flashes after Synchro-Recording is set.

- ➔ Insert a recordable disc (page 28).
- ➔ Insert a disc with enough space for the recording.
- ➔ The disc has 99 or more titles, which prevents further recording.
- ➔ The disc is protected (page 66).

Contents previously recorded were erased.

- ➔ Data that has been recorded on a DVD with a PC will be erased from the disc when the disc is inserted.

VCR Playback

The playback picture does not appear on the TV screen.

- ➔ Make sure the TV is set to the channel for the VCR. If a monitor is used, set it to video input.

The picture is not clear.

- ➔ Adjust the tracking by the TRACKING +/- buttons.
- ➔ The video heads are dirty (see page 108). Clean the video heads using a Sony video head cleaning cassette. If a Sony cleaning cassette is not available in your area, have the heads cleaned at your nearest Sony dealer (a standard service fee will be charged). Do not use a commercially available liquid type cleaning cassette, as it may damage the video heads.
- ➔ The video heads may have to be replaced. Consult your local Sony dealer for more information.
- ➔ The tape is defective.

The picture rolls vertically during picture search.

- ➔ Adjust the vertical hold control on the TV or monitor.

The picture has no sound.

- ➔ The tape is defective.
- ➔ Check the audio cord connection.

A tape cannot be inserted.

- ➔ Check that a tape is not already in the tape compartment.

VCR Recording

The channel cannot be changed from the one you are recording.

- ➔ Set the TV's input source to "TV."

No TV program appears on the TV screen.

- ➔ Make sure the TV is set to the channel for the VCR. If a monitor is used, set it to video input.
- ➔ Select the correct source with the CH +/- or INPUT SELECT buttons. Select a channel number when recording TV programs; select "LINE1" or "LINE2" when recording from other equipment.

TV reception is poor.

- ➔ Adjust the TV antenna.

The tape starts playing as soon as it is inserted.

- ➔ The safety tab has been removed. To record on this tape, cover the tab hole.

The tape is ejected when ● REC is pressed.

- ➔ Check that the safety tab has not been removed.

Nothing happens when ● REC is pressed.

- ➔ Make sure the tape is not at its end.

VCR Timer recording

The timer does not operate.

- ➔ Check that the clock is set.
- ➔ Make sure a tape has been inserted.
- ➔ Check that the safety tab has not been removed.
- ➔ Make sure the tape is not at its end.
- ➔ Make sure a program has been set for timer recording.
- ➔ Make sure the timer settings are set for a future time.
- ➔ Check that the cable box is turned on.
- ➔ "----" appears in the front panel display if the recorder is disconnected from the wall outlet for more than one minute. Reset the clock and timer.

➔ continued 103 104

➔ continued 105 106

- ➔ Turn the power off and unplug the AC power cord.
- ➔ The program that starts first has priority and the second program starts recording only after the first program has finished. If the programs start at the same time, the program listed first in the menu has priority (page 77).

The  indicator flashes after timer recording is set.

- ➔ Check that the safety tab has not been removed.

The SYNCHRO REC indicator flashes after Synchro-Recording is set.

- ➔ Check that the safety tab has not been removed.

Display

Menus or displays do not appear on the screen.

- ➔ While the recorder is reading disc information, the System Menu, TOOLS menu, or information display will not appear.

"- - -" appears in the front panel display.

- ➔ Set the clock again (page 94).

The  indicator is flashing.

- ➔ The disc does not have enough space.
- ➔ Insert a recordable disc or a tape with its safety tab in place inside the recorder.

Remote control

The remote does not function.

- ➔ Batteries are weak.
- ➔ The remote is too far from the recorder.
- ➔ The remote's manufacturer code returned to the default setting when you replaced the batteries. Reset the code (page 19).
- ➔ Turn on the recorder.
- ➔ The remote is not pointed at the remote sensor on the recorder.
- ➔ Different command modes are set for the recorder and remote. Set the same command mode (page 24).
- ➔ Slide the TV/DVD-VIDEO switch to DVD-VIDEO (page 20).

Other Sony equipment responds to the remote.

- ➔ The same command mode is set for both the Sony DVD equipment. Set a different command mode for the recorder (page 24).

Others

The recorder does not operate properly.

- ➔ Restart the recorder. Press down  on the recorder for more than ten seconds until "SONY DVD" appears in the front panel display.
- ➔ When static electricity, etc., causes the recorder to operate abnormally, turn off the recorder and wait until the clock appears in the front panel display. Then, unplug the recorder and after leaving it off for a while, plug it in again.

The disc tray does not open after you press  OPEN/CLOSE.

- ➔ It may take a few seconds for the disc tray to open after you have recorded or edited a disc. This is because the recorder is adding disc data to the disc.

The disc tray does not open and "TRAY LOCKED" appears in the front panel display.

- ➔ Contact your Sony dealer or local authorized Sony service facility.

"CAN NOT RECORD BECAUSE OF HIGH TEMP." appears in the front panel display.

- ➔ Check that the vent on the rear of the recorder is not blocked. Then, turn off the recorder, wait until the clock appears in the front panel display, and disconnect the AC power cord. Leave the recorder off for a while, then re-connect the power cord, and press  on the recorder.

"CHILD LOCK" appears in the front panel display.

- ➔ The recorder is locked. Cancel the Child Lock (page 37).

Control by AV mouse is not possible.

- ➔ Some satellite receivers may not support AV mouse.

Additional Information

Notes About This Recorder

On adjusting volume

Do not turn up the volume while listening to a section with very low level inputs or no audio signals. If you do, the speakers may be damaged when a peak level section is played.

On cleaning

Clean the cabinet, panel, and controls with a soft cloth slightly moistened with a mild detergent solution. Do not use any type of abrasive pad, scouring powder or solvent such as alcohol or benzine.

On cleaning discs

Do not use a commercially available cleaning disc. It may cause a malfunction.

Notes about the discs

- To keep the disc clean, handle the disc by its edge. Do not touch the surface. Dust, fingerprints, or scratches on the disc may cause it to malfunction.



- Do not expose the disc to direct sunlight or heat sources such as hot air ducts, or leave it in a car parked in direct sunlight as the temperature may rise considerably inside the car.
- After playing, store the disc in its case.
- Clean the disc with a cleaning cloth. Wipe the disc from the center out.



- Do not use solvents such as benzine, thinner, commercially available cleaners, or anti-static spray intended for vinyl LPs.
- Do not use the following discs.
 - A disc that has a non-standard shape (e.g., card, heart).
 - A disc with a label or sticker on it.
 - A disc that has cellophane tape or sticker adhesive on it.

107 108

About i.LINK

The DV IN jack on this recorder is an i.LINK-compliant DV IN jack. This section describes the i.LINK standard and its features.

What is i.LINK?

i.LINK is a digital serial interface for handling digital video, digital audio and other data in two directions between equipment having the i.LINK jack, and for controlling other equipment. i.LINK-compatible pieces of equipment can be connected by a single i.LINK cable. Possible applications are operations and data transactions with various digital AV equipment. When two or more i.LINK-compatible equipment are connected to this recorder in a daisy chain, operations and data transactions are possible with not only the equipment that this recorder is connected to but also with other devices via the directly connected equipment.

Note, however, that the method of operation sometimes varies according to the characteristics and specifications of the equipment to be connected, and that operations and data transactions are sometimes not possible on some connected equipment.

Note

Normally, only one piece of equipment can be connected to this recorder by the i.LINK cable (DV connecting cable). When connecting this recorder to i.LINK-compatible equipment having two or more i.LINK jacks (DV jacks), see the instruction manual of the equipment to be connected.

About the name "i.LINK"

i.LINK is a more familiar term for IEEE 1394 data transport bus proposed by SONY, and is a trademark approved by many corporations. IEEE 1394 is an international standard standardized by the Institute of Electrical and Electronics Engineers.

i.LINK baud rate

i.LINK's maximum baud rate varies according to the equipment. Three maximum baud rates are defined:

- S100 (approx. 100 Mbps*)
- S200 (approx. 200 Mbps)
- S400 (approx. 400 Mbps)

The baud rate is listed under "Specifications" in the instruction manual of each equipment. It is also indicated near the i.LINK jack on some equipment.

The maximum baud rate of equipment on which it is not indicated such as this unit is "S100."

When units are connected to equipment having a different maximum baud rate, the baud rate sometimes differs from the indicated baud rate.

* What is Mbps?

Mbps stands for megabits per second, or the amount of data that can be sent or received in one second. For example, a baud rate of 100 Mbps means that 100 megabits of data can be sent in one second.

i.LINK functions on this recorder

For details on how to dub when this recorder is connected to other video equipment having DV jacks, see page 88.

The DV jack on this recorder can only input DVC-SD signals. It cannot output signals. The DV jack will not accept MICRO MV signals from equipment such as a MICRO MV digital video camera with an i.LINK jack.

For further precautions, see the notes on page 88. For details on precautions when connecting this recorder, also see the instruction manuals for the equipment to be connected.

Required i.LINK cable

Use the Sony i.LINK 4-pin-to-4-pin cable (during DV/D8 dubbing).

i.LINK and  are trademarks.


Additional Information

Guide to Parts and Controls

For more information, see the pages in parentheses.

Front panel

Buttons on the recorder have the same function as the buttons on the remote if they have the same or similar names.




- | | |
|---|---|
| 1 I/⏻ (on/standby) button (22) | 10 SELECT DVD/VIDEO buttons (32, 46, 67, 74) |
| 2 Disc tray (32, 46, 89) | 11 □ (remote sensor) (19) |
| 3 △ (open/close) button (32, 46, 89) | 12 Front panel display (44, 71) |
| 4 DVD → button (83) | 13 SYNCHRO REC indicator (50, 78) |
| ← VIDEO button (82) | 14 PROGRESSIVE indicator (16, 96) |
| 5 Tape compartment (67, 74) | 15 CHANNEL/TRACKING +/- buttons* (20, 46, 68, 74) |
| 6 △ (eject) button (67) | 16 DV IN jack (88) |
| 7 ● REC (record) button (46, 74) | 17 LINE 2 IN (S VIDEO/VIDEO/AUDIO L/R) jacks (26) |
| 8 ◀▶ (rewind/fast-forward) buttons (35) | |
| 9 ▷ (play) button* (32, 67) | |
| ■ (pause) button (33, 46, 69, 74) | |
| ■ (stop) button (32, 46, 67, 74) | |

* ▷ and CHANNEL +/- buttons have a tactile dot. Use the tactile dot as a reference.

Remote

For DVD functions



Buttons with an orange dot next to them can be used with your TV when the TV/DVD-VIDEO switch is set to TV.


- | |
|--|
| 1 TV/DVD-VIDEO switch (20) |
| 2 △ OPEN/CLOSE button (32, 46, 89) |
| 3 DVD button (32, 46) |
| 4 Number buttons* (20, 33) |
| SET button (20) |
| 5 CLEAR button (39) |
| 6 AUDIO button* (33) |
| SUBTITLE button (33) |
| 7 ORIGINAL/PLAYLIST button (37, 56) |
| 8 DISPLAY button (43) |
| TIME/TEXT button (44) |
| 9 TOP MENU button (32) |
| 10 ↑/↓/←/→/ENTER button (22) |
| 11 ↺ RETURN button (22) |
| 12 ◀◀ PREV (previous) ▶▶ NEXT buttons (33) |
| 13 ◀◀◀/▶▶▶ (search) buttons (33) |
| 14 ZOOM button (33) |
| 15 ● REC (record) button (46) |
| 16 REC MODE button (46, 89) |
| 17 SYNCHRO REC button (50) |
| 18 ANGLE button (33) |
| 19 REPEAT button (33) |
| 20 MARKER button (39) |
| 21 SEARCH button (39) |

* Number 5 and AUDIO buttons have a tactile dot. Use the tactile dot as a reference.

Additional Information

112


→ continued 113



- | |
|---|
| 22 I/⏻ (on/standby) button (22) |
| 23 CH (channel) +/- buttons* (20, 46) |
| 24 VOL (volume) +/- buttons (20) |
| 25 TV/VIDEO button (20) |
| 26 INPUT SELECT button (46, 53, 89) |
| 27 SUR (surround) button (33) |
| 28 SYSTEM MENU button (10) |
| TITLE LIST button (37, 56) |
| TIMER button (48) |
| 29 MENU button (32) |
| 30 TOOLS button (38) |
| 31 ◀◀ REPLAY/▶▶ ADVANCE buttons (33) |
| 32 ▷ PLAY button* (32) |
| 33 ■ STOP button (32, 46) |
| 34 ■ PAUSE button (46) |
| 35 CHAPTER MARK/CHAPTER MARK ERASE buttons (59) |
| 36 WIDE MODE button (20) |
| 37 ONE TOUCH DUBBING button (91) |
| 38 COMMAND MODE switch (DVD 1, 2, 3) (24) |

* CH + and ▷ PLAY buttons have a tactile dot. Use the tactile dot as a reference.

For VCR functions



- | |
|--|
| 1 TV/DVD-VIDEO switch (20) |
| 2 △ OPEN/CLOSE (eject) button (67) |
| 3 Number buttons* (20) |
| SET button (20) |
| 4 CLEAR button (67) |
| 5 AUDIO button* (72) |
| 6 DISPLAY button (71) |
| TIME/TEXT button (71) |
| 7 SYSTEM MENU button (10) |
| 8 ↺ RETURN button (22) |
| 9 ◀◀ PREV (previous) ▶▶ NEXT buttons (69) |
| 10 ◀◀◀/▶▶▶ (search) buttons (69) |
| 11 ● REC (record) button (74) |
| 12 REC MODE button (74) |
| 13 SYNCHRO REC button (78) |
| 14 I/⏻ (on/standby) button (22) |
| 15 VIDEO button (67, 74) |
| 16 CH (channel)/TRACKING +/- buttons* (20, 74, 68) |
| 17 VOL (volume) +/- buttons (20) |
| 18 TV/VIDEO button (20) |
| 19 INPUT SELECT button (74) |
| 20 TIMER button (76) |
| 21 ↑/↓/←/→/ENTER button (22) |
| 22 TOOLS button (70) |
| 23 ◀◀ REPLAY/▶▶ ADVANCE buttons (69) |
| 24 ▷ PLAY button* (67) |
| 25 ■ STOP button (67, 74) |
| 26 ■ PAUSE button (69, 74) |
| 27 WIDE MODE button (20) |
| 28 COMMAND MODE switch (DVD 1, 2, 3) (24) |


* Number 5, AUDIO, CH +, and ▷ PLAY buttons have a tactile dot. Use the tactile dot as a reference.

Additional Information

114


→ continued 115

Front panel display



- 1 DVD Playing/recording status
- 2 Disc type/recording format
- 3 Audio signal indicators
- 4 STEREO indicator (45, 73)
- 5 SAP (Second Audio Program) indicator (45, 73)
- 6 VIDEO Playing/recording status
- 7 Tape indicator
- 8 Timer indicator
- 9 Displays the following (44, 71):
 - Playing time/remaining time
 - Current title/chapter/track/index number
 - Recording time/recording mode
 - Clock
 - Channel
- 10 (angle) indicator (33)
- 11 Disc indicator

Rear panel



- 1 AUDIO OUT L/R jacks (17)
- 2 DIGITAL AUDIO OUT (COAXIAL/OPTICAL) jacks (17)
- 3 COMPONENT VIDEO OUT (Y, Pb, Pr) jacks (16)
- 4 S VIDEO OUT jack (15)
- 5 LINE 1 IN (VIDEO/AUDIO L/R) jacks (27)
- 6 LINE OUT (VIDEO/AUDIO L/R) jacks (15, 16)
- 7 VHF/UHF IN/OUT jacks (14)

Glossary

Chapter (page 38)

Sections of a picture or a music feature that are smaller than titles. A title is composed of several chapters. Depending on the disc, no chapters may be recorded.

Copy protection signals (page 46)

Copy restriction set by copyright owners, etc. These signals are included in some software or TV programs and restrict recording on this recorder.

Dolby Digital (page 97)

Digital audio compression technology developed by Dolby Laboratories. This technology conforms to multi-channel surround sound. The rear channel is stereo and there is a discrete subwoofer channel in this format. Dolby Digital provides the same discrete channels of high quality digital audio found in "Dolby Digital" theater surround sound systems. Good channel separation is realized because all of the channel data is recorded discretely, and little deterioration occurs because all channel data processing is digital.

DTS (page 97)

Digital audio compression technology by Digital Theater Systems, Inc. This technology conforms to multi-channel surround sound. The rear channel is stereo and there is a discrete subwoofer channel in this format. DTS provides the same discrete channels of high quality digital audio. Good channel separation is realized because all of the channel data is recorded discretely, and little deterioration occurs because all channel data processing is digital.

DVD+RW (page 28)

A DVD+RW (read "plus RW") is a recordable and rewritable disc. DVD+RWs use a recording format that is comparable to the DVD VIDEO format.

DVD-RW (page 28)

A DVD-RW is a recordable and rewritable disc that is the same size as a DVD VIDEO. The DVD-RW has two different modes: VR mode and Video mode. DVDs created in Video mode have the same format as a DVD VIDEO, while discs created in VR (Video Recording) mode allow the contents to be programmed or edited.

DVD+R (page 28)

A DVD+R (read "plus R") is a recordable disc that is the same size as a DVD VIDEO. Contents can be recorded only once to a DVD+R, and will have the same format as a DVD VIDEO.

DVD-R (page 28)

A DVD-R is a recordable disc that is the same size as a DVD VIDEO. Contents can be recorded only once to a DVD-R, and will have the same format as a DVD VIDEO.

DVD VIDEO (page 30)

A disc that contains up to eight hours of moving pictures on a disc the same diameter as a CD. The data capacity of a single-layer and single-sided DVD is 4.7 GB (Giga Byte), which is 7 times that of a CD. The data capacity of a double-layer and single-sided DVD is 8.5 GB, a single-layer and double-sided DVD is 9.4 GB, and double-layer and double-sided DVD is 17 GB. The picture data uses the MPEG 2 format, which is a worldwide standard of digital compression technology. The picture data is compressed to about 1/40 (average) of its original size. The DVD also uses a variable rate coding technology that changes the data to be allocated according to the status of the picture. Audio information is recorded in a multi-channel format, such as Dolby Digital, allowing you to enjoy a more real audio presence.

Furthermore, various advanced functions such as the multi-angle, multilingual, and Parental Control functions are provided on the DVD.

Additional information

→ continued 117

Additional information

Interface format

Interface format shows every other line of an image as a single "field" and is the standard method for displaying images on television. The even number field shows the even numbered lines of an image, and the odd numbered field shows the odd numbered lines of an image.

Original (page 55)

Titles actually recorded on a DVD-RW (VR mode). Erasing original titles frees up disc space.

Playlist (page 55)

Playback information created from the actual recordings on a DVD-RW (VR mode). A Playlist leaves the original titles as they are, and contains only the information needed to control playback. A Playlist title takes up very little disc space.

Progressive format (page 96)

Compared to the Interface format that alternately shows every other line of an image (field) to create one frame, the Progressive format shows the entire image at once as a single frame. This means that while the Interface format can show 30 frames/60 fields in one second, the Progressive format can show 60 frames in one second. The overall picture quality increases and still images, text, and horizontal lines appear sharper.

Title (page 38)

The longest section of a picture or music feature on a DVD, movie, etc., in video software, or the entire album in audio software.

Track (page 38)

Sections of a music feature on a CD (the length of a song).

DVD Audio/Subtitle Language

When you play a DVD VIDEO, the language of the selected audio track or subtitle is abbreviated as follows. See page 100 to change the audio track or subtitle.

Abbreviation	Language
ARA	Arabic
BUL	Bulgarian
CHI	Chinese
CRO	Croatian
CZE	Czech
DAN	Danish
DEU	German
ENG	English
ESP	Spanish
FIN	Finnish
FRA	French
GRE	Greek
HUN	Hungarian
IDN	Indonesian
IND	Hindi
ISL	Icelandic
ITA	Italian
IWR	Hebrew
JPN	Japanese
KOR	Korean
MAL	Malay
NLD	Dutch
NOR	Norwegian
POL	Polish
POR	Portuguese
RUS	Russian
SVE	Swedish
THA	Thai

Abbreviation	Language
TUR	Turkish
VIE	Vietnamese
ZAF	Afrikaans

Index

Words in quotations appear in the on-screen displays.

Numerics

16:9 23, 95
4:3 Letter Box 23, 95
4:3 Pan Scan 23, 95

A

“A-B Erase” 57
“Add” 63, 65
ADVANCE 34, 69
ANGLE 33
Antenna 14
AUDIO 33, 72
“Audio” 100
Audio cords 17
“Audio DRC” 98
Audio settings 97
Auto Clock Set 94
“Auto Play” 100
“Auto Preset” 93
“Auto Repeat” 100

B

Batteries 19
“Black Level” 96
Bookmark 39

C

Cable box 13, 14
Changing or Canceling Timer Settings (Timer List) 52, 79
Chapter 117
“Chapter Erase” 57
CHAPTER MARK 59
CHAPTER MARK ERASE 59
“Check” 63
Child Lock 37
Cleaning discs 108
Cleaning the video heads 106
CLEAR 67
“Clock Set CH” 94
Clock Set settings 94

“Combine Titles” 63
“Command Mode” 25, 102
COMPONENT VIDEO OUT 16
Connecting
 the antenna cable 12
 to your AV/amplifier (receiver) 17
 to your TV 15
Controlling TVs with the remote 20
Copy protection 46, 117
Copy-Free 46
Copy-Never 46
Copy-Once 46
Counter 67
CPRM 28
“Create Dubbing List” 85
“Create Playlist” 61
Creating chapters 48, 59

D

“Daylight Saving” 95
“Del” 52, 80
“Digital Out” 97
“Disc Finalize” 66, 87
“Disc Format” 66
“Disc Information” 66
“Disc Menu” 100
“Disc Name” 66
“Disc Protect” 66
“Disc Setting” 66, 87
Disc types 28
Display
 front panel display 116
 Setup Display 92
“Divide Title” 58, 63
Dolby Digital 23, 98, 117
“Downmix” 98
DTS 23, 35, 98, 117
“Dubbing” 82, 84
“DV Audio Input” 90, 99
“DV/D8 Dubbing” 90
“DV/D8 One Touch Dubbing” 91
“DV/D8 Simple Dubbing” 90
“DVD Auto Chapter” 99
DVD Editing 55
DVD VIDEO 30, 117

DVD+R 28, 117
DVD+R DL 28
DVD+RW 28, 117
DVD-R 28, 117
DVD-RW 28, 117

E

Easy Setup 102
“Edit” 52, 80
“Edit Playlist” 63
“Edit Scene” 63
Enter characters 60
EP mode 74
“Erase” 57
“Erase All Titles” 66

F

“Factory Setting” 102
Fast forward 34, 69
Fast reverse 34, 69
Feature settings 99
Finalizing 86
“Format DVD” 100
“Front Display” 101
Front panel 112
Front panel display 116

H

Handling discs 108

I

i.LINK 88, 110
INPUT SELECT 46, 74, 89
Interlace format 118

J

JPEG image files 41

L

“Language” 100
Language Abbreviation 118
LINE 1 IN 27
LINE 2 IN 26
“Line Audio Input” 50, 54, 99

M

Manual Clock Set 95

“Manual Set” 94
MARKER 39
MENU 32
Menu
 Top menu 32
“Modify” 63
“Move” 63
MP3 audio tracks 40

N

NEXT 34, 69
Number buttons 20, 38

O

One Touch Dubbing 91
On-screen display
 Setup Display 92
 Sub-menu 10
 System Menu 10
 TOOLS menu 11
Options settings 100
Original 38, 118
ORIGINAL/PLAYLIST 38, 56
“OSD” language 22, 100

P

“Parental” 101
Parental Control 36
Parts and controls 112
PAUSE 34, 47, 69, 74
PBC 36
“Picture control” 96
PLAY 32, 67
Playable discs 30
Playback 32, 67
 MP3 audio tracks 40
 Repeat Play 35
 Resume Play 36
 Slow-motion play 33
Playlist 38, 61, 118
Power cord 19
PREV 34, 69
Program Dubbing 84
“Progressive” 96
Progressive format 118
“Protect” 57

Q

Quick Timer 47, 74

R

Rear panel 116
REC 47, 74
REC MODE 47, 74
Recording 45, 73
 recordable discs 28
 recording format 28
 recording mode 45
 tape speed 73
 while watching another program 47, 74

Recording mode 45
Recording time 45, 48
Region code 31
Remaining time 75
Remote 19, 113
REPEAT 35
Repeat A-B Play 36
REPLAY 34, 69
Resetting 102
Resume Play 36
Rotate 42

S

Safety tab 73
SAP (Second Audio Program) 45, 73
Satellite receiver 13
“Scan Audio” 36, 98
“Scene Dubbing” 85
Searching
 for “Chapter” 38
 for “Title” 38
 for “Track” 38
 Time Search 38
Settings 92
Setup Display 92
“Simple Dubbing” 84
SP mode 74
Stereo programs 45, 73
STOP 32, 47, 67, 74
Sub-menu 10
SUBTITLE 33
“Subtitle” 100
SURROUND 34

SYNCHRO REC 51, 78
“Synchro Recording” 51, 78, 100
System Menu 10

T

“Tape Length” 100
Tape speed 73
“Time Zone” 95
TIME/TEXT 44, 71
TIMER 49, 76
Timer List 52, 79
Timer recording 48, 76
 change or cancel 52, 79
Title 118
“Title Dubbing” 85
“Title Erase” 57, 63
TITLE LIST 37, 56
Title List 37
“Title Name” 57, 63
TOOLS 11
TOP MENU 32
Track 118
TRACKING 68
Tracking adjustment 68
Troubleshooting 103
“Tuner Audio” 97
Tuner Preset 23
Tuner Preset settings 93
“TV Type” 95
TV/DVD-VIDEO 20
TV/VIDEO 47, 74

U

“Unfinalize” 87
Unrecordable pictures 46

V

“VCR Function” 100
VIDEO CD 30
Video mode 28
Video settings 95
VR mode 28

Z

ZOOM 33
Zoom 42

MEMO

2. DISASSEMBLY AND REASSEMBLY

2-1 CABINET AND PCB

2-1-1 Cabinet Top Removal




Fig. 2-1 Cabinet Top Removal

2-1-2 Bottom Cover Removal




Fig. 2-2 Bottom Cover Removal

2-1-3 Ass'y Front Panel Removal




Fig. 2-3 Ass'y Front Panel Removal

2-1-4 Function Timer PCB Removal




Fig. 2-4 Function Timer PCB Removal

2-1-5 Chassis Removal




Fig. 2-5 Chassis Removal

2-1-6 VCR Main PCB Removal




Fig. 2-6 VCR Main PCB Removal

2-2 CIRCUIT BOARD LOCATIONS




Fig. 2-7 Circuit Board Locations

2-3 VCR DECK PARTS LOCATIONS

2-3-1 Top View




Fig. 2-8 Top parts Location-1

- ❶ GEAR FL CAM
- ❷ MOTOR LOADING ASS'Y
- ❸ LEVER FL ARM ASS'Y
- ❹ HOLDER FL CASSETTE ASS'Y
- ❺ LEVER FL DOOR
- ❻ SLIDER FL DRIVE




Fig. 2-9 Top Parts Location-2

- | | |
|--------------------------|-----------------------|
| ❶ FE HEAD | ❸ DISK S REEL |
| ❷ CYLINDER ASS'Y | ❹ LEVER S BRAKE ASS'Y |
| ❸ ACE HEAD ASS'Y | ❺ GEAR IDLE |
| ❹ LEVER UNIT PINCH ASS'Y | ❻ LEVER IDLE |
| ❺ LEVER #9 GUIDE ASS'Y | ❼ LEVER T BRAKE ASS'Y |
| ❻ LEVER TENSION ASS'Y | ❽ DISK T REEL |
| ❼ BAND BRAKE ASS'Y | |

2-3-2 Bottom View




Fig. 2-10 Bottom Parts Location

- ❶ GEAR JOINT 1
- ❷ GEAR JOINT 2
- ❸ BRACKET GEAR
- ❹ MOTOR CAPSTAN ASS'Y
- ❺ LEVER T LOAD ASS'Y
- ❻ GEAR LOADING DRIVE
- ❼ LEVER S LOAD ASS'Y
- ❽ HOLDER CLUTCH ASS'Y
- ❾ BELT PULLEY
- ❿ SLIDER CAM

2-4 VCR DECK

2-4-1 Holder FL Cassette Ass'y Removal

- 1) Pull the Holder FL Cassette Ass'y ❶ to the eject position.
- 2) Pull the Holder FL Cassette Ass'y ❶ as grasping the Holder FL Cassette Ass'y ❶ and Lever FL Cassette-R ❷ in the same time to release hooking from Main Base until the Boss [A] of Holder FL Cassette Ass'y ❶ is taken out from the Rail [B].
- 3) Lift the Holder FL Cassette Ass'y ❶, in this time, you have to grasp the Lever FL Cassette-R ❷ continuously until the Holder FL Cassette Ass'y ❶ is taken out completely.

Note: Be sure to insert Lever FL Cassette-R ❷ in the direction of "A" to prevent separation and breakage of the Lever FL Cassette-R ❷ at disassembling and reassembling.




Fig. 2-11 Holder FL Cassette Ass'y Removal

2-4-2 Lever FL Arm Ass'y Removal

- 1) Push the hole "A" in the direction of arrow "B" use the pin.(about Dia. 2.5)
- 2) Pull out the Lever FL Arm Ass'y ❶ from the Boss of Main Base.
- 3) Remove the Lever FL Arm Ass'y ❶ in the direction of arrow "C".




Fig. 2-12 Lever FL Arm Ass'y Removal

2-4-3 Lever FL Door Removal

- 1) Release the Hook ❷ and Remove the Lever FL Door ❶ in the direction of arrow "A".




Fig. 2-13 Lever FL Door Removal

2-4-4 Slider FL Drive, Gear FL Cam Removal

- 1) Pull the Slider FL Drive ❶ to the front direction.
- 2) Remove the Slider FL Drive ❶ in the direction of arrow. (Refer to Fig. 2-14)
- 3) Remove the Gear FL cam ❷.

Note: When reinstalling be sure to reassemble Slider FL drive ❶ after you insert the Boss of Lever FL ARM-R in Groove of Slider FL drive ❶.

Assembly: Align the Gear FL Cam ❶ with the Gear worm wheel Post as shown drawing. (Refer to Timing point)




Fig. 2-14 Slider FL Drive Removal




Fig. 2-15 Gear FL Cam, Gear Worm

2-4-5 Gear Worm Wheel Removal

- 1) Remove the Gear Worm wheel **1**.




Fig. 2-16 Gear Worm Wheel Removal

2-4-6 Cable Flat Removal

- 1) Remove the Drum connecting part of Cable Flat **1** from Connector Wafer **2**.




Fig. 2-17 Cable Flat Removal

2-4-7 Motor Loading Ass'y Removal

- 1) Remove the screw ❶.
- 2) Remove the Motor Loading Ass'y ❷.




Fig.2-18 Motor Loading Ass'y Removal

2-4-8 Bracket Gear, Gear Joint 2, 1 Removal

- 1) Remove the SCREW ❶.
- 2) Remove the Bracket Gear ❷.
- 3) Remove the Gear Joint 2 ❸.
- 4) Remove the Gear Joint 1 ❹.

Assembly:

- 1) Be sure to align dot mark of Gear Joint 1 ❶ with dot mark of Gear Joint 2 ❷ as shown Fig 2-20.
(Refer to Timing point1)
- 2) Confirm the Timing Point 2 of the Gear Joint 2 ❷ and Slider Cam ❸.




Fig. 2-19 Bracket Gear, Gear Joint 1,2 Removal




Fig. 2-20 Gear Joint 1,2 Assembly

2-4-9 Gear Loading Drive, Slider Cam, Lever Load S, T Ass'y Removal

- 1) Remove the Belt Pulley. (Refer to Fig. 2-38)
- 2) Remove the Gear Loading Drive **1** after releasing Hook [A] in the direction arrow as shown in detail drawing.
- 3) Remove the Slider Cam **2**.
- 4) Remove the Lever Load S Ass'y **3** & Lever Load T Ass'y **4**.




Fig. 2-21 Gear Loading Drive, Slider Cam, Lever T, S Load Ass'y Removal

2-4-10 Gear Loading Drive, Slider Cam, Lever Load S, T Ass'y Assembly

- 1) When reinstalling, be sure to align dot of Lever Load T Ass'y **1** with dot of Lever Load S Ass'y **2** as shown in drawing, (Refer to Timing Point 1).
- 2) Insert the Pin A,B,C,D into the Slider Cam **3** hole,
- 3) Be sure to align dot of Lever Load T **1** and dot of Gear Loading Drive **4**, (Refer to Timing Point 2).
- 4) Aline dot of Gear Loading drive **4** with mark of Slider Cam **3** as shown in drawing (Refer to Timing Point 3).




Fig. 2-22 Gear Loading Drive, Slider Cam, Lever Load S, T Ass'y Assembly

2-4-11 Lever Pinch Drive, Lever Tension Drive Removal

- 1) Remove the Lever Pinch Drive ❶, Lever Tension Drive ❷.




Fig. 2-23 Lever Pinch Drive,
Lever Tension Drive Removal

2-4-12 Lever Tension Ass'y, Band Brake Ass'y Removal

- 1) Remove the Lever Brake S Ass'y (Refer to Fig 2-25).
- 2) Remove the Spring Tension Lever ❶.
- 3) Rotate stopper of Main Base in the direction of arrow "A".
- 4) Lift the Lever Tension Ass'y ❷ & Band brake Ass'y ❸.

Note:

- 1) When replacing the Lever Tension Ass'y ❷, be sure to apply Grease on the post,
- 2) Take care not to touch stain on the felt side, and not to be folder and broken Band brake Ass'y
- 3) After Lever Tension Ass'y seated, Rotate stopper of Main Base to the Mark[B].




Fig. 2-24 Lever Tension Ass'y,
Band Brake Ass'y Removal

2-4-13 Lever Brake S, T Ass'y Removal

- 1) Release the Hook [A] and the Hook [B], [C] in the direction of arrow as shown in Fig 2-25.
- 2) Lift the Lever S, T Brake Ass'y ①, ② with spring brake ③.

Assembly:

- 1) Assembly the Lever S Brake Ass'y ① on the Main Base.
- 2) Assembly the Lever T Brake Ass'y ② with spring brake ③.

Note: Take extreme care not to be folded and transformed Spring Brake at removing or reinstalling.




Fig. 2-25 Lever Brake S, T Ass'y Removal

2-4-14 Gear Idle Ass'y Removal

- 1) Push the Lever Idle ① in the direction of arrow "A", "B".
- 2) Lift the Lever Idle ①.

Assembly:

- 1) Apply oil in two Bosses of Lever Idle ①.
- 2) Assemble the Gear Idle ② with the Lever Idle ①.

Note: When replacing the Gear Idle ②, be sure to add oil in the boss of Lever Idle ①.




Fig. 2-26 Gear Idle Ass'y Removal

2-4-15 Disk S, T Reel Removal

- 1) Lift the Disk S, T Reel ❶, ❷.




Fig. 2-27 Disk S, T Reel Removal

2-4-16 Holder Clutch Ass'y Removal

- 1) Remove the Washer Slit ❶.
- 2) Lift the Holder Clutch Ass'y ❷.

Note: When you reinstall Holder Clutch Ass'y

- 1) Check the condition of spring as shown in detail A.
- 2) Don't push Holder Clutch Ass'y down with excessive force Just insert Holder Clutch Ass'y into post center with dead force and Rotate it smoothly.
Be sure to confirm that spring is in the slit of Gear Center Ass'y as shown in detail B.





Fig. 2-28 Holder Clutch Ass'y Removal

2-4-17 Lever Up Down Ass'y, Gear Center Ass'y Removal

- 1) Remove the 2 hooks in the direction of arrow as shown Fig. 2-29 and lift the Lever Up Down Ass'y ①.
- 2) Lift the Gear Center Ass'y ②.

Assembly:

- 1) Insert the Lever Up Down Ass'y ① in the rectangular holes on Main Base as shown in Fig 2-30.
- 2) Lift the Lever Up Down Ass'y ① about 35°.
- 3) Insert Ring of the Gear Center Ass'y ② in the Guide of the Lever Up Down Ass'y ①.
- 4) Insert the Gear Center Ass'y ② in the post on Main Base.
- 5) Push down the Lever Up Down Ass'y ① for locking of the Hook.

Note:

- 1) Take care not to separate and sentence does not mark sense.
- 2) Be sure to confirm that Ring of the Gear Center Ass'y ② is in the Guide of the Lever Up Down Ass'y ① after finishing assembly of Lever Up Down Ass'y ① and Gear Center Ass'y ②.




Fig. 2-29 Lever Up Down Ass'y Removal




Fig. 2-30 Lever Up Down Ass'y Removal

2-4-18 Guide Cassette Door Removal

- 1) Lift the Hook [A].
- 2) Rotate the Guide Cassette Door ① in the direction of arrow.

Note: After reinstalling the Guide Cassette Door ① sure the Hook [A].




Fig. 2-31 Guide Cassette Door Removal

2-4-19 Lever Unit Pinch Ass'y, Plate Joint, Spring Pinch Drive Removal

- 1) Lift the Unit Pinch Ass'y ❶.
- 2) Remove the Plate Joint ❷ from Lever Pinch Drive.
- 3) Remove the Spring Pinch Drive ❸.

Note:

- 1) Take extreme care not to touch the grease on the Roller Pinch.
- 2) When reinstalling, be sure to apply grease on the post pinch roller.




Fig. 2-32 Lever Unit Pinch Ass'y, Plate Joint, Spring Pinch Drive Removal

2-4-20 Lever #9 Guide Ass'y Removal

- 1) Remove the Spring #9 Guide ❶.
- 2) Lift the Spring #9 Guide Ass'y ❷ in the direction of arrow "A".

Note:

- 1) Take extreme care not to get grease on the tape Guide Post.
- 2) After reinstalling, check the bottom side of the Post #9 Guide to the top side of Main Base.




Fig. 2-33 Lever #9 Guide Ass'y Removal

2-4-21 FE Head Removal

- 1) Rotate the FE Head ❶ in the direction of arrow to lift up.




Fig. 2-34 FE Head Removal

2-4-22 ACE Head Removal

- 1) Pull out the FPC from connector of ACE Head Ass'y ❷.
- 2) Remove the screw ❶.
- 3) Lift the ACE Head Ass'y ❷.




Fig. 2-35 ACE Head Removal

2-4-23 Slider S, T Ass'y Removal

- 1) Move the Slider S, T Ass'y ❶, ❷ to slot, and then lift it to remove. (Refer to arrow)




Fig. 2-36 Slider S, T Ass'y Removal

2-4-24 Plate Ground Deck, Cylinder Ass'y Removal

- 1) Remove the 3 Screws ❶.
- 2) Lift the Plate Ground Deck ❷.
- 3) Lift the Cylinder Ass'y ❸.

Assembly:

- 1) Match the 3 holes in the bottom of Cylinder Ass'y ❸ to the 3 holes of Main Base as attending not to drop or knock the Cylinder Ass'y ❸.
- 2) Tighten the 1 Screw ❶.
- 3) Match the Plate Ground Deck ❷ to the Hole of Base Main.
- 4) Tighten the other 2 Screws ❶.

Note:

- 1) Take care not to touch the Cylinder Ass'y ❸ and the tape guide post at reinstalling.
- 2) When reinstalling, Don't push down too much on Screw Driver.




Fig. 2-37 Plate Ground Deck, Cylinder Ass'y Removal

2-4-25 Hook Capstan, Belt Pulley Removal

- 1) Remove the Hook Capstan ❶ after realeasing Hook in the direction arrow as shown in detail drawing.
- 2) Remove the Belt Pulley ❷.

Note: Take extreme care not to get grease on Belt Pulley ❷ at assembling or reassembling.




Fig. 2-38 Belt Pulley Removal

2-4-26 Motor Capstan Ass'y Removal

- 1) Remove the 3 Screws ❶.
- 2) Remove the Motor Capstan Ass'y ❷.

Assembly:

- 1) Match the 3 holes of Motor Capstan Ass'y ❷ to the 3 holes of Main Base. Be careful not to drop or knock the Motor Capstan Ass'y ❷.
- 2) Tighten the 3 Screws ❶ in the direction of arrow as shown detail drawing.

Note: After tightening screws, check if there is gap between the head of screws and the top side of Main Base. There should have no gap between the head of screws and the top side of Main Base. After reinstalling, adjusting the tape transport system again.




Fig. 2-39 Motor Capstan Ass'y Removal

2-4-27 Post #8 Guide Ass'y Removal

- 1) Rotate the Post #8 Guide Ass'y ❶ in the direction of arrow to lift up.




Fig. 2-40 Post #8 Guide Ass'y Removal

2-4-28 Level Head Cleaner Ass'y Removal

- 1) Release the Hook ❶.
- 2) Lift the Lever Head Cleaner Ass'y ❷.




Fig. 2-41 Lever Head Cleaner Ass'y Removal

2-4-29 How to Eject the Cassette Tape (If the tape is stuck in the unit)

- 1) Turn the Gear worm ❶ clockwise with screw driver.(Refer to arrow)
(Other method: Remove the Screw of Motor Load Ass'y, Separate the Motor Load Ass'y)




Fig. 2-42

- 2) When Slider S,T are approached in the position of unloading, rotate holder Clutch counterclockwise after inserting screw driver in the hole of frame's bottom in order to wind the unwinded tape.
(Refer to Fig.2-43)
(If you rotate Gear Worm ❶ continuously when tape is in state of unwinding, you may cause a tape contamination by grease and tape damage.
Be sure to wind the unwinded tape in the state of set horizontally.)
- 3) Rotate Gear Worm ❶ clockwise using screw driver again up to the state of eject mode and then pick out the tape.(Refer to Fig.2-42)




Fig. 2-43

2-5 THE TABLE OF CLEANING, LUBRICATION AND REPLACEMENT TIME ABOUT PRINCIPAL PARTS

- 1) The replacement time of parts is not life of parts.
- 2) The table 2-1 is that the VCR Set is in normal condition (normal temperature, normal humidity).
The checking period may be changed owing to the condition of use, runtime and environmental conditions.
- 3) Life of the Cylinder Ass'y is depend on the condition of use.
- 4) See exploded view for location of each parts.


<Table 2-1>

*	Parts Name	Checking Period										Remark
		500	1000	1500	2000	2500	3000	3500	4000	4500	5000	
T A P E P A T H S Y S T E M	POST TENSION	△	△	△	△	△	△	△	△	△	△	- To clean the parts, use patch and alcohol (solvent).
	SLANT POST S, T	△	△	△	△	△	△	△	△	△	△	
	#8 GUIDE SHAFT	△	△	△	△	△	△	△	△	△	△	
	CAPSTAN SHAFT	△	△	△	△	△	△	△	△	△	△	- After cleaning, use the video tape after alcohol is gone away completely.
	#9 GUIDE POST	△	△	△	△	△	△	△	△	△	△	
	#3 GUIDE POST	△	△	△	△	△	△	△	△	△	△	
	GUIDE ROLLER S, T	△	△	△	○	○	○	○	○	○	○	- We recommend to use oil [EP-50] or solvent.
	CYLINDER ASS'Y	△	○	○	○	○	○	○	○	○	○	
	FE HEAD	△	△	△	○	○	○	○	○	○	○	
	ACE HEAD	△	○	○	○	○	○	○	○	○	○	- One or two drops of oil should be applied after cleaning with alcohol.
	PINCH ROLLER	△	○	○	○	○	○	○	○	○	○	
	POST REEL S, T		◆		◆		◆		◆		◆	
	SLEEVE TENSION		◆		◆		◆		◆		◆	- Periodic time of applying oil (Apply oil after cleaning)
	POST CENTER		◆		◆		◆		◆		◆	
	LEVER IDLE BOSS (2Point)		◆		◆		◆		◆		◆	
D R I V I N G S Y S T E M	CAPSTAN MOTOR PULLEY	△	△	△	△	△	○	○	○	○	○	
	BELT PULLEY				○	○	○	○	○	○	○	
	HOLDER CLUTCH ASS'Y	△	○	○	○	○	○	○	○	○	○	
	GEAR CENTER ASS'Y		○	○	○	○	○	○	○	○	○	
	GEAR IDLE (2Point)		○	○	○	○	○	○	○	○	○	
	LOADING MOTOR		○	○	○	○	○	○	○	○	○	
B R A K E S Y S T E M	BAND BRAKE ASS'Y		○	○	○	○	○	○	○	○	○	
	BRAKE T ASS'Y		○	○	○	○	○	○	○	○	○	

△ : Cleaning ○ : Check and replacement in necessary ◆ : Add Oil

MEMO

3. Block Diagram



MEMO

4. PCB Diagrams

4-1 VCR Main PCB 4-3

4-2 DVD Main PCB 4-7


4-3 Jack PCB 4-11

4-4 DV Jack PCB 4-15


4-5 Function Timer PCB 4-15

4-1 VCR Main PCB


COMPONENT SIDE



CONDUCTOR SIDE





COMPONENT SIDE



4-3 Jack PCB


COMPONENT SIDE






4-4 DV Jack PCB

COMPONENT SIDE




CONDUCTOR SIDE




4-5 Function Timer PCB

COMPONENT SIDE



CONDUCTOR SIDE



5. Schematic Diagrams

◆ Block Identification of Main PCB - - - - - 5-3

5-1 S.M.P.S (VCR Main PCB) - - - - - 5-5

5-2 Power (VCR Main PCB) - - - - - 5-7

5-3 Logic (VCR Main PCB) - - - - - 5-9

5-4 A/V (VCR Main PCB) - - - - - 5-11

5-5 Hi-Fi (VCR Main PCB) - - - - - 5-13

5-6 Function Timer (Function Timer PCB)- - - - - 5-15

5-7 Encoder (DVD Main PCB) - - - - - 5-17

5-8 Decoder (DVD Main PCB) - - - - - 5-19

5-9 Video Decoder and Connector (DVD Main PCB) - - - - - 5-21

5-10 DV Interface and 1394 Connector (DVD Main PCB)- - - - - 5-23

5-11 Connectors and Power (DVD Main PCB) - - - - - 5-25

5-12 MTS/Tuner (JACK PCB)- - - - - 5-27

5-13 AV IN/OUT (JACK PCB) - - - - - 5-29

5-14 Component/Super Out (JACK PCB) - - - - - 5-31



Note

For schematic Diagram
- Resistors are in ohms, 1/8W unless otherwise noted.


Special note :
Most semiconductor devices are electrostatically sensitive and therefore require the special handling techniques described under the “electrostatically sensitive (ES) devices” section of this service manual.

Important safety notices :
Components identified with the mark ⚠ have the special characteristics for safety. When replacing any of these components. Use only the same type.


◆ Block Identification of Main PCB




5-1 S.M.P.S. (VCR Main PCB)




5-2 Power (VCR Main PCB)




5-3 Logic (VCR Main PCB)




5-4 A/V (VCR Main PCB)




5-5 Hi-Fi (VCR Main PCB)




5-6 Function Timer (Function Timer PCB)




5-7 Encoder (DVD Main PCB)







5-9 Video Decoder and Connector (DVD Main PCB)



5-10 DV Interface and 1394 Connector (DVD Main PCB)




5-11 Connectors and Power (DVD Main PCB)






5-13 AV IN/OUT (JACK PCB)



5-14 Component/Super Out (JACK PCB)



6. ALIGNMENT AND ADJUSTMENTS

6-1 VCR ADJUSTMENT

6-1-1 Reference

- 1) X-Point (Tracking center) adjustment, "Head switching adjustment" can be adjusted with remote control.
- 2) When replacing the Main PCB Micom (IC601) and NVRAM (IC603: EEPROM) be sure to adjust the "Head switching adjustment".
- 3) When replacing the cylinder ass'y, be sure to adjust the "X-Point" and "Head switching adjustment".
- 4) How to adjust.
 - Intermittently short-circuit the Test Point on Function Timer PCB with pincers to the adjustment mode.
 - If the corresponding adjustment button is pressed, the adjustment is performed automatically.
 - When the adjustment is completed, be sure to turn the power off.

6-1-1(a) Location of adjustment button of remote control




Fig. 6-1

6-1-1(b) TEST location for adjustment mode setting




Fig. 6-2 Function Timer PCB (Top View)

6-1-2 Head Switching Point Adjustment

- 1) Playback the alignment tape.
- 2) Intermittently short-circuit the two Test Points on Function Timer PCB while setting the adjustment mode. (See Fig. 6-2)
- 3) Press the “1, 0” buttons ; remote control adjustment operates automatically. (See Fig. 6-1)

6-2 VCR MECHANICAL ADJUSTMENT

6-2-1 Tape Transport System and Adjustment Locations

The tape transport system has been adjusted precisely in the factory. Alignment is not necessary except for the following :

- 1) Noise observed on the screen.
- 2) Tape damage.
- 3) Parts replacement in the tape transport system.

Lower flange height of tape guide is used as the reference for the transport adjustment.

To maintain the height of the tape guide and prevent damage, do not apply excessive force onto the main base.




Fig. 6-3 Location of Tape Transport Adjustment




Fig. 6-4 Tape Travel Diagram

6-2-2 Tape Transport System Adjustment

When parts are replaced, perform the required adjustments by referring to procedures for the tape transport system. If there are any changes to the tape path, first run a T-120 tape and make sure excessive tape wrinkle does not occur at the tape guides.

- ◆ If tape wrinkle is observed at the guide roller S, T, turn the guide roller S, T until wrinkle disappears.
- ◆ If the tape wrinkle is still observed at the tape guide, perform the tilt adjustment of the ACE head.

(1) ACE Head Assembly Adjustment

a. ACE HEAD HEIGHT ADJUSTMENT

- 1) Run the alignment tape (Color bar) in the playback mode.
- 2) Observe surface of the audio head using a dental mirror.
- 3) Turn screw (C) clockwise or counterclockwise until the gap of lower tape edge and the lower edge of the control head is about 0.25mm. (Refer to Fig. 6-5 and 6-6)




Fig. 6-5 Location of ACE Head Adjustment Screw




Fig. 6-6 ACE Head Height Adjustment

b. ACE HEAD TILT ADJUSTMENT

- 1) Playback a blank tape and observe the position of the tape at the lower flange of tape guide.
- 2) Confirm that there is no curl or wrinkle at the lower flange of tape guide as shown in Fig. 6-7 (B).
- 3) If a curl or wrinkle of the tape occurs, slightly turn the screw (A) tilt adjust on the ACE head ass'y.
- 4) Reconfirm the ACE head height.




Fig. 6-7 Tape Guide Check

c. AUDIO AZIMUTH ADJUSTMENT

- 1) Load alignment tape (Mono scope) and playback the 7KHz signal.
- 2) Connect channel-1 scope probe to audio output.
- 3) Adjust screw (B) to achieve maximum audio level. (See Fig. 6-5)

d. ACE HEAD POSITION (X-POINT) ADJUSTMENT

- 1) Playback the alignment tape (Color bar)
- 2) Intermittently short-circuit the two Test Points on Function Timer PCB. (See Fig. 6-2)
- 3) Press the “0, 5” remote control buttons, then adjustment is operates automatically. (See Fig. 6-1)
- 4) Connect the CH-1 probe to “Envelope” the CH-2 probe to “H’D switching pulse” and then trigger to CH-1.
- 5) Insert the (-) driver into the X-Point adjustment hole and adjust it so that envelope waveform is maximum.

Test point: TP2 (Audio Output)
TP3 (Envelope)
TP4 (H’D S/W -Trigger)
TP5 (Control Pulse)




Fig. 6-8 Location of Test point (VCR Main PCB-Top View)

(2) Linearity adjustment (Guide roller S, T adjustment)

- 1) Playback the Mono Scope alignment tape (SP mode).
- 2) Observe the video envelope signal on an oscilloscope (triggered by the video switching pulse).
- 3) Make sure the video envelope waveform (at its minimum) meets the specification shown in Fig. 6-9.

If it does not, adjust as follows :

Note:

- a=Maximum output of the video RF envelope.
- b=Minimum output of the video RF envelope at the entrance side.
- c=Minimum output of the video RF envelope at the center point.
- d=Maximum output of the video RF envelope at the exit side.

- 4) If the section A in Fig. 6-10 does not meet the specification, adjust the guide roller S up or down.
- 5) If the section B in Fig. 6-10 does not meet the specification, adjust the guide roller T up or down.




Fig. 6-9 Envelope Waveform Adjustment




Fig. 6-10 Adjustment Points

- 6) Play back the Mono Scope alignment tape (SP mode).
- 7) Connect an oscilloscope CH-1 to the "Envelope" and CH-2 to the "H'D SW Pulse" for triggering.
- 8) Turn the guide roller heads with a flat head (🔧) driver to obtain a flat video RF envelope as shown in Fig. 6-11.




Fig. 6-11 Guide Roller S, T Height Adjustment

(3) Check Transitional Operation from RPS to Play

Check transition from RPS mode to play mode : Using a pre-recorded SP tape, make sure the entry side of envelope comes to an appropriate steady state within 3 seconds (as shown in Fig. 6-12).

If the envelope waveform does not reach specified peak-to-peak amplitude within 3 seconds, adjust as follows :

- 1) Make sure there is no gap between the supply roller lower flange and the tape.
If there is a gap, adjust the supply guide roller again.
- 2) Change operation mode from the RPS to the play mode (again) and make sure the entry side of envelope rises within 3 second.




Fig. 6-12 Video Envelope Rising when Operation mode Changes from RPS to Play Mode

(4) Envelope Check

- 1) Make recordings on T-120 (E-120) and T-160 (E-180) tape.
Make sure the playback output envelope meets the specification as shown in Fig. 6-13.
- 2) Play back a self recorded tape (recording made on the unit using with T-120 (E-120)).
The video envelope should meet the specification as shown in Fig. 6-13.
In SP mode, (A) should equal (B).
If the head gap is wide, upper cylinder should be checked.




Fig. 6-13 Envelope Input and Output Level

(5) Tape Wrinkle Check

- 1) Run the T-160 (E-180) tape in the playback, FPS, RPS and Pause modes and observe tape wrinkle at each guide.
- 2) If excessive tape wrinkle is observed, perform the following adjustments in Playback mode :

- ◆ Tape wrinkle at the guide roller S, T section : Linearity adjustment.
- ◆ Tape wrinkle at tape guide flange : ACE head assembly coarse adjustment.

6-2-3 Reel Torque

- 1) The rotation of the capstan motor causes the holder clutch ass'y to rotate through the belt pulley.
- 2) The spring wrap PLAY/REV of holder clutch ass'y drives the disk reel S, T through gear idler by rotation of gear center ass'y.
- 3) Brake is operated by slider cam at FF/REW mode.
- 4) Transportation of accurate driving force is done by gears. (Gear Center Ass'y)



Note: If the spec. does not meet the followings specifications, replace the holder clutch ass'y and then recheck.



< Table 6-1 >



MODE	TORQUE g/cm	GAUGE
PB	42 ± 11	Cassette Torquemeter
RPS	145 ± 30	Cassette Torquemeter



7. TROUBLESHOOTING



7-1






































**DRUM DOES
NOT ROTATE**

(VCR Section)










No Analog Audio Output




No digital audio out











Line2 CVBS Video Input Error



Line2 S-Video Video Input Error




8. REPAIR PARTS LIST

8-1 Exploded Views	8-2
8-1-1 Cabinet Assembly	8-2
8-1-2 VCR Mechanical Parts (Top Side)	8-3
8-1-3 VCR Mechanical Parts (Bottom Side)	8-4
8-2 Electrical Parts List	8-5


- The mechanical parts with no reference number in the exploded views are not supplied.

Les composants identifiés par une marque  sont critiques pour la sécurité.
Ne les remplacer que par une pièce portant le numéro spécifié.




Ref. No.	Part No.	Description	Remarks	Ref. No.	Part No.	Description	Remarks
1	9-885-090-50	ASSY -PANEL FRONT (VX515)		101	9-885-083-79	CABINET-TOP	
1	9-885-093-72	ASSY -PANEL FRONT (VX511)		151	9-885-090-41	FAN-DC	
3	9-885-090-49	DOOR-TRAY		153	9-885-084-32	SCREW-TAPTITE	
4	9-885-069-96	SPRING ETC-DOOR SUS304WPB		155	3-078-566-01	SCREW TAP M3 L10 BLK	
6	9-885-056-92	SCREW TAP M2.6 L7					
7	9-885-079-49	ASSY DECK		157	9-885-069-88	SCREW-TAPTITE ZPC (WHT)	
8	9-885-084-31	ASSY -DVDR DECK		158	9-885-069-91	SCREW-SPECIAL	
9	9-885-094-69	REMOCON DOOR-REMOCON (for RMT-D224A)		159	9-885-090-43	FFC CABLE-FLAT	
10	9-885-093-70	DOOR-BATTERY REMOCON (for RMT-D224A)		△ 200	1-824-674-11	POWER CORD EP2 SPT-2	
22	9-885-090-48	DOOR-CASSETTE		602	9-885-090-45	ASSY PCB-MAIN DVD	
23	3-080-528-01	SPRING ETC		UT01	9-885-090-47	REMOCON-ASSY (RMT-D224A)	

8-1-2 VCR Mechanical Parts (Top Side)



Ref. No.	Part No.	Description	Remarks	Ref. No.	Part No.	Description	Remarks
B410	1-796-434-11	LOADING ASSY, MOTOR		G560	9-885-061-14	POST-#8 GUIDE ASSY	
B440	9-885-067-38	SCREW MAC 3X3.3		G680	3-075-021-01	AUTO HEAD CLEANER (G680)	
G001	9-885-069-98	ASSY-CYLINDER		G681	3-075-022-01	AUTO HEAD CLEANER (G681)	
G060	3-075-254-01	SCREW ASSY MAC 3X6		K110	3-075-046-01	DISK S REEL	
G070	9-885-061-12	PLATE-GROUND DECK		K140	3-075-047-01	DISK T REEL	
G420	3-079-347-01	SLIDER-SUPPLY ASSY		K240	3-067-781-01	LEVER-TENSION	
G450	3-079-346-01	SLIDER-TAKE UP ASSY		K248	3-067-782-01	SPRING-TENSION LEVER	
G480	9-885-083-60	ASSY ACE HEAD		K250	3-067-783-01	BAND-BREAK	
G510	9-885-061-04	SCREW TAP M2.6X5.6		K340	3-067-785-01	LEVER-T, BRAKE	
G520	9-885-053-44	LEVER-#9 GUIDE		K350	3-067-786-01	SPRING-BRAKE	
G527	3-067-780-01	SPRING-#9 GUIDE		K490	3-067-788-01	HOLDER-FL CASS.	
G546	9-885-061-11	LEVER-FL DOOR		K546	3-067-789-01	GUIDE-CASS. DOOR	
G555	9-885-053-45	UNIT PINCH ASSY					

8-1-3 VCR Mechanical Parts (Bottom Side)



Ref. No.	Part No.	Description	Remarks
B462	9-885-056-92	SCREW TAP M2.6 L7	
B560	9-885-081-58	MOTOR CAPSTAN	
B561	1-824-063-11	CABLE FLAT 10P	

Ref. No.	Part No.	Description	Remarks
B570	9-885-061-03	SCREW CAP 2.6X6	
G542	3-067-790-01	BELT-PULLEY	

8-2 ELECTRICAL PARTS LIST

NOTE:

- Due to standardization, replacements in the parts list may be different from the parts specified in the diagrams or the components used on the set.
- XX, and -X mean standardized parts, so they may have some difference from the original one.
- RESISTORS**
All resistors are in ohms.
METAL: metal-film resistor
METAL OXIDE: Metal Oxide-film resistor
F: nonflammable
- Not all of the parts are listed.

- Items marked “*” are not stocked since they are seldom required for routine service. Some delay should be anticipated when ordering these items.
- SEMICONDUCTORS**
In each case, u: μ , for example:
uA...: μ A..., uPA..., μ PA...,
uPB..., μ PB..., uPC..., μ PC...,
uPD..., μ PD...
- CAPACITORS:**
uF: μ F
- COILS**
uH: μ H

When indicating parts by reference number, please include the board name.

The components identified by mark $\triangle$ or dotted line with mark $\triangle$ are critical for safety. Replace only with part number specified.

Les composants identifiés par une marque $\triangle$ sont critiques pour la sécurité. Ne les remplacer que par une pièce portant le numéro spécifié.

Ref. No. Part No. Description Remarks

DVD MAIN BOARD

Note: Perform the reset whenever the IC203 or IC205 was replaced.
(See page 10)

	9-885-090-45	ASSY PCB-MAIN DVD <IC>	
IC101	9-885-070-63	IC CS92686 (ENCODER/DECODER)	
IC102	9-885-090-37	IC (DRAM)	
IC103	9-885-090-37	IC (DRAM)	
IC104	9-885-090-37	IC (DRAM)	
IC105	9-885-090-37	IC (DRAM)	
IC201	9-885-070-62	IC CS98201 (DECODER)	
IC202	9-885-090-38	IC (DRAM)	
IC203	9-885-095-27	IC (FLASH MEMORY) (Refer to Note)	
IC204	9-885-090-38	IC (DRAM)	
IC205	9-885-097-54	IC 524AB0X91 (EEPROM) (Refer to Note)	
IC206	9-885-090-39	IC G9966 (POSIFIXED REG.)	
IC302	1-805-039-11	IC M74HC04	
IC303	9-885-079-21	IC 74VHC125 (CMOS LOGIC)	
IC1001	9-885-083-82	IC (VIDEO DECODER)	
IC1301	9-885-070-64	IC TSB41AB1-PAP (DATA COMM/GEN)	

< BEAD >

R39	9-885-083-84	BEAD-SMD	47 OHM
R64	9-885-083-84	BEAD-SMD	47 OHM
R103	9-885-083-84	BEAD-SMD	47 OHM
R1307	9-885-083-84	BEAD-SMD	47 OHM

< VIBRATOR >

X3	9-885-067-37	CRYSTAL (27MHz)	
X1001	9-885-070-70	CRYSTAL-SMD (24.576MHz)	
X1301	9-885-070-70	CRYSTAL-SMD (24.576MHz)	

FUNCTION TIMER BOARD

< DIODE >

D701	1-804-407-11	DIODE 1N4148	
D702	1-804-407-11	DIODE 1N4148	
D703	1-804-407-11	DIODE 1N4148	
D704	1-804-407-11	DIODE 1N4148	
D705	1-804-407-11	DIODE 1N4148	
D706	1-804-407-11	DIODE 1N4148	
D707	1-804-407-11	DIODE 1N4148	

Ref. No. Part No. Description Remarks

D708 1-804-407-11 DIODE 1N4148

< VFD DISPLAY >

DT701 9-885-070-01 VFD DISPLAY HNV-10SM40

< IC >

IC701 1-805-299-11 IC PT6315 (VFD)

< COIL >

L701 1-400-074-11 INDUCTOR 100uH

< LED >

LD701	9-885-079-26	LED (COPY VCR→DVD)	
LD702	9-885-079-26	LED (COPY DVD→VCR)	
LD703	9-885-076-82	LED (PROGRESSIVE)	
LD704	9-885-076-83	LED (SYNCRO REC)	

< TRANSISTOR >

Q701	1-805-016-11	TRANSISTOR	KSC1623-L
Q702	1-805-016-11	TRANSISTOR	KSC1623-L
Q703	1-805-016-11	TRANSISTOR	KSC1623-L
Q704	1-805-016-11	TRANSISTOR	KSC1623-L

< MODULE >

RM701 9-885-069-95 MODULE REMOCON TSOP2240RF1

< SWITCH >

SW703	1-786-353-11	TACT SWITCH (PAUSE)	
SW705	1-786-353-11	TACT SWITCH (VIDEO)	
SW706	1-786-353-11	TACT SWITCH (COPYD2V)	
SW707	1-786-353-11	TACT SWITCH (PLAY)	
SW708	1-786-353-11	TACT SWITCH (DVD)	

SW709	1-786-353-11	TACT SWITCH (EJECT)	
SW710	1-786-353-11	TACT SWITCH (COPYV2D)	
SW711	1-786-353-11	TACT SWITCH (REC)	
SW713	1-786-353-11	TACT SWITCH (FF)	
SW714	1-786-353-11	TACT SWITCH (OPEN)	

SW715	1-786-353-11	TACT SWITCH (REW)	
SW716	1-786-353-11	TACT SWITCH (STOP)	

Ref. No.	Part No.	Description	Remarks
		JACK BOARD *****	
		< CAPACITOR >	
C405A	1-165-563-11	CONDENSER	0.1uF
VC17	1-165-563-11	CONDENSER	0.1uF
		< COIL >	
D0L3	1-400-074-11	INDUCTOR	100uH
EBD23	1-400-085-11	INDUCTOR	70uH
L1	1-400-074-11	INDUCTOR	100uH
L3	1-400-074-11	INDUCTOR	100uH
L4	1-400-074-11	INDUCTOR	100uH
L801	1-400-074-11	INDUCTOR	100uH
L802	1-400-074-11	INDUCTOR	100uH
LS01	1-400-074-11	INDUCTOR	100uH
PL3	1-400-074-11	INDUCTOR	100uH
PL4	1-400-074-11	INDUCTOR	100uH
VL6	1-400-074-11	INDUCTOR	100uH
WJ121	1-400-074-11	INDUCTOR	100uH
WJ287	1-400-074-11	INDUCTOR	100uH
		< CORE >	
ABD1	1-400-316-11	CORE-FERRITE BEAD	220 OHM
ABD2	1-400-316-11	CORE-FERRITE BEAD	220 OHM
ABD3	1-400-316-11	CORE-FERRITE BEAD	220 OHM
CVL1	1-400-316-11	CORE-FERRITE BEAD	220 OHM
CVL2	1-400-316-11	CORE-FERRITE BEAD	220 OHM
CVL3	1-400-316-11	CORE-FERRITE BEAD	220 OHM
DOL2	1-400-316-11	CORE-FERRITE BEAD	220 OHM
DOL4	1-400-316-11	CORE-FERRITE BEAD	220 OHM
EBD05	1-400-316-11	CORE-FERRITE BEAD	220 OHM
EBD06	1-400-316-11	CORE-FERRITE BEAD	220 OHM
EBD15	1-400-316-11	CORE-FERRITE BEAD	220 OHM
EBD16	1-400-316-11	CORE-FERRITE BEAD	220 OHM
EBD18	1-400-316-11	CORE-FERRITE BEAD	220 OHM
EBD19	1-400-316-11	CORE-FERRITE BEAD	220 OHM
EBD20	1-400-316-11	CORE-FERRITE BEAD	220 OHM
EBD21	1-400-316-11	CORE-FERRITE BEAD	220 OHM
JL1	1-400-316-11	CORE-FERRITE BEAD	220 OHM
JL2	1-400-316-11	CORE-FERRITE BEAD	220 OHM
SVL1	1-400-316-11	CORE-FERRITE BEAD	220 OHM
SVL2	1-400-316-11	CORE-FERRITE BEAD	220 OHM
VR100	1-400-316-11	CORE-FERRITE BEAD	220 OHM
		< BEAD >	
DVR1	9-885-083-84	BEAD-SMD	47 OHM
DVR2	9-885-083-84	BEAD-SMD	47 OHM
DVR3	9-885-083-84	BEAD-SMD	47 OHM
DVR4	9-885-083-84	BEAD-SMD	47 OHM
EBD1	9-885-083-84	BEAD-SMD	47 OHM
EBD2	9-885-083-84	BEAD-SMD	47 OHM
EBD3	9-885-083-84	BEAD-SMD	47 OHM
EBD4	9-885-083-84	BEAD-SMD	47 OHM
EBD07	9-885-083-84	BEAD-SMD	47 OHM
EBD08	9-885-083-84	BEAD-SMD	47 OHM
EBD09	9-885-083-84	BEAD-SMD	47 OHM

Ref. No.	Part No.	Description	Remarks
		< DIODE >	
AD1	1-805-012-11	DIODE	DAN202K
AD2	1-805-012-11	DIODE	DAN202K
AD3	1-805-012-11	DIODE	DAN202K
AD4	9-885-070-11	DIODE	DAN217
AD5	1-805-012-11	DIODE	DAN202K
AMD1	1-805-013-11	DIODE	DAP202K
AZ1	1-805-011-11	DIODE	UDZ9.1B
AZ2	1-805-011-11	DIODE	UDZ9.1B
AZ3	1-805-011-11	DIODE	UDZ9.1B
AZ4	1-805-011-11	DIODE	UDZ9.1B
AZ40	1-805-011-11	DIODE	UDZ9.1B
AZ41	1-805-011-11	DIODE	UDZ9.1B
AZ42	1-805-011-11	DIODE	UDZ9.1B
AZ43	1-805-011-11	DIODE	UDZ9.1B
AZ44	1-805-011-11	DIODE	UDZ9.1B
AZ50	1-805-011-11	DIODE	UDZ9.1B
AZ51	1-805-011-11	DIODE	UDZ9.1B
AZ52	1-805-011-11	DIODE	UDZ9.1B
AZ53	1-805-011-11	DIODE	UDZ9.1B
AZ55	1-805-011-11	DIODE	UDZ9.1B
AZ56	1-805-011-11	DIODE	UDZ9.1B
AZ57	1-805-011-11	DIODE	UDZ9.1B
AZ58	1-805-011-11	DIODE	UDZ9.1B
AZ44A	1-805-011-11	DIODE	UDZ9.1B
DOZ1	1-805-011-11	DIODE	UDZ9.1B
DOZ2	1-805-011-11	DIODE	UDZ9.1B
QD01	1-805-012-11	DIODE	DAN202K
VZ1	1-805-011-11	DIODE	UDZ9.1B
VZ2	1-805-011-11	DIODE	UDZ9.1B
VZ3	1-805-011-11	DIODE	UDZ9.1B
VZ4	1-805-011-11	DIODE	UDZ9.1B
VZ5	1-805-011-11	DIODE	UDZ9.1B
VZ6	1-805-011-11	DIODE	UDZ9.1B
VZ7	1-805-011-11	DIODE	UDZ9.1B
VZ8	1-805-011-11	DIODE	UDZ9.1B
VZ9	1-805-011-11	DIODE	UDZ9.1B
VZ10	1-805-011-11	DIODE	UDZ9.1B
VZ50	1-805-011-11	DIODE	UDZ9.1B
VZ51	1-805-011-11	DIODE	UDZ9.1B
VZ50A	1-805-011-11	DIODE	UDZ9.1B
VZ51A	1-805-011-11	DIODE	UDZ9.1B
		< FERRITE BEAD >	
FB17	1-400-086-11	FERRITE CORE	
L410	1-400-086-11	FERRITE CORE	
		< FILTER >	
DOL1	9-885-069-75	FILTER-EMI SMD	
		< IC >	
IC501	9-885-070-46	IC	CS4391 (D/A CONVERTER)
IC502	9-885-070-47	IC	(A/D CONVERTER)
IC503	1-805-028-11	IC	4560 (OP AMP)
IC504	1-805-028-11	IC	4560 (OP AMP)
IC801	9-885-069-93	IC	SV1274/LA7274M
IC4M01	9-885-090-40	IC	(DECODER)
U1	1-805-022-11	IC	74VHCT125A (CMOS LOGIC)
VIC1	9-885-037-03	IC	LA73054 (VIDEO)

Ref. No.	Part No.	Description	Remarks
< TRANSISTOR >			
AMQ1	1-805-016-11	TRANSISTOR	KSC1623-L
AMQ2	1-805-016-11	TRANSISTOR	KSC1623-L
AQ1	1-805-017-11	TRANSISTOR	
AQ2	1-805-018-11	TRANSISTOR	KSR2103
AQ3	1-805-016-11	TRANSISTOR	KSC1623-L
AQ4	1-805-017-11	TRANSISTOR	
AQ5	1-805-018-11	TRANSISTOR	KSR2103
AQ6	1-805-016-11	TRANSISTOR	KSC1623-L
AQ7	1-805-017-11	TRANSISTOR	
AQ8	1-805-018-11	TRANSISTOR	KSR2103
AQ9	9-885-060-82	TRANSISTOR	KSA812
Q801	9-885-060-82	TRANSISTOR	KSA812
QAS01	9-885-060-82	TRANSISTOR	KSA812
QAS02	1-805-016-11	TRANSISTOR	KSC1623-L
QAS03	1-805-016-11	TRANSISTOR	KSC1623-L
QS01	9-885-060-82	TRANSISTOR	KSA812
QS02	9-885-060-82	TRANSISTOR	KSA812
QS03	1-805-016-11	TRANSISTOR	KSC1623-L
QS04	1-805-016-11	TRANSISTOR	KSC1623-L
< SWITCH >			
SW1	1-786-353-11	TACT SWITCH (POWER)	
SW3	1-786-353-11	TACT SWITCH (CH DOWN)	
SW4	1-786-353-11	TACT SWITCH (CH UP)	
< TUNER >			
TM401	9-885-090-46	TM BLOCK-05	
VCR MAIN BOARD			

SC1P02	3-075-255-01	SCREW TAP 3X8	
SC1P05	3-075-255-01	SCREW TAP 3X8	
SC1S01	3-075-255-01	SCREW TAP 3X8	
SC1S30	3-075-255-01	SCREW TAP 3X8	
SC1S31	3-075-255-01	SCREW TAP 3X8	
SC1S32	3-075-255-01	SCREW TAP 3X8	
SC1S33	3-075-255-01	SCREW TAP 3X8	
< CAPACITOR >			
C319	1-100-020-11	CONDENSER	10000PF
C357	1-100-000-11	CONDENSER FILM	15000PF
C502	1-165-563-11	CONDENSER	0.1uF
C522	1-100-020-11	CONDENSER	10000PF
C625	1-100-020-11	CONDENSER	10000PF
C635	1-100-020-11	CONDENSER	10000PF
C636	1-100-020-11	CONDENSER	10000PF
△C1S02	1-100-358-11	CONDENSER CERAMIC DISC	100PF
△C1S03	1-100-358-11	CONDENSER CERAMIC DISC	100PF
△C1S04	9-885-081-57	CONDENSER FILM	47000PF
△C1S05	9-885-081-57	CONDENSER FILM	47000PF
C1S07	1-165-990-11	CONDENSER	100PF
C1S08	1-165-574-11	CONDENSER FILM	10000PF
C1S12	1-165-574-11	CONDENSER FILM	10000PF
C1S39	1-165-999-11	CONDENSER FILM	0.1uF
< CONNECTOR >			
CN301	1-815-685-11	CONNECTOR FPC 10P	

Ref. No.	Part No.	Description	Remarks
CN303	1-815-688-11	CONNECTOR FPC 6PSN	
< FLAT CABLE >			
CN01B	9-885-090-42	CABLE-FLAT	
CN02B	9-885-079-25	CABLE-FLAT	
CN303B	1-824-062-11	CABLE FLAT 6P	
< DIODE >			
BD01	9-885-070-14	DIODE 1N5397GP	
BD02	9-885-070-14	DIODE 1N5397GP	
BD03	9-885-070-14	DIODE 1N5397GP	
BD04	9-885-070-14	DIODE 1N5397GP	
D601	1-804-407-11	DIODE 1N4148	
D605	1-804-407-11	DIODE 1N4148	
D1P101	1-804-407-11	DIODE 1N4148	
D1P102	1-804-407-11	DIODE 1N4148	
D1P103	1-804-407-11	DIODE 1N4148	
D1S05	1-804-408-11	DIODE UF4007	
D1S06	1-804-407-11	DIODE 1N4148	
D1S07	1-804-412-11	DIODE F1T4	
D1S30	9-885-076-80	DIODE MBRF10A0	
D1S31	9-885-076-80	DIODE MBRF10A0	
D1S32	9-885-076-80	DIODE MBRF10A0	
D1S33	9-885-076-80	DIODE MBRF10A0	
D1S34	1-804-412-11	DIODE F1T4	
D1S35	1-804-411-11	DIODE UG2D	
D1S36	1-804-412-11	DIODE F1T4	
D1S37	1-804-412-11	DIODE F1T4	
D1S40	1-804-412-11	DIODE F1T4	
ZD401	1-804-414-11	DIODE UZP33B	
ZD1P02	1-804-418-11	DIODE MTZJ12B	
ZD1P03	1-804-417-11	DIODE MTZJ9.1B	
ZD1P04	1-804-416-11	DIODE MTZJ5.1B	
ZD1P05	9-885-070-18	DIODE UZP27B	
ZD1P06	9-885-070-17	DIODE UZ5.6BM	
ZD1S01	1-805-265-11	DIODE MTZJ4.3B	
ZD1S02	9-885-070-23	DIODE MTZJ18C	
< FUSE >			
△F1S01	1-576-525-11	FUSE (1.6A/250V)	
△FR01	1-576-729-11	FUSE-RADIAL LEAD (1A/50V)	
△FR02	1-576-729-11	FUSE-RADIAL LEAD (1A/50V)	
△FR03	1-576-729-11	FUSE-RADIAL LEAD (1A/50V)	
< FUSE CLIP >			
FC1S01	1-576-527-11	FUSE CLIP	
FC1S02	1-576-527-11	FUSE CLIP	
< IC >			
IC301	1-805-296-11	IC LA71207 (VIDEO)	
IC501	9-885-070-60	IC LA72670M (SIGNAL PROCESSOR)	
IC601	9-885-092-85	IC (MICOM)	
IC603	9-885-079-45	IC S524A (EEPROM)	
IC1P01	9-885-069-92	IC KA78R12 (VOLT REGU)	
IC1P02	9-885-084-28	IC (SWITCH VOL. REG)	
IC1P03	9-885-070-56	IC G9105 (POSI. FIXED REG)	
IC1P04	9-885-069-92	IC KA78R12 (VOLT REGU)	
IC1P05	9-885-070-57	IC G9205 (POSI. FIXED REG)	

The components identified by mark △ or dotted line with mark △ are critical for safety. Replace only with part number specified.

Les composants identifiés par une marque △ sont critiques pour la sécurité. Ne les remplacer que par une pièce portant le numéro spécifié.

VCR MAIN

Ref. No.	Part No.	Description	Remarks
IC1S01	9-885-037-01	IC (PWM CONTROLLER)	
△ IC1S02	1-804-440-11	PHOTO COUPLER	
IC1S03	1-804-445-11	IC KA4318	
IC6B1	1-804-773-11	IC (RESET)	
		< JACK >	
J1J	9-885-084-29	JACK-IEEE1394 4P/1C (DV IN)	
		< COIL/FERRITE BEAD >	
BD1P01	1-400-086-11	FERRITE CORE	
BD1S01	1-400-085-11	INDUCTOR 70uH	
BD1S02	1-400-085-11	INDUCTOR 70uH	
L301	1-400-085-11	INDUCTOR 70uH	
L302	1-400-086-11	FERRITE CORE	
L303	1-400-086-11	FERRITE CORE	
L304	1-400-086-11	FERRITE CORE	
L305	1-400-085-11	INDUCTOR 70uH	
L306	1-400-083-11	INDUCTOR RA 1500uH	
L307	1-400-074-11	INDUCTOR 100uH	
L501	1-400-086-11	FERRITE CORE	
L502	1-400-086-11	FERRITE CORE	
L601	1-400-082-11	INDUCTOR RA 100uH	
L602	1-400-074-11	INDUCTOR 100uH	
L603	1-400-074-11	INDUCTOR 100uH	
L1P02	1-400-074-11	INDUCTOR 100uH	
L1P101	1-400-074-11	INDUCTOR 100uH	
△ L1S01	1-424-831-11	LINE FILTER 20mH	
△ L1S02	1-424-830-11	LINE FILTER 30mH	
L1S30	9-885-070-00	COIL CHOKE DR CHOKE (8*6)	
L1S31	9-885-070-00	COIL CHOKE DR CHOKE (8*6)	
L1S32	1-424-828-11	COIL CHOKE 10uH	
		< LED >	
LD601	9-885-060-84	LED-IR (T/S LED)	
		< TRANSFORMER >	
△ PT01	9-885-069-94	TRANS SWITCHING EER3531	
		< PHOTO INTERRUPTER >	
PT601	9-885-060-86	PHOTO INTERRUPTER (S-REEL)	
PT602	9-885-060-86	PHOTO INTERRUPTER (R-REEL)	
		< TRANSISTOR >	
Q302	9-885-060-82	TRANSISTOR KSA812	
Q303	1-805-016-11	TRANSISTOR KSC1623-L	
Q304	9-885-060-82	TRANSISTOR KSA812	
Q305	1-804-422-11	TRANSISTOR KTC3203	
Q306	9-885-060-82	TRANSISTOR KSA812	
Q307	1-804-422-11	TRANSISTOR KTC3203	
Q308	1-804-422-11	TRANSISTOR KTC3203	
Q601	9-885-043-26	TRANSISTOR KSR1104	
Q1P103	9-885-084-19	FET GFP50N03	
Q1P105	9-885-060-83	TRANSISTOR KSC2328AY	
Q1P106	1-804-429-11	TRANSISTOR KSR2001	
Q1P107	1-804-421-11	TRANSISTOR KSC945	
Q1P108	9-885-060-83	TRANSISTOR KSC2328AY	
Q1P109	9-885-060-83	TRANSISTOR KSC2328AY	
Q1P110	9-885-060-83	TRANSISTOR KSC2328AY	

Ref. No.	Part No.	Description	Remarks
Q1S01	9-885-036-95	FET	
		< RESISTOR >	
R1S04	1-244-373-11	RESISTOR 2.7	
R1S13	1-245-575-11	R-METAL OXIDE	
		< PHOTO TRANSISTOR >	
S601	9-885-060-85	PHOTO TRANSISTOR (END SENSOR)	
S602	9-885-060-85	PHOTO TRANSISTOR (START SENSOR)	
		< SWITCH >	
SW602	9-885-061-07	SWITCH REC (REC-SW)	
SW603	9-885-061-06	SWITCH MODE (MODE-SW)	
		< VIBRATOR >	
XT301	1-795-603-11	VIBRATOR CRYSTAL (3.579545MHz)	
XT601	1-795-334-11	VIBRATOR CRYSTAL (14.31818MHz)	
MISCELLANEOUS			

8	9-885-084-31	ASSY-DVDR DECK	
△ 200	1-824-674-11	POWER CORD EP2 SPT-2	
159	9-885-090-43	FFC CABLE-FLAT	
B410	1-796-434-11	LOADING ASSY, MOTOR	
B560	9-885-081-58	MOTOR CAPSTAN	
G001	9-885-069-98	ASSY-CYLINDER	
G480	9-885-083-60	ASSY ACE HEAD	
ACCESSORIES			

2-636-467-11		MANUAL, INSTRUCTION (ENGLISH) (VX515)	
2-636-467-21		MANUAL, INSTRUCTION (FRENCH)	
		(VX515: Canadian)	
2-636-468-11		QUICK START GUIDE (ENGLISH) (VX515)	
2-636-468-21		QUICK START GUIDE (FRENCH)	
		(VX515: Canadian)	
2-650-209-11		MANUAL, INSTRUCTION (ENGLISH) (VX511)	
2-650-210-11		QUICK START GUIDE (ENGLISH) (VX511)	
9-885-090-47		REMOCON-ASSY (RMT-D224A)	
9-885-094-69		REMOCOM DOOR-REMOCOM	
		(for RMT-D224A)	
9-885-093-70		DOOR-BATTERY REMOCOM (for RMT-D224A)	


The components identified by mark △ or dotted line with mark △ are critical for safety. Replace only with part number specified.

Les composants identifiés par une marque △ sont critiques pour la sécurité. Ne les remplacer que par une pièce portant le numéro spécifié.

VHS MECHANICAL ADJUSTMENT MANUAL VII

TS-10 MECHANISM

Please use this manual with the service manual.



VHS MECHANISM DECK

SONY®

TABLE OF CONTENTS

1. Disassembly and Reassembly

1-1	Deck Parts Locations	3
1-1-1	Top View	3
1-1-2	Bottom View	5
1-2	Main Deck	6
1-2-1	Lever FL Door Removal	6
1-2-2	Holder FL Cassette Ass'y Removal	6
1-2-4	Lever FL Arm Ass'y Removal	7
1-2-3	Slider FL Drive, Gear FL Cam Removal	7
1-2-5	Gear Worm Wheel Removal	8
1-2-6	Motor Loading Ass'y Removal	8
1-2-7	Bracket Gear, Gear Joint 2, 1 Removal	9
1-2-8	Gear Loading Drive, Slider Cam, Lever Load S, T Ass'y Removal	9
1-2-9	Gear Loading Drive, Slider Cam, Lever Load S, T Ass'y Assembly	10
1-2-10	Lever Pinch Drive, Lever Tension Drive Removal	10
1-2-11	Lever Tension Ass'y, Band Brake Ass'y Removal	11
1-2-12	Lever Brake S, T Ass'y Removal	11
1-2-13	Gear Idle Ass'y Removal	12
1-2-14	Disk S, T Reel Removal	12
1-2-15	Holder Clutch Ass'y Removal	13
1-2-16	Lever Up Down Ass'y, Gear Center Ass'y Removal	13
1-2-18	Lever Unit Pinch Ass'y, Plate Joint, Spring Pinch Drive Removal	14
1-2-17	Guide Cassette Door Removal	14
1-2-19	Lever #9 Guide Ass'y Removal	15
1-2-20	FE Head Removal	15
1-2-21	ACE Head Removal	16
1-2-22	Slider S, T Ass'y Removal	16
1-2-23	Plate Ground Deck, Cylinder Ass'y Removal	17
1-2-24	Belt Pulley Removal	17
1-2-26	Damper Capstan, Motor Capstan Ass'y Removal	18
1-2-27	How to Eject the Cassette Tape	18
1-3	The table of clearing, Lubrication and replacement time about principal parts	19
1-4	Tools and fixtures required for service	20

2. Alignment and Adjustment

2-1	Tape Transport System and Adjustment Locations	21
2-2	Tape Transport System Adjustment	22
2-2-1	ACE Head Assembly Adjustment	22
2-2-2	Linearity Adjustment (Guide roller S, T adjustment)	23
2-2-3	Check Transitional Operation from RPS to Play	24
2-2-4	Envelope Check	24
2-2-5	Tape Wrinkle Check	24
2-3	Reel Torque	24

1. Disassembly and Reassembly

1-1 Deck Parts Locations

1-1-1 Top View




Fig. 1-1 Top parts Location-1

- ❶ GEAR FL CAM
- ❷ MOTOR LOADING ASS'Y
- ❸ LEVER FL ARM ASS'Y
- ❹ HOLDER FL CASSETTE ASS'Y
- ❺ LEVER FL DOOR
- ❻ SLIDER FL DRIVE




Fig. 1-2 Top Parts Location-2

- | | |
|--------------------------|-----------------------|
| ❶ FE HEAD | ❸ DISK S REEL |
| ❷ CYLINDER ASS'Y | ❹ LEVER S BRAKE ASS'Y |
| ❸ ACE HEAD ASS'Y | ❺ GEAR IDLE |
| ❹ LEVER UNIT PINCH ASS'Y | ❻ LEVER IDLE |
| ❺ LEVER #9 GUIDE ASS'Y | ❼ LEVER T BRAKE ASS'Y |
| ❻ LEVER TENSION ASS'Y | ❽ DISK T REEL |
| ❼ BAND BRAKE ASS'Y | |

1-1-2 Bottom View




Fig. 1-3 Bottom Parts Location

- ❶ GEAR JOINT 1
- ❷ GEAR JOINT 2
- ❸ BRACKET GEAR
- ❹ MOTOR CAPSTAN ASS'Y
- ❺ LEVER T LOAD ASS'Y
- ❻ GEAR LOADING DRIVE
- ❼ LEVER S LOAD ASS'Y
- ❽ HOLDER CLUTCH ASS'Y
- ❾ BELT PULLEY
- ❿ SLIDER CAM

1-2 Main Deck

1-2-1 Lever FL Door Removal

- 1) Push the Holder FL Cassette Ass'y ❶ about 20mm in the direction of arrow "A".
- 2) Rotate the Lever FL Door ❷ in the direction of arrow "B".
- 3) Release the Hook ❸ and Remove the Lever FL Door ❷ in the direction of arrow "C".




Fig. 1-4 Lever FL Door Removal

1-2-2 Holder FL Cassette Ass'y Removal

- 1) Pull the Holder FL Cassette Ass'y ❶ to the eject position.
- 2) Pull the Holder FL Cassette Ass'y ❶ as grasping the Holder FL Cassette Ass'y ❶ and Lever FL Cassette-R ❷ in the same time to release hooking from Main Base until the Boss [A] of Holder FL Cassette Ass'y ❶ is taken out from the Rail [B].
- 3) Lift the Holder FL Cassette Ass'y ❶, in this time, you have to grasp the Lever FL Cassette-R ❷ continuously until the Holder FL Cassette Ass'y ❶ is taken out completely.

Note : Be sure to insert Lever FL Cassette-R ❷ in the direction of "A" to prevent separation and breakage of the Lever FL Cassette-R ❷ at disassembling and reassembling.




Fig. 1-5 Holder FL Cassette Ass'y Removal

1-2-3 Slider FL Drive, Gear FL Cam Removal

- 1) Pull the Slider FL Drive ❶ to the front direction.
- 2) Remove the Slider FL Drive ❶ in the direction of arrow. (Refer to Fig. 1-6)
- 3) Remove the Gear FL cam ❷.

Note : When reinstalling be sure to reassemble Slider FL drive ❶ after you insert the Boss of Lever FL ARM-R in Groove of Slider FL drive ❶.

Assembly : Align the Gear FL Cam ❶ with the Gear worm wheel Post as shown drawing. (Refer to Timing point)




Fig. 1-6 Slider FL Drive Removal




Fig. 1-7 Gear FL Cam, Gear Worm

1-2-4 Lever FL Arm Ass'y Removal

- 1) Push the hole "A" in the direction of arrow "B" use the pin.(about Dia.2.5)
- 2) Pull out the Lever FL Arm Ass'y ❶ from the Boss of Main Base.
- 3) Remove the Lever FL Arm Ass'y ❶ in the direction of arrow "C".




Fig. 1-8 Lever FL Arm Ass'y Removal

1-2-5 Gear Worm Wheel Removal

- 1) Remove the Gear Worm wheel ❶.




Fig. 1-9 Gear Worm Wheel Removal

1-2-6 Motor Loading Ass'y Removal

- 1) Remove the screw ❶.
- 2) Remove the Motor Loading Ass'y ❷.




Fig. 1-10 Motor Loading Ass'y Removal

1-2-7 Bracket Gear, Gear Joint 2, 1 Removal

- 1) Remove the SCREW ❶.
- 2) Remove the Bracket Gear ❷.
- 3) Remove the Gear Joint 2 ❸.
- 4) Remove the Gear Joint 1 ❹.

Assembly :

- 1) Be sure to align dot mark of Gear Joint 1 ❶ with dot mark of Gear Joint 2 ❷ as shown Fig 1-12.
(Refer to Timing point1)
- 2) Confirm the Timing Point 2 of the Gear Joint 2 ❷ and Slider Cam ❸.




Fig. 1-11 Bracket Gear, Gear Joint 1,2 Removal




Fig. 1-12 Gear Joint 1,2 Assembly

1-2-8 Gear Loading Drive, Slider Cam, Lever Load S, T Ass'y Removal

- 1) Remove the Belt Pulley. (Refer to Fig. 1-30)
- 2) Remove the Gear Loading Drive ❶ after releasing Hook [A] in the direction arrow as shown in detail drawing.
- 3) Remove the Slider Cam ❷.
- 4) Remove the Lever Load S ❸, Link Load S ❹ & Lever Load T ❺, Link Load T ❻.




Fig. 1-13 Gear Loading Drive, Slider Cam, Lever T, S Load Ass'y Removal

1-2-9 Gear Loading Drive, Slider Cam, Lever Load S, T Ass'y Assembly

- 1) When reinstalling, be sure to align dot of Lever Load T Ass'y ❶ with dot of Lever Load S Ass'y ❷ as shown in drawing, (Refer to Timing Point 1).
- 2) Insert the Pin A,B,C,D into the Slider Cam ❸ hole,
- 3) Be sure to align dot of Lever Load T ❶ and dot of Gear Loading Drive ❹, (Refer to Timing Point 2).
- 4) Aline dot of Gear Loading drive ❹ with mark of Slider Cam ❸ as shown in drawing(Refer to Timing Point 3).




Fig. 1-14 Gear Loading Drive, Slider Cam, Lever Load S, T Ass'y Assembly

1-2-10 Lever Pinch Drive, Lever Tension Drive Removal

- 1) Remove the Lever Pinch Drive ❶, Lever Tension Drive ❷.




Fig. 1-15 Lever Pinch Drive, Lever Tension Drive Removal

1-2-11 Lever Tension Ass'y, Band Brake Ass'y Removal

- 1) Remove the Lever Brake S Ass'y (Refer to Fig 1-17).
- 2) Remove the Spring Tension Lever **1**.
- 3) Rotate stopper of Main Base in the direction of arrow "A".
- 4) Lift the Lever Tension Ass'y **2** & Band brake Ass'y **3**.

Note :

- 1) When replacing the Lever Tension Ass'y **2**, be sure to apply Grease on the post,
- 2) Take care not to touch stain on the felt side, and not to be folder and broken Band brake Ass'y
- 3) After Lever Tension Ass'y seated, Rotate stopper of Main Base to the Mark[B].




Fig. 1-16 Lever Tension Ass'y,
Band Brake Ass'y Removal

1-2-12 Lever Brake S, T Ass'y Removal

- 1) Release the Hook [A] and the Hook [B], [C] in the direction of arrow as shown in Fig 1-17.
- 2) Lift the Lever S, T Brake Ass'y **1**, **2** with spring brake **3**.

Assembly :

- 1) Assembly the Lever S Brake Ass'y **1** on the Main Base.
- 2) Assembly the Lever T Brake Ass'y **2** with spring brake **3**.

Note : Take extreme care not to be folded and transformed Spring Brake at removing or reinstalling.




Fig. 1-17 Lever Brake S, T Ass'y Removal

1-2-13 Gear Idle Ass'y Removal

- 1) Push the Lever Idle ❶ in the direction of arrow "A", "B".
- 2) Lift the Lever Idle ❶.

Assembly :

- 1) Apply oil in two Bosses of Lever Idle ❶.
- 2) Assemble the Gear Idle ❷ with the Lever Idle ❶.

Note : When replacing the Gear Idle ❷, be sure to add oil in the boss of Lever Idle ❶.




Fig. 1-18 Gear Idle Ass'y Removal

1-2-14 Disk S, T Reel Removal

- 1) Lift the Disk S, T Reel ❶, ❷.




Fig. 1-19 Disk S, T Reel Removal

1-2-15 Holder Clutch Ass'y Removal

- 1) Remove the Washer Slit ❶.
- 2) Lift the Holder Clutch Ass'y ❷.

Note : When you reinstall Holder Clutch Ass'y

- 1) Check the condition of spring as shown in detail A.
- 2) Don't push Holder Clutch Ass'y down with excessive force Just insert Holder Clutch Ass'y into post center with dead force and Rotate it smoothly. Be sure to confirm that spring is in the slit of Gear Center Ass'y as shown in detail B.




Fig. 1-20 Holder Clutch Ass'y Removal

1-2-16 Lever Up Down Ass'y, Gear Center Ass'y Removal

- 1) Remove the 2 hooks in the direction of arrow as shown Fig. 1-21 and lift the Lever Up Down Ass'y ❶.
- 2) Lift the Gear Center Ass'y ❷.

Assembly :

- 1) Insert the Lever Up Down Ass'y ❶ in the rectangular holes on Main Base as shown in Fig 1-22.
- 2) Lift the Lever Up Down Ass'y ❶ about 35 degree.(Refer to Fig 1-22)
- 3) Insert Ring of the Gear Center Ass'y ❷ in the Guide of the Lever Up Down Ass'y ❶.
- 4) Insert the Gear Center Ass'y ❷ in the post on Main Base.
- 5) Push down the Lever Up Down Ass'y ❶ for locking of the Hook.

Note :

- 1) Take care not to separate and sentence does not mark sense.
- 2) Be sure to confirm that Ring of the Gear Center Ass'y ❷ is in the Guide of the Lever Up Down Ass'y ❶ after finishing assembly of Lever Up




Fig. 1-21 Lever Up Down Ass'y Removal




Fig. 1-22 Lever Up Down Ass'y Removal

1-2-17 Guide Cassette Door Removal

- 1) Lift the Hook [A].
- 2) Rotate the Guide Cassette Door ❶ in the direction of arrow.

Note : After reinstalling the Guide Cassette Door ❶ sure the Hook [A].




Fig. 1-23 Guide Cassette Door Removal

1-2-18 Lever Unit Pinch Ass'y, Plate Joint, Spring Pinch Drive Removal

- 1) Lift the Unit Pinch Ass'y ❶.
- 2) Remove the Plate Joint ❷ from Lever Pinch Drive.
- 3) Remove the Spring Pinch Drive ❸.

Note :

- 1) Take extreme care not to touch the grease on the Roller Pinch.
- 2) When reinstalling, be sure to apply grease on the post pinch roller.




Fig. 1-24 Lever Unit Pinch Ass'y, Plate Joint, Spring Pinch Drive Removal

1-2-19 Lever #9 Guide Ass'y Removal

- 1) Remove the Spring #9 Guide ❶.
- 2) Lift the Spring #9 Guide Ass'y ❷ in the direction of arrow "A".

Note :

- 1) Take extreme care not to get grease on the tape Guide Post.
- 2) After reinstalling, check the bottom side of the Post #9 Guide to the top side of Main Base.




Fig. 1-25 Lever #9 Guide Ass'y Removal

1-2-20 FE Head Removal

- 1) Remove the screw ❶.
- 2) Lift the FE Head ❷.




Fig. 1-26 FE Head Removal

1-2-21 ACE Head Removal

- 1) Pull out the FPC from connector of ACE Head Ass'y ②.
- 2) Remove the screw ①.
- 3) Lift the ACE Head Ass'y ②.




Fig. 1-27 ACE Head Removal

1-2-22 Slider S, T Ass'y Removal

- 1) Move the Slider S, T Ass'y ①, ② to slot, and then lift it to remove. (Refer to arrow)




Fig. 1-28 Slider S, T Ass'y Removal

1-2-23 Plate Ground Deck, Cylinder Ass'y Removal

- 1) Remove the 3 Screws ❶.
- 2) Lift the Plate Ground Deck ❷.
- 3) Lift the Cylinder Ass'y ❸.

Assembly :

- 1) Match the 3 holes in the bottom of Cylinder ass'y ❸ to the 3 holes of Main Base as attending not to drop or knock the Cylinder ass'y ❸.
- 2) Tighten the 1 Screw ❶.
- 3) Match the Plate Ground Deck ❷ to the Hole of Base Main.
- 4) Tighten the other 2 Screws ❶.

Note :

- 1) Take care not to touch the Cylinder Ass'y ❸ and the tape guide post at reinstalling.
- 2) When reinstalling, Don't push down too much on Screw Driver.




Fig. 1-29 Plate Ground Deck, Cylinder Ass'y Removal

1-2-24 Belt Pulley Removal

- 1) Remove the Belt Pulley ❶.

Note : Take extreme care not to get grease on Belt Pulley ❶ at assembling or reassembling.




Fig. 1-30 Belt Pulley Removal

1-2-25 Level Head Cleaner Ass'y Removal

- 1) Release the Hook ❶.
- 2) Lift the Lever Head Cleaner Ass'y ❷.




Fig. 1-31 Level Head Cleaner Ass'y Removal

1-2-26 Damper Capstan, Motor Capstan Ass'y Removal

- 1) Remove the Damper Capstan ❶ in the direction of arrow.
- 2) Remove the 3 Screws ❷.
- 3) Remove the Motor Capstan Ass'y ❸.

Assembly :

- 1) Match the 3 holes of Motor Capstan Ass'y ❸ to the 3 holes of Main Base. Be careful not to drop or knock the Motor Capstan Ass'y ❸.
- 2) Tighten the 3 Screws ❷ in the direction of arrow as shown detail drawing.
- 3) Assemble the Damper Capstan ❶.

Note : After tightening screws, check if there is gap between the head of screws and the top side of Main Base. There should have no gap between the head of screws and the top side of Main Base. After reinstalling, adjusting the tape transport system again.




Fig. 1-32 Damper Capstan, Motor Capstan Ass'y Removal

1-2-27 How to Eject the Cassette Tape (If the unit does not operate on condition that is inserted into housing ass'y)

- 1) Turn the Gear worm ❶ clockwise with screw driver. (Refer to arrow)
(Other method : Remove the Screw of Motor Load Ass'y, Separate the Motor Load Ass'y)




Fig. 1-33

- 2) When Slider S,T are approached in the position of unloading, rotate holder Clutch counterclockwise after inserting screw driver in the hole of frame's bottom in order to wind the unwinded tape. (Refer to Fig.1-34)
(If you rotate Gear Worm ❶ continuously when tape is in state of unwinding, you may cause a tape contamination by grease and tape damage. Be sure to wind the unwinded tape in the state of set horizontally.)
- 3) Rotate Gear Worm ❶ clockwise using screw driver again up to the state of eject mode and then pick out the tape. (Refer to Fig.1-33)




Fig. 1-34

1-3 The table of clearing, Lubrication and replacement time about principal parts

1) The replacement time of parts is not life of parts.

2) The table 1-1 is that the VCR Set is in normal condition (normal temperature, normal humidity).

The checking period may be changed owing to the condition of use, runtime and environmental conditions.

3) Life of the Cylinder Ass'y is depend on the condition of use.

4) See exploded view for location of each parts.

<Table 1-1>

*	Parts Name	Checking Period										Remark
		500	1000	1500	2000	2500	3000	3500	4000	4500	5000	
T A P E P A T H S Y S T E M	POST TENSION	Δ	Δ	Δ	Δ	Δ	Δ	Δ	Δ	Δ	Δ	- To clean the parts, use patch and alcohol (solvent).
	SLANT POST S, T	Δ	Δ	Δ	Δ	Δ	Δ	Δ	Δ	Δ	Δ	
	#8 GUIDE SHAFT	Δ	Δ	Δ	Δ	Δ	Δ	Δ	Δ	Δ	Δ	- After cleaning, use the video tape after alcohol is gone away completely.
	CAPSTAN SHAFT	Δ	Δ	Δ	Δ	Δ	Δ	Δ	Δ	Δ	Δ	
	#9 GUIDE POST	Δ	Δ	Δ	Δ	Δ	Δ	Δ	Δ	Δ	Δ	- We recommend to use oil [NT-68] or solvent.
	#3 GUIDE POST	Δ	Δ	Δ	Δ	Δ	Δ	Δ	Δ	Δ	Δ	
	GUIDE ROLLER S, T	Δ	Δ	Δ	O	O	O	O	O	O	O	- One or two drops of oil should be applied after cleaning with alcohol.
	CYLINDER ASS'Y	Δ	O	O	O	O	O	O	O	O	O	
	FE HEAD	Δ	Δ	Δ	O	O	O	O	O	O	O	- Periodic time of applying oil (Apply oil after cleaning)
	ACE HEAD	Δ	O	O	O	O	O	O	O	O	O	
	PINCH ROLLER	Δ	O	O	O	O	O	O	O	O	O	- The excessive applying oil may be the cause of malfunction.
	POST REEL S, T		◆		◆		◆		◆		◆	
	SLEEVE TENSION		◆		◆		◆		◆		◆	
	POST CENTER		◆		◆		◆		◆		◆	
	LEVER IDLE BOSS (2Point)		◆		◆		◆		◆		◆	
D R I V I N G S Y S T E M	CAPSTAN MOTOR PULLEY	Δ	Δ	Δ	Δ	Δ	O	O	O	O	O	
	BELT PULLEY				O	O	O	O	O	O	O	
	HOLDER CLUTCH ASS'Y	Δ	O	O	O	O	O	O	O	O	O	
	GEAR CENTER ASS'Y		O	O	O	O	O	O	O	O	O	
	GEAR IDLE (2Point)		O	O	O	O	O	O	O	O	O	
	LOADING MOTOR		O	O	O	O	O	O	O	O	O	
B R A K E S Y S T E M	BAND BRAKE ASS'Y		O	O	O	O	O	O	O	O	O	
	BRAKE T ASS'Y		O	O	O	O	O	O	O	O	O	


Δ : Cleaning

O : Check and replacement in necessary

◆ : Add Oil

1-4 Tools and fixtures required for service

Ref. No.	Name		Part No.	Caved Jig No.	Remarks
J-1	Torque Measurement Cassette VHT-103S		J-6090-072-A		For FWD & back tension torque measurement
	Torque Measurement Cassette VHT-404S		J-6082-012-A		For CUE and REVIEW torque measurement
J-2	Alignment Tape	KRV-52NE (NTSC)	8-192-605-41		Tape path, Audio azimuth, X-value adjustments
		KRV-51N2 (NTSC)	8-192-605-32		Electrical adjustments, Operation check
		KRV-52PL (PAL)	8-192-605-46		Tape path, Audio azimuth, X-value adjustments
		KRV-51P (PAL)	8-192-605-36		Electrical adjustments, Operation check
J-3	Cleaning Fluid		Y-2031-001-0	—	
J-4	Chamois Leather		2-034-697-00	—	
J-5	Dental Mirror (with Handle)		J-6080-029-A	SL-5052	Tape path and tape traveling adjustments or checks
	Dental Mirror (Mirror)		J-6080-030-1		
J-6	Grease Molykote EM 30LG		J-6090-014-A		Net. 20 g
J-6	Diamond Oil NT-68		7-661-018-18		



<Fig 1-35>

2. Alignment and Adjustment

2-1 Tape Transport System and Adjustment Locations

The tape transport system has been adjusted precisely in the factory. Alignment is not necessary except for the following :

- 1) Noise observed on the screen.
- 2) Tape damage.
- 3) Parts replacement in the tape transport system.

Lower flange height of tape guide is used as the reference for the transport adjustment.

To maintain the height of the tape guide and prevent damage, do not apply excessive force onto the main base.




Fig. 2-1 Location of Tape Transport Adjustment




Fig. 2-2 Tape Travel Diagram

2-2 Tape Transport System Adjustment

When parts are replaced, perform the required adjustments by referring to procedures for the tape transport system. If there are any changes to the tape path, first run a T-120 tape and make sure excessive tape wrinkle does not occur at the tape guides.

- 1) If tape wrinkle is observed at the guide roller S, T, turn the guide roller S, T until wrinkle disappears.
- 2) If the tape wrinkle is still observed at the tape guide, perform the tilt adjustment of the ACE head. (See page 5-3 of the Service Manual for Test Point Locations.)

2-2-1 ACE Head Assembly Adjustment

2-2-1(a) ACE HEAD HEIGHT ADJUSTMENT

- 1) Run the alignment tape (KRV-52NE (NTSC)/52PL (PAL)) in the playback mode.
- 2) Observe surface of the audio head using a dental mirror.
- 3) Turn screw (C) clockwise or counterclockwise until the gap of lower tape edge and the lower edge of the control head is about 0.25mm. (Refer to Fig. 2-3 and 2-4)




Fig. 2-3 Location of ACE Head Adjustment Screw




Fig. 2-4 ACE Head Height Adjustment

2-2-1(b) ACE HEAD TILT ADJUSTMENT

- 1) Playback a blank tape and observe the position of the tape at the lower flange of tape guide.
- 2) Confirm that there is no curl or wrinkle at the lower flange of tape guide as shown in Fig. 2-5 (B).
- 3) If a curl or wrinkle of the tape occurs, slightly turn the screw (A) tilt adjust on the ACE head ass'y.
- 4) Reconfirm the ACE head height.




Fig. 2-5 Tape Guide Check

2-2-1(c) AUDIO AZIMUTH ADJUSTMENT

- 1) Load alignment tape (KRV-52NE (NTSC)/52PL (PAL)) and playback the NTSC : 5KHz (PAL : 4KHz) signal.
- 2) Connect channel-1 scope probe to audio output test point.
- 3) Adjust screw (B) to achieve maximum audio level. (See Fig. 2-3)

2-2-1(d) ACE HEAD POSITION (X-POINT) ADJUSTMENT

- 1) See "2. Alignment and Adjustment" for ACE Head position (X-Point) adjustment.

2-2-2 Linearity Adjustment (Guide roller S, T adjustment)

- 1) Playback the alignment tape (KRV-51N2 (NTSC)/51P (PAL)) (SP mode, Mono Scope).
- 2) Observe the video envelope signal on an oscilloscope (triggered by the video switching pulse).
- 3) Make sure the video envelope waveform (at its minimum) meets the specification shown in Fig. 2-6.

If it does not, adjust as follows :

Note :

a=Maximum output of the video RF envelope.

b=Minimum output of the video RF envelope at the entrance side.

c=Minimum output of the video RF envelope at the center point.

d=Maximum output of the video RF envelope at the exit side.

- 4) If the section A in Fig. 2-7 does not meet the specification, adjust the guide roller S up or down.
- 5) If the section B in Fig. 2-7 does not meet the specification, adjust the guide roller T up or down.
- 6) Play back the alignment tape (SP mode, Mono Scope).
- 7) Connect an oscilloscope CH-1 to the Envelope and CH-2 to the H'D SW Pulse for triggering.
- 8) Turn the guide roller heads with a flat head () driver to obtain a flat video RF envelope as shown in Fig. 2-8.




Fig. 2-6 Envelope Waveform Adjustment




Fig. 2-7 Adjustment Points




Fig. 2-8 Guide Roller S, T Height Adjustment

2-2-3 Check Transitional Operation from RPS to Play

Check transition from RPS mode to play mode :
Using a pre-recorded SP tape, make sure the entry side of envelope comes to an appropriate steady state within 3 seconds (as shown in Fig. 2-9).
If the envelope waveform does not reach specified peak-to-peak amplitude within 3 seconds, adjust as follows :

- 1) Make sure there is no gap between the supply roller lower flange and the tape.
If there is a gap, adjust the supply guide roller again.
- 2) Change operation mode from the RPS to the play mode (again) and make sure the entry side of envelope rises within 3 second.




Fig. 2-9 Video Envelope Rising when Operation mode Changes from RPS to Play Mode

2-2-4 Envelope Check

- 1) Make recordings on T-120 (E-120) and T-160 (E-180) tape.
Make sure the playback output envelope meets the specification as shown in Fig. 2-10.
- 2) Play back a self recorded tape (recording made on the unit using with T-120 (E-120)).
The video envelope should meet the specification as shown in Fig. 2-10.
In SP mode, (A) should equal (B).
If the head gap is wide, upper cylinder should be checked.




Fig. 2-10 Envelope Output and Output Level

2-2-5 Tape Wrinkle Check

- 1) Run the T-160 (E-180) tape in the playback, FPS, RPS and Pause modes and observe tape wrinkle at each guide.
- 2) If excessive tape wrinkle is observed, perform the following adjustments in Playback mode :
 - ◆ Tape wrinkle at the guide roller S, T section :
Linearity adjustment.
 - ◆ Tape wrinkle at tape guide flange :
ACE head assembly coarse adjustment.

2-3 Reel Torque

- 1) The rotation of the capstan motor causes the Holder Clutch Ass'y to rotate through the Belt Pulley.
- 2) The spring wrap PLAY/REV of holder clutch ass'y drives the disk reel S, T through gear idle by rotation of gear center ass'y.
- 3) Brake is operated by slider cam at FF/REW mode.
- 4) Transportation of accurate driving force is done by gears. (Gear Center Ass'y)

Note : If the spec. does not meet the followings specifications, replace the holder clutch ass'y and then recheck.

<Table 2-1>

MODE	TORQUE g/cm	GAUGE
PB	42 ± 11	Cassette Torquemeter
RPS	145 ± 30	Cassette Torquemeter

